

'87-95 32V 928 S4/GT/GTS Vacuum Line Diagram

The diagram provided shows the factory vacuum line diagram with locations, lengths, and identification of size of connectors shown for proper placement.

Remove your new kit & familiarize yourself with the separate lines from your kit. You might want to remove some of the lines (pull gently) to ease installation. You do not have to replace all the lines shown/provided at one time. It is highly suggested that you replace one line/one line cluster at a time.

Note: for cars equipped with Automatic transmissions, snip the middle of the 5" lead connecting the fuel pressure regulator and Tee in the auto-trans vacuum line.

