

Maintenance Schedule — Vutek 3r (EFI)

MX-Printing (Mexico) · EFI VUTEk 3r LED-UV roll-to-roll, 3.2 m · SER # 9870418

Source: EFI VUTEk 3r & 5r Series Maintenance Guide (OMM-00144) and EFI 3r/5r Operator Training Guide. EFI intervals assume one 8-hour shift, 5 days/week — the "Weekly" section is EFI's 40-hour bucket; shorten intervals proportionally when running multiple shifts. Matches the checklist in the maintenance dashboard.

Daily / Shift

Clean print head plate / around print head area EFI "every 4 hours"	Every Shift
--	-------------

Purge and wipe print heads; nozzle test until clean EFI "every 4 hours"	Every Shift
--	-------------

Clean the print platen (IPA, scraper, tip cleaner) EFI "every 8 hours"	Daily
---	-------

Clean the measure-media sensor	Daily
--------------------------------	-------

Clean the ink sink	Daily
--------------------	-------

Clean the LED lamp glass on both UV lamps Carriage raised to 35 mm	Daily
---	-------

Clean the ionizer bars	Daily
------------------------	-------

Clean the carriage crash sensors (left and right)	Daily
---	-------

Print head care — 20 s soak per head face, purge, standard clean	Daily
--	-------

White ink maintenance — stir, 2 s white purge, dry-wipe white heads Print a small white job to keep heads healthy	Daily
--	-------

Check facility air compressor and air filters; drain moisture	Daily
---	-------

Check exhaust filter; replace if dirty	Daily
--	-------

Weekly (EFI 40-hour bucket)

Clean the freefall rollers (roll conditioner) Do twice weekly when running two shifts	Weekly
--	--------

Clean the Y (shaft) and T (tension) rubber rollers	Weekly
--	--------

Clean the metal rollers — feed, press, collector	Weekly
--	--------

Lubricate the carriage bearings 3 pumps Molykote Longterm W2 per bearing	Weekly
---	--------

Clean the carriage rail ends (remove excess grease)	Weekly
---	--------

Empty the waste ink container	Weekly
-------------------------------	--------

Check chiller fluid level; top up with distilled water	Weekly
--	--------

Check the last-chance air and water filters	Weekly
---	--------

Monthly

Clean the vented exterior covers	Monthly
----------------------------------	---------

Vacuum the cable carrier and shelf	Monthly
Clean the three main exhaust vents	Monthly
Wipe the linear encoder strip	Monthly
Clean the carriage home sensor	Monthly

Quarterly & Longer

Inspect/replace white ink degasser tubes	Quarterly
Vacuum the power supplies and motorized drivers	Quarterly
Create a printer configuration backup	Quarterly
Replace the primary ink filters (all colors)	Half-Yearly
Schedule EFI/dealer technician PM visit	Yearly

As Needed

Repeat head soak/purge on nozzle dropouts or banding	As Required
Bi-directional / fine-tuning alignment after head change or drift	As Required
Replace exhaust filter whenever the daily check shows it dirty	As Required

Supplies to keep stocked: clean-room wipes · print head cleaning fluid (P/N 77700253) · IPA · roll conditioner · Molykote W2 grease + gun (P/N 77700198) · primary ink filters · degasser tubing · nitrile gloves · safety glasses

References: EFI OMM-00144 VUTEk 3r/5r Maintenance Guide (inkjet.support.efi.com) · EFI 3r/5r Operator Training Guide (June 2018). Prepared August 2026 for the WS Display machine maintenance dashboard.