

Tool guide

Every tool, its cursor icon, how to type it and what it does.

Draw

Icon	Tool	What it does
	LINE also: L · in Spanish: LINEA	LINE [M] — chained lines (Escape finishes); with M, a line given by its midpoint
	PLINE also: PL · in Spanish: POLILINEA	Polyline. Type C to close it; Escape or Enter finishes it.
	RECTANGLE also: REC, RECT · in Spanish: RECTANGULO	RECTANGLE [C · 3P · M] — two corners; from the center; three points (rotated); by size
	POLIGONO also: POL, POLYGON	POLYGON [sides] — regular polygon by center and vertex (L: by the midpoint of a side)
	CIRCLE also: C · in Spanish: CIRCULO	CIRCLE [2P · 3P · D] — center and radius; two diameter points; three points; center and diameter
	ARC also: A · in Spanish: ARCO	ARC [CIF · IFR · ICA] — three points; center-start-end; start-end-radius; start-center-angle
	ELLIPSE also: EL · in Spanish: ELIPSE	ELLIPSE [E] — by center, axis endpoint and minor semi-axis; with E, by both axis endpoints
	SPLINE also: SPL	SPLINE [CV] — curve through the points you give; with CV, a curve pulled by control points (Bézier). Escape finishes.
	POINT also: PU · in Spanish: PUNTO	Marks a point (works as a node for snaps)
	HATCH also: H, SOMBREADO · in Spanish: RAYADO	Hatches a closed polyline or a circle: the pattern is picked in a gallery with a live preview
	TEXT also: T, DT, MT, TM, TEXTOM · in Spanish: TEXTO	Text (one or more lines): Enter saves, Alt+Enter makes a new line

Edit

Icon	Tool	What it does
	ERASE also: B, E, SUPR · in Spanish: BORRAR	Erases the selection (Del key)
	MOVE also: M · in Spanish: MOVER	Moves the selection
	COPY also: CP, CO · in Spanish: COPIAR	Copies the selection
	ROTATE also: RO · in Spanish: ROTAR	Rotates the selection around a point
	SCALE also: ES, SC · in Spanish: ESCALAR	Scales the selection: base point, reference point and new point (or type the factor)
	MIRROR also: SI, MI · in Spanish: ESPEJO	Mirrors the selection across an axis

Icon	Tool	What it does
	DESFASE also: DF, O, OFFSET	Copies a line, polyline, circle or arc at a given distance
	TRIM also: RC, TR · in Spanish: RECORTAR	Removes the piece of line or arc you pick
	EXTEND also: EXT, EX · in Spanish: EXTENDER	Extends a line to the first thing it meets
	FILLET also: EM, F · in Spanish: EMPALME	Rounds the corner between two lines with a radius
	CHAMFER also: CH, CHA · in Spanish: CHAFLAN	Cuts the corner between two lines at a distance
	ARRAY also: AR · in Spanish: ARREGLO	ARRAY [R rectangular · P polar]
	STRETCH also: ET, S · in Spanish: ESTIRAR	Stretches what you grab by crossing (right to left)
	MATCHPROP also: IG, MA · in Spanish: IGUALAR	Copies layer, color, lineweight and linetype from one entity to others
	UNIR also: J, UN, JOIN	Joins touching lines, arcs and polylines into a single polyline
	GRUPO also: G, AGRUPAR, GROUP	Groups the selection: picking one picks all (Ctrl+G)
	DESAGRUPAR also: DG, UNGROUP	Ungroups the selection (Ctrl+Shift+G)
	EXPLOTAR also: X, EXPLODE, DESCOMPONER	Breaks blocks, polylines, hatches, dimensions and foreign entities into their parts

Dimensions and annotations

Icon	Tool	What it does
	DIM also: CO_, DIMLIN · in Spanish: COTA	Linear dimension (horizontal or vertical depending on the points)
	COTAH	Forced horizontal dimension
	COTAV	Forced vertical dimension
	DIMALIGNED also: CAL, DAL · in Spanish: COTAALINEADA	Dimension parallel to the measured segment
	DIMCONTINUE also: CC, DCO · in Spanish: COTACONTINUA	Dimensions chained one after another
	DIMBASELINE also: CB, DBA · in Spanish: COTABASE	Dimensions from the same origin
	DIMANGULAR also: CAN, DAN · in Spanish: COTAANGULAR	Measures the angle between two directions
	DIMRADIUS also: CR, DRA · in Spanish: COTARADIO	Dimensions the radius of a circle or arc
	DIMDIAMETER also: CD, DDI · in Spanish: COTADIAMETRO	Dimensions the diameter of a circle
	LEADER also: DIR, LE · in Spanish: DIRECTRIZ	Arrow with a note at the end

Icon	Tool	What it does
	DIMSTYLE also: DIMESTILO, EC · in Spanish: ESTILOCOTA	Text height and arrow size of the dimensions

Blocks and images

Icon	Tool	What it does
	BLOCK also: BL, B_ · in Spanish: BLOQUE	Turns the selection into a block
	INSERT also: IN, I_ · in Spanish: INSERTAR	Inserts a block from the drawing or from the shop library
	WBLOCK also: GB · in Spanish: GUARDARBLOQUE	Saves a block from the drawing into the shop library
	LIBRARY also: BIB · in Spanish: BIBLIOTECA	Lists the blocks in the drawing and in the shop library
	PDFBACKGROUND also: PDFF, FONDO · in Spanish: PDFFONDO	Brings the lines of an architect's PDF to trace over
	IMAGEREF also: IMG, REFIMG · in Spanish: IMAGENREF	Puts a photo or a scan under the drawing, to trace

Sheets and printing

Icon	Tool	What it does
	LAYOUT also: HOJA, LAYOUT · in Spanish: PLANO	New sheet, or edits the open sheet, in a dialog
	ADDVIEWPORT also: AGREGARVENTANA, VH · in Spanish: VENTANAHOJA	Box a zone of the model and create a sheet whose viewport shows exactly that
	EDITVIEWPORT also: VENTANAS, VP · in Spanish: EDITARVENTANA	Toggles the sheet viewports' handles: corners and sides resize, the frame moves it, the inside pans the drawing
	NEWVIEWPORT also: NV, NUEVAVENTANA · in Spanish: VENTANANUEVA	Adds a viewport to the sheet: box it with two corners on the paper
	DELETEVIEWPORT also: BV · in Spanish: BORRARVENTANA	Removes a viewport from the sheet (click on it)
	EDITSHEET also: HOJACONF · in Spanish: EDITARHOJA	Dialog for the open sheet: size, scale and title block
	MODEL also: MO · in Spanish: MODELO	Goes back to model space
	VPSCALE also: EV, ESCALA · in Spanish: ESCALAVENTANA	Changes the scale of the sheet's viewport
	CENTER also: CENTRARVENTANA, CV · in Spanish: CENTRAR	Centers the drawing in the sheet viewport (Enter: whole drawing; click: that point to the center)
	IMPRIMIR also: PDF, PLOT	PRINT [ALL] — the open sheet, or all of them in a PDF
	PREVIEW also: PREVIA, PREVIEW · in Spanish: VISTAPREVIA	Shows how the sheet comes out on the chosen printer and paper

View

Icon	Tool	What it does
	ZOOM also: Z	ZOOM [E extents · V window · P previous · factor]
	REGEN also: RE, REDIBUJAR	Redraws the drawing at full quality and rebuilds the index (like AutoCAD's REGEN)
	REGENALL also: REGENALL, REA · in Spanish: REGENERAR	Asks the engine for the whole drawing again and redraws it
	GRID also: GRID, F7 · in Spanish: REJILLA	GRID [ON · OFF · step in mm]
	SNAP also: F9	SNAP [ON · OFF · step in mm] — snap the cursor to the grid
	ORTHO also: OR, F8	ORTHO [ON · OFF] — forces horizontal or vertical
	OSNAP also: REF, OSNAP, F3 · in Spanish: REFERENCIAS	OSNAP [ON · OFF · mode] — object snaps
	OSNAPSET also: REFCOEF, OSNAPCONF · in Spanish: MODOSREF	Dialog with the object snap modes
	DYN also: DIN · in Spanish: DINAMICA	DYN [ON · OFF] — dynamic input next to the cursor
	THEME in Spanish: TEMA	Switches between light and dark

Measure and inquire

Icon	Tool	What it does
	MEASURE also: MD, DIST, DI · in Spanish: MEDIR	Measures the distance between two points
	QUANTITIES also: TABLA, CONTAR · in Spanish: CANTIDADES	Counts how many times each block is inserted
	COMPARE also: DIFF · in Spanish: COMPARAR	Compares this drawing with another file and says what changed

File

Icon	Tool	What it does
	IMPORTART101X also: T101X, COCINA	Imports a Taller 101 kitchen and draws its plans and elevations

Settings and help

Icon	Tool	What it does
	HELP also: ?, H · in Spanish: AYUDA	Lists the commands
	GUIDE also: MANUAL, GUIDE, HERRAMIENTAS · in Spanish: GUIA	Opens the tool guide PDF: icon, name and what each tool does
	SETTINGS also: CONFIG, OPCIONES, AJUSTES, PREFERENCIAS · in Spanish: CONFIGURACION	Changes the interface language and the theme
	LANGUAGE also: LANG · in Spanish: IDIOMA	Changes the interface language: IDIOMA EN · IDIOMA ES
	UNITS also: UNITS, UN · in Spanish: UNIDADES	Change the drawing's working unit: mm, cm or m

Icon	Tool	What it does
	SHORTCUT also: ALIAS · in Spanish: ATAJO	ATAJO — make your own alias
	TOOLBAR also: BH · in Spanish: BARRA	TOOLBAR [left · right · top · bottom · floating]
	ODA also: INSTALARODA, ODAINSTALAR	Install or update the ODA File Converter (converts DWG faster and more faithfully)
	UPDATE also: UPDATE, ACTUALIZACIONES, UPDATES · in Spanish: ACTUALIZAR	Busca si hay una versión nueva de draw101 y la baja e instala
	NOTICES also: NOTICIAS, NEWS, NOTICES · in Spanish: AVISOS	Avisos de Taller 101 para quien usa draw101
	LICENSES also: LICENSES, TERCEROS, CREDITOS · in Spanish: LICENCIAS	Componentes de terceros que van dentro de draw101 y sus licencias
	ABOUT also: VER, ACERCADE · in Spanish: VERSION	Which version this is and what it brought
	DIAG also: DIAGNOSTICO	DIAG [ON · OFF] — anuncia en la consola cada cuadro o movimiento del ratón que tarde de más

Other

Icon	Tool	What it does
	ACTUALIZARMUEBLES also: ACT, REGENT101X	Re-reads the .t101x and rebuilds the cabinets without touching your annotations
	DRAFT also: DRAFT, BORR · in Spanish: BORRADOR	DRAFT [ON · OFF] — draft mode: 1 px lines, no linetypes, texts as boxes (lighter)
	DELETESHEET in Spanish: BORRARPLANO	Deletes the open sheet
	ZOOMEXTENTS also: ZE, EX · in Spanish: ENCUADRAR	Zooms to the whole drawing
	VPFIT also: EVE · in Spanish: ENCUADRARVENTANA	Re-centers the viewport on the whole drawing
	HOJASPORMUEBLE also: HPM, DESPIECE	One print sheet per imported cabinet
	IMAGE also: PNG · in Spanish: IMAGEN	Saves the sheet as PNG
	PRINT also: IMPRESORA, PLOTEAR · in Spanish: IMPRIMIRFISICO	Sends the sheet to a printer on this PC (Ctrl+P)
	PAN also: P	Pans the view (or drag with the middle or right button)
	REFEXT also: XREF	Brings another DXF as a locked background, and can reload it
	PERFORMANCE also: PERF, MEDIR · in Spanish: RENDIMIENTO	Measures how much painting and navigating cost on this machine, for diagnosis
	TITLEBLOCK also: PIE · in Spanish: ROTULO	Fills in the sheet's title block
	SUPERVISOR also: ENVIAR, PAQUETE	Leaves the PDF, the DXF and the manifest in a folder for SUPERVISOR