## Bladder pressure monitoring

- Pressure transducer set-up
  - o single line pressure transducer
  - o A-line manifold & pole
  - o A-line monitor cable
  - o 500ml NS bag
  - o pressure bag
- foley catheter
- 60ml luer-lock syringe
- Chlorhex pad
- clamp