Lab 7

Michael

Lab Section: 7F34

August 29, 2017

b. Answers to all pre-lab questions

1) If the NAD/DAD board were not available, nor any conventional desktop measuring tools (like a voltmeter), how could you verify that your DAC were functioning properly

ANS: One way to check is to use ADC(analog to digital converter) to verify. The DAC output would be sent to a ACD input, then using conversions and usart (LAB 5), the values can be outputted to a terminal.

2) You probably noticed that your sine wave does not look very good. While at least meeting specifications, how could you increase the quality of your sine wave?

ANS: To increase the quality of my sine wave, 2 things must be done. The first is that more data points would have to be used. The second thing is the timer would have to be decreased (the PER) in order to keep the desired Hz

- 3) How many DMA channels are available on the XMEGA?
 - ANS: CH0, CH1, CH2, and CH3 are available for a total of 4 DMA channels on the XMEGA.
- 4) How many different options are there to trigger the DMA?
 - **ANS:** There are 26 different options to trigger the DMA.
- 5) While you were not asked to implement this in your lab, explain how one might vary the amplitude of an output wave, much like the frequency was varied.

ANS: One might change the amplitude of the output wave by using a reference higher than the one currently used (not using AREFB). Then one would have to increase/add values in the sine table higher than 0xFFF.

c. Problems Encountered

Problems encounter was that in part D, the wave type would not switch if the output was set to 0. This was fixed by resetting the DMA every time it was switched

d. Future Work/Applications

Future application would be using the speaker. Instead of using data for a sine wave, the data can be for musical notes and the notes can be played from the speaker.

e. Schematics

N/A

g. Pseudocode/Flowcharts

Pseudocode for Lab7A.c:

```
MAIN:
    * Call Change_CLK_32HZ Function
    * Call DAC_INIT();
    * Output 1.3V
    WHILE(TRUE);
END
FUNCTION DAC_INIT
    * Set up port A
    * Set up DAC controls
FUNCTION UPDATE_DACA_CHO
    * Update DACA.CHO data
FUNCTION Change_CLK_32HZ
    * Enable the new oscillator
   WHILE(OSC FLAG not set){}
    * Write the IOREG signature to the CPU_CCP reg
    * Select the new clock source in the CLK_CTRL reg
```

Pseudocode for Lab7B.c:

```
MAIN:
    * Call Change_CLK_32HZ Function
    * Call DAC_INIT
    * Call COUNTER_INIT
    * Call COUNTER_START
    * Enable interrupts
    WHILE(TRUE);
END
FUNCTION COUNTER_INIT
    * Set top of counter
FUNCTION COUNTER_START
    * Set interupt for counter
    * Start COUNTER
ISR TCCO_OVF_vect
    * Preserve Status Reg
    * Change output
    IF(COUNTER equals 100){
        * Reset Counter
    * Clear interrupt flags
    * Restore Status Reg
FUNCTION DAC_INIT
    * Set up port A
    * Set up DAC controls
FUNCTION UPDATE_DACA_CHO
    * Update DACA.CHO data
FUNCTION Change_CLK_32HZ
    * Enable the new oscillator
    WHILE(OSC FLAG not set){}
    * Write the IOREG signature to the CPU_CCP reg
    * Select the new clock source in the CLK_CTRL reg
```

Pseudocode for Lab7C.c:

```
MAIN:
    * Call Change_CLK_32HZ Function
    * Call DAC_INIT
    * Call DMA_INIT
    * Call COUNTER_INIT
    * Call COUNTER_START
    * Enable interrupts
    WHILE(TRUE);
END
FUNCTION DMA_INIT
    * Enable DMA
    * Set up ADDRESS CONTROL
    * Set up TRIGGER SOURCE
    * Set up CH BLOCK TRANSFER COUNT
    * Set up DMA as CONTINOUS
   * Set up Source Address
    * Set up Destination Address
    * Set up CHO control
FUNCTION COUNTER_INIT
    * Set top of counter
FUNCTION COUNTER_START
    * Set interupt for counter
    * Start COUNTER
ISR TCCO_OVF_vect
    * Preserve Status Reg
    * Clear interrupt flags
    * Restore Status Reg
FUNCTION DAC_INIT
    * Set up port A
    * Set up DAC controls
FUNCTION UPDATE_DACA_CHO
    * Update DACA.CHO data
```

FUNCTION Change_CLK_32HZ

* Enable the new oscillator

WHILE(OSC FLAG not set){}

- * Write the IOREG signature to the CPU_CCP reg
- * Select the new clock source in the CLK_CTRL reg

Pseudocode for Lab7D.c:

```
MAIN:
    * Call Change_CLK_32HZ Function
    * Call DAC_INIT
    * Call DMA_INIT
    * Call COUNTER_INIT
    * Call COUNTER_START
    * Call USART_INIT
    * Enable interrupts
    WHILE(TRUE) {
        * Display Menu
        * Get User input
     SWITCH(user input){
         CASE 's' CASE 'S'
             * Change DMA with Sine data
         CASE 't' CASE 'T'
             * Change DMA with Triangle data
         CASE '0'
             * Turn off TCC0
             * Output Ov
         CASE '1'
             * Change Hz to 50*1
         CASE '2'
             * Change Hz to 50*2
         CASE '3'
             * Change Hz to 50*3
         CASE '4'
             * Change Hz to 50*4
         CASE '5'
             * Change Hz to 50*5
         CASE '6'
             * Change Hz to 50*6
         CASE '7'
             * Change Hz to 50*7
         CASE '8'
             * Change Hz to 50*8
         CASE '9'
             * Change Hz to 50*9
     }
     IF(choice is 1 - 9){
         * Call COUNTER_START()
     }
    }
END
```

```
FUNCTION DISPLAY_MENU
    * Make Menu Strings
    * Set up array of menu strings
   FOR(int i = 0; i < size; i++){</pre>
        * Display string
FUNCTION USART_INIT
    * Set port D for USART com
    * Set up Ctrl B and C
    * Set up baud rate
FUNCTION OUT_STRING
    While(char[] does not equal NULL){
        * Call OUT_CHAR
FUNCTION OUT_CHAR
    While(Transmitting){}
    * Return USART Data in a CHAR
FUNCTION IN_CHAR
    * WHILE(Recieving){}
    * Return data
FUNCTION DMA_INIT
    * Enable DMA
    * Set up ADDRESS CONTROL
    * Set up TRIGGER SOURCE
    * Set up CH BLOCK TRANSFER COUNT
    * Set up DMA as CONTINOUS
    IF(MODE is SINE){
        * Call SINE_SOURCE_DES
   ELSE IF(MODEis TRIANGLE){
       * Call TRIANGLE_SOURCE_DES
    * Set up CHO control
FUNCTION SINE_SOURCE_DES
    * Wait until CH is not busy
    * Set up address with Sine
    * Set up Source Address
    * Set up Destination Address
```

FUNCTION TRIANGLE_SOURCE_DES

- * Wait until CH is not busy
- * Set up address with Sine
- * Set up Source Address
- * Set up Destination Address

FUNCTION COUNTER_INIT

* Set top of counter

FUNCTION COUNTER_START

- * Set interupt for counter
- * Start COUNTER

ISR TCC0_OVF_vect

- * Preserve Status Reg
- * Clear interrupt flags
- * Restore Status Reg

FUNCTION DAC_INIT

- * Set up port A
- * Set up DAC controls

FUNCTION UPDATE_DACA_CHO

* Update DACA.CHO data

FUNCTION Change_CLK_32HZ

* Enable the new oscillator

WHILE(OSC FLAG not set){}

- * Write the IOREG signature to the CPU_CCP reg
- * Select the new clock source in the CLK_CTRL reg

h. Program Code

Code for Lab7A.c:

```
/*Lab 7 Part A
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Output 1.3V using DAC
Lab7A.c
Created: 7/25/2017 12:48:48 AM
#include <avr/io.h>
#include "constants.h"
#include "Clk_32MHz.h"
#include "DAC.h"
int main(void){
  //Set up program
  Change_CLK_32HZ();
  DAC_INIT();
  UPDATE_DACA_CHO(2130);
  //Run forever
   while(TRUE);
  //Return is 0 status
  return 0;
}
```

Code for Lab7B.c:

```
/*Lab 7 Part B
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Output SINE using DAC
Lab7B.c
Created: 7/25/2017 2:08:59 AM
#include <avr/io.h>
#include <avr/interrupt.h>
#include "constants.h"
#include "Clk_32MHz.h"
#include "DAC.h"
#include "TIMER_COUNTER.h"
int main(void){
  //Set up program
  Change_CLK_32HZ();
  DAC_INIT();
  COUNTER_INIT();
  COUNTER_START();
  //enable interrupts.
  PMIC\_CTRL = 0x07;
   sei();
  //Run forever
   while(TRUE);
  //Return is 0 status
  return 0;
}
```

Code for Lab7C.c:

```
/*Lab 7 Part C
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Output SINE using DAC and DMA
Lab7C.c
Created: 7/25/2017 3:51:09 AM
*/
#include <avr/io.h>
#include <avr/interrupt.h>
#include "constants.h"
#include "Clk_32MHz.h"
#include "DAC.h"
#include "TIMER_COUNTER.h"
#include "DMA.h"
int main(void){
  //Set up program
  Change_CLK_32HZ();
  DAC_INIT();
  DMA_INIT();
  COUNTER_INIT();
  COUNTER_START();
  //enable interrupts.
  PMIC\_CTRL = 0x07;
  sei();
  //Run forever
  while(TRUE);
  //Return is 0 status
  return 0;
}
```

Code for Lab7D.c

```
/*Lab 7 Part D
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Advance Waveform Generation
Lab7D.c
Created: 7/26/2017 2:57:37 AM
#include <avr/io.h>
#include <avr/interrupt.h>
#include "constants.h"
#include "Clk_32MHz.h"
#include "DAC.h"
#include "TIMER_COUNTER.h"
#include "DMA.h"
#include "USART.h"
//Function Prototypes
void DISPLAY_MENU(void);
int main(void){
  //Set up program
  Change_CLK_32HZ();
  DAC_INIT();
  DMA_INIT('s');
  COUNTER_INIT();
  COUNTER_START();
  USART_INIT();
  //enable interrupts.
  PMIC\_CTRL = 0x07;
  sei();
  //Set up vars
  char choice;
  //Run forever
  while(TRUE){
     //Display Menu, User input
     DISPLAY_MENU();
     choice = IN_CHAR();
     OUT_STRING("USER_CHOICE:_");
     OUT_CHAR(choice);
     OUT_STRING("\r\n");
     //Output based on choice
     switch(choice){
```

```
case 'S':
     case 's':
        DMA_CHANGE('s');
        break;
     case 'T':
     case 't':
        DMA_CHANGE('t');
        break;
     case '0':
        //Turn off TCCO, Output 0
        COUNTER_STOP();
        TCCO.PER = 0;
        DACA.CHODATA = 0;
        break;
     case '1':
        UPDATE_PER(1);
        break;
     case '2':
        UPDATE_PER(2);
        break;
     case '3':
        UPDATE_PER(3);
        break;
     case '4':
        UPDATE_PER(4);
        break;
     case '5':
        UPDATE_PER(5);
        break;
     case '6':
        UPDATE_PER(6);
        break;
     case '7':
        UPDATE_PER(7);
        break;
     case '8':
        UPDATE_PER(8);
        break;
     case '9':
        UPDATE_PER(9);
        break;
  }
  //Restart counter from when 0
  if(choice >= '1' && choice <= '9'){</pre>
        COUNTER_START();
  }
//Return is 0 status
return 0;
```

}

}

```
void DISPLAY_MENU(void){
   uint8_t menu_size = 12;
   //Menu String
   char *menuS = "S/s:__Output__a__sinusoid\r\n";
   char *menuT = "T/t:_Output_a_triangle_wave\r\n";
   char *menu0 = "0:\( \)Make\( \)the\( \)output\( \)waveform: 0\( \)Hz\( \)and\( \)0\( \)\( \)\( \)\( \)";
   char *menu1 = "1:_Make_the_output_waveform:50Hz_(1_x_50_Hz)\r\n";
   char *menu2 = "2: |Make| |the| |output| |waveform: 100Hz| |(2| |x| |50| |Hz) \r\n";
   char *menu3 = "3:\_Make\_the\_output\_waveform:150Hz\_(3\_x\_50\_Hz)\r\n";
   char *menu4 = "4:\( \text{Make}\) the\( \text{output}\) waveform: 100Hz\( \text{U}\) (4\( \text{X}\) 50\( \text{Hz}\) \r\n";
   char *menu5 = "5:_Make_the_output_waveform:250Hz_(5_x_50_Hz)\r\n";
   char *menu6 = "6:,|Make,|the,|output,|waveform:300Hz,|(6,|x,|50,|Hz)\r\n";
   \label{eq:char_menu7} \verb| = "7: | Make_ | the_ | output_ | waveform: 350 | Hz_ | (7_ | x_ | 50_ | Hz) \\ | r | ";
   char *menu8 = "8:_\Make_\the_output_\waveform:400Hz\(8\\\x\\\\50\\\Hz\)\r\n";
   char *menu9 = "9:\_Make\_the\_output\_waveform:450Hz\_(9\_x\_50\_Hz)\r\n";
   //Set up array of menu strings
   char *menu[] = {menuS, menuT, menu0, menu1, menu2, menu3, menu4,
      menu5, menu6, menu7, menu8, menu9};
   //Loop thru menu array to display
   for(uint8_t i = 0; i < menu_size; i++){</pre>
      OUT_STRING(menu[i]);
   }
   //return
   return;
}
```

i. Appendix




Figure 1: DAD reading of constant 1.3V signal




Figure 2: 300Hz sine wave




Figure 3: 300Hz sine wave (with DMA)




Figure 4: 50Hz sine wave




Figure 5: 350Hz triangle wave

Code for Clk_32MHz.h:

```
#ifndef CLK_32MHZ_H_
#define CLK_32MHZ_H_

/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Header for CLK_32MHz.c

Clk_32MHz.h
Created: 7/7/2017 11:20:13 PM
*/

//Function Prototype
void Change_CLK_32HZ(void);

#endif /* CLK_32MHZ_H_ */
```

Code for Clk_32MHz.c:

```
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Changes uP freq to 32Mhz
* Clk_32MHz.c
* Created: 7/17/2017 6:21:29 AM
#include <avr/io.h>
//include extern constants
extern const uint8_t NEW_CLOCK_FREQ;
/****************Function***********************
; Function Name: Change_CLK_32HZ
; Inputs: No direct input (from stack)
; Outputs: No direct outputs
*/
void Change_CLK_32HZ(void){
  //Set the clk config
  OSC_CTRL = NEW_CLOCK_FREQ;
  //Wait for the right flag to be set in the OSC_STATUS reg
  while((OSC_STATUS & PIN1_bm) != PIN1_bm);
  //Write the IOREG signature to the CPU_CCP reg
  CPU_CCP = CCP_IOREG_gc;
  //Select the new clock source in the CLK_CTRL reg
  CLK_CTRL = CLK_SCLKSEL_RC32M_gc;
  return;
}
```

Code for DAC.h:

```
#ifndef DAC_H_
#define DAC_H_

/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Header for DAC

DAC.h
Created: 7/25/2017 1:08:59 AM
*/

void DAC_INIT(void);
void UPDATE_DACA_CHO(uint16_t data);

#endif /* DAC_H_ */
```

Code for DAC.c:

```
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Functions for DAC
DAC.c
Created: 7/25/2017 1:08:39 AM
#include <avr/io.h>
//include extern constants
extern const uint8_t DAC_CTRLA_CONFIG;
extern const uint8_t DAC_CTRLC_CONFIG;
/****************Function***********************
; Function Name: DAC_INIT
; Inputs: No direct input
; Outputs: No direct outputs
*/
void DAC_INIT(void){
  //Set port A for output
  PORTA.DIRSET = PIN2_bm;//0x04
  //Set up DAC controls
  DACA.CTRLA = DAC_CTRLA_CONFIG;
  DACA.CTRLC = DAC_CTRLC_CONFIG;
}
/****************Function***********************
; Function Name: UPDATE_DACA_CHO
; Inputs: uint8_t:data
; Outputs: No direct outputs
*/
void UPDATE_DACA_CHO(uint16_t data){
  //Store data in CHO
  DACA.CHODATA = data;
  //Return from function
  return;
}
```

Code for DMA.h:

```
#ifndef DMA_H_
#define DMA_H_
/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Header for DMA

DMA.h
Created: 7/25/2017 3:54:42 AM
*/

//Function Prototypes
void DMA_INIT(uint8_t mode);
void SINE_SOURCE_DES(void);
void TRIANGLE_SOURCE_DES(void);
void DMA_CHANGE(uint8_t mode);
#endif /* DMA_H_ */
```

Code for DMA.c:

```
/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Functions for DMA
DMA.c
Created: 7/25/2017 3:53:36 AM
#include <avr/io.h>
//Include constants
extern uint16_t sine[];
extern uint16_t triangle[];
extern const uint8_t DMA_CTRL_CONFIG;
extern const uint8_t DMA_CHO_ADDRCTRL_CONFIG;
extern const uint8_t DMA_CHO_TRIGSRC_CONFIG;
extern const uint8_t DMA_CHO_TRFCNT_CONFIG;
extern const uint8_t DMA_CHO_REPCNT_CONFIG;
extern const uint8_t DMA_CHO_CTRLA_CONFIG;
//Function Prototype
void SINE_SOURCE_DES(void);
; Function Name: DMA_INIT
; Inputs: No inputs
; Outputs: No outputs
void DMA_INIT(uint8_t mode){
  //Enable DMA
  DMA.CTRL = DMA_CTRL_CONFIG;
  //ADDRESS CONTROL REG: BLOCK; INCREMENT; BURST; INCREMENT
  DMA.CHO.ADDRCTRL = DMA_CHO_ADDRCTRL_CONFIG;
  //TRIGGER SOURCE REG: TCCO
  DMA.CHO.TRIGSRC = DMA_CHO_TRIGSRC_CONFIG;
  //CH BLOCK TRANSFER COUNT: 200=100(8bit)*2(16bit)
  DMA.CHO.TRFCNT = DMA_CHO_TRFCNT_CONFIG;
  //CONTINOUS DMA
  DMA.CHO.REPCNT = DMA_CHO_REPCNT_CONFIG;
  if(mode == 's'){
     //Set up DMA with sine
     SINE_SOURCE_DES();
  }
```

```
else if(mode == 't'){
     //Set up DMA with sine
     TRIANGLE_SOURCE_DES();
  }
  //Set CHO CTRL: ENABLE; REPEAT; SINGLE; 2BYTE
  DMA.CHO.CTRLA = DMA_CHO_CTRLA_CONFIG;
  //Return from function
  return;
}
/*******************Function*************************
; Function Name: SINE_SOURCE_DES
; Inputs: No inputs
; Outputs: No outputs
void SINE_SOURCE_DES(void){
  //Wait until CH is not busy
  while((DMA.CHO.CTRLB & PIN7_bm) == PIN7_bm);
  //Set up address with Sine
  uint32_t SINE_ADDRESS = (uint32_t)sine;
  //Source Address
  DMA.CHO.SRCADDRO = (uint8_t)(SINE_ADDRESS >> 0);
  DMA.CHO.SRCADDR1 = (uint8_t)(SINE_ADDRESS >> 8);
  DMA.CHO.SRCADDR2 = (uint8_t)(SINE_ADDRESS >> 16);
  uint8_t* dac_ptr = &DACA_CHODATA;
  uint32_t dac_address = (uint32_t)dac_ptr;
  //Destination Address
  DMA.CHO.DESTADDRO = (uint8_t)(dac_address >> 0);
  DMA.CHO.DESTADDR1 = (uint8_t)(dac_address >> 8);
  DMA.CHO.DESTADDR2 = (uint8_t)(dac_address >> 16);
  //Return from function
  return;
}
/****************Function***********************
; Function Name: TRIANGLE_SOURCE_DES
; Inputs: No inputs
; Outputs: No outputs
*/
void TRIANGLE_SOURCE_DES(void){
  //Wait until CH is not busy
```

```
while((DMA.CHO.CTRLB & PIN7_bm) == PIN7_bm);
  //Set up address with Triangle
  uint32_t TRIANGLE_ADDRESS = (uint32_t)triangle;
  //Source Address
  DMA.CHO.SRCADDRO = (uint8_t)(TRIANGLE_ADDRESS >> 0);
  DMA.CHO.SRCADDR1 = (uint8_t)(TRIANGLE_ADDRESS >> 8);
  DMA.CHO.SRCADDR2 = (uint8_t)(TRIANGLE_ADDRESS >> 16);
  uint8_t* dac_ptr = &DACA_CHODATA;
  uint32_t dac_address = (uint32_t)dac_ptr;
  //Destination Address
  DMA.CHO.DESTADDRO = (uint8_t)(dac_address >> 0);
  DMA.CHO.DESTADDR1 = (uint8_t)(dac_address >> 8);
  DMA.CHO.DESTADDR2 = (uint8_t)(dac_address >> 16);
  //Return from function
  return;
}
void DMA_CHANGE(uint8_t mode){
  //Disable DMA
  DMA.CTRL = 0;
  //Software Reset on
  DMA.CTRL = 0b01000000;
  //Re initlize DMA with new wave mode
  DMA_INIT(mode);
}
```

Code for TIMER_COUNTER.h:

```
#ifndef TIMER_COUNTER_H_
#define TIMER_COUNTER_H_

/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Header for TIMER_COUNTER

TIMER_COUNTER.h
Created: 7/12/2017 6:09:50 AM
*/

void COUNTER_INIT(void);
void COUNTER_START(void);
void COUNTER_STOP(void);
void UPDATE_PER(uint8_t input);

#endif /* TIMER_COUNTER_H_ */
```

Code for TIMER_COUNTER.c:

```
/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Functions for TIMER_COUNTER
TIMER_COUNTER.c
Created: 7/25/2017 2:21:42 AM
#include <avr/io.h>
#include <avr/interrupt.h>
#include "DAC.h"
//Include extern constants
extern const uint16_t TC_PER_CONFIG;
extern const uint8_t INTCTRLA_CONFIG;
extern const uint8_t CLK_DIV_CONFIG;
/****************Function************************
; Function Name: COUNTER_INIT
; Inputs: Char c
; Outputs: No outputs
void COUNTER_INIT(void){
  // SET top of counter
  TCCO.PER = TC_PER_CONFIG;
  //Return from function
  return;
}
; Function Name: COUNTER_START
; Inputs: No inputs
; Outputs: No outputs
void COUNTER_START(void){
  //SET interupt for counter
  TCCO.INTCTRLA = INTCTRLA_CONFIG;
  //Start COUNTER
  TCCO_CTRLA = CLK_DIV_CONFIG;
  //Return from function
  return;
}
```

```
/*****************Function*************************
; Function Name: COUNTER_STOP
; Inputs: No inputs
; Outputs: No outputs
*/
void COUNTER_STOP(void){
  //STOP TIMER INTERRUPT
  TCCO.INTCTRLA = 0x00;
  //STOP TIMER
  TCCO.CTRLA = 0x00;
  //RESET TIMER
  TCCO_CTRLFCLR = TC_CMD_RESTART_gc;
  //Return from function
  return;
}
/*****************Function************************
; Function Name: COUNTER_STOP
; Inputs: uint8_t:input
; Outputs: No outputs
*/
void UPDATE_PER(uint8_t input){
  //Stop Timer
  COUNTER_STOP();
  //Update PER (Hz)
  TCCO.PER = (TC_PER_CONFIG/input);
  //Start Timer
  COUNTER_START();
  //Return from function
  return;
}
; ISR TYPE: TCCO_OVF_vect
; Inputs: NO inputs
; Outputs: No outputs
*/
ISR(TCCO_OVF_vect){
  //Preserve Status Reg
  uint8_t temp = CPU_SREG;
```

```
//Clear interrupt flags
TCCO.INTFLAGS = 0x01;

//Restore Status Reg
CPU_SREG = temp;

//Return from ISR
return;
```

Code for TIMER_COUNTER.c (Part B):

```
/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Functions for TIMER_COUNTER
TIMER_COUNTER.c
Created: 7/25/2017 2:21:42 AM
#include <avr/io.h>
#include <avr/interrupt.h>
#include "DAC.h"
//Include extern constants
extern const uint16_t TC_PER_CONFIG;
extern const uint8_t INTCTRLA_CONFIG;
extern const uint8_t CLK_DIV_CONFIG;
extern volatile uint16_t sine[];
//Global Varibles
volatile uint8_t counter = 0;
/*****************Function*************************
; Function Name: COUNTER_INIT
; Inputs: No direct input
; Outputs: No direct outputs
*/
void COUNTER_INIT(void){
  // SET top of counter
  TCCO.PER = TC_PER_CONFIG;
  return;
}
/*****************Function***********************
; Function Name: COUNTER_START
; Inputs: No direct input
; Outputs: No direct outputs
*/
void COUNTER_START(void){
  //SET interupt for counter
  TCCO.INTCTRLA = INTCTRLA_CONFIG;
  //Start COUNTER
  TCCO_CTRLA = CLK_DIV_CONFIG;
  //Return from function
```

```
return;
}
; ISR TYPE: TCCO_OVF_vect
; Inputs: No direct input
; Outputs: No direct outputs
ISR(TCCO_OVF_vect){
  //Preserve Status Reg
  uint8_t temp = CPU_SREG;
  //Change output
  UPDATE_DACA_CHO(sine[counter++]);
  //IF END OF SINE TABLE
  if(counter == 100){
    //Reset Counter
    counter = 0;
  }
  //Clear interrupt flags
  TCCO.INTFLAGS = 0x01;
  //Restore Status Reg
  CPU_SREG = temp;
  //Return from ISR
  return;
}
```

Code for USART.h:

```
#ifndef USART_H_
#define USART_H_

/*

USART.h
Created: 7/26/2017 4:37:25 AM
*/

//Function Prototypes
void USART_INIT(void);
void OUT_CHAR(char c);
void OUT_STRING(char* str);
char IN_CHAR(void);

#endif /* USART_H_ */
```

Code for USART.c:

```
/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Set up USART
USART.c
Created: 7/26/2017 4:34:28 AM
#include <avr/io.h>
extern const uint8_t pin_Tx;
extern const uint8_t pin_Rx;
extern const uint8_t TxRx_On;
extern const uint8_t usart_ctrl_C;
extern const uint8_t BSCALE;
extern const uint8_t upper_BSEL;
extern const uint8_t BSEL;
; Function Name: USART_INIT
; Inputs: No inputs
; Outputs: No outputs
*/
void USART_INIT(void){
  // Set port D for USART com
  PORTD.DIRSET = pin_Tx;
  PORTD.OUTSET = pin_Tx;
  PORTD.DIRCLR = pin_Rx;
  //Set up Ctrl B and C
  USARTDO_CTRLB = TxRx_On;
  USARTDO_CTRLC = usart_ctrl_C;
  //Set up baud rate
  USARTDO.BAUDCTRLA = BSEL;
  USARTDO.BAUDCTRLB = (BSCALE | upper_BSEL);
  return;
}
; Function Name: OUT_CHAR
; Inputs: Char c
; Outputs: No outputs
```

```
*/
void OUT_CHAR(char c){
  // Wait until prev receive done
  while((USARTDO.STATUS & PIN5_bm) == 0);
  //Output char thru USART
  USARTDO.DATA = c;
  return;
}
/****************Function***********************
; Function Name: OUT_STRING
; Inputs: Char pointer c
; Outputs: No outputs
void OUT_STRING(char* str){
  //While char is not null
  while(*str){
     //Output char
     OUT_CHAR(*str++);
  }
  return;
}
/******************Function**************************
; Function Name: IN_CHAR
; Inputs: Char c
; Outputs: No outputs
char IN_CHAR(void){
  while((USARTDO.STATUS & PIN7_bm) == 0);
  return USARTDO_DATA;
}
```

Code for constants.h:

```
#ifndef CONSTANTS_H_
#define CONSTANTS_H_
/*
Name: Michael Arboleda
Section #: 7F34
TA Name: Wesley Piard
Description: Changes uP freq to 32Mhz
constants.h
Created: 7/7/2017 11:53:20 PM
*/
#include <avr/io.h>
//OVERALL DEFS
#define TRUE 1
#define FALSE 0
#define NULL 0
const uint8_t NEW_CLOCK_FREQ = 0b00000010;
//*********** DAC.c ***************************
const uint8_t DAC_CTRLA_CONFIG = 0b00000101;//0x05
const uint8_t DAC_CTRLC_CONFIG = 0b00011000;//0x18
//************* TIMER_COUNTER.c **********************
const uint16_t TC_PER_CONFIG = 822;//50hz
const uint8_t INTCTRLA_CONFIG = 0b00000011;//0x03
const uint8_t CLK_DIV_CONFIG = 0b00000100;//0x04
//************** DMA.c *******************************
const uint8_t DMA_CTRL_CONFIG = 0b10000000;//0x80
const uint8_t DMA_CHO_ADDRCTRL_CONFIG = Ob01011001 ://0x59
const uint8_t DMA_CHO_TRIGSRC_CONFIG = 0b01000000;//0x40
const uint8_t DMA_CHO_TRFCNT_CONFIG = 200;
const uint8_t DMA_CHO_REPCNT_CONFIG = 0x00;
const uint8_t DMA_CHO_CTRLA_CONFIG = Ob10100101;//0xA5
const uint8_t pin_Tx = PIN3_bm;
const uint8_t pin_Rx = PIN2_bm;
const uint8_t TxRx_On = 0b00011000; // 0x18
// asynch, 8 databits, no parity, 1 start, and 1 stop
const uint8_t usart_ctrl_C = 0b00000011;
// BSEL 28,800
const uint8_t upper_BSEL = 0b00001000;
```

```
const uint8_t BSEL = 0b10001110;
const uint8_t BSCALE = Ob10110000; // -5 BSCALE
// SINEWAVE FROM http://www.daycounter.com/Calculators/Sine-GeneratorCalculator.phtml
// PARAMETERS: 100 POINTS, AMPLITUDE FFF (4096)
uint16_t sine[] = \{0x800,0x881,0x901,0x980,0x9fd,0xa79,0xaf2,0xb68,0xbdb,0xc49,
  0xcb4,0xd19,0xd7a,0xdd5,0xe2a,0xe79,0xec1,0xf03,0xf3d,0xf70,
  Oxf9c,Oxfc0,Oxfdc,Oxff0,Oxffc,Oxfff,Oxffc,Oxff0,Oxfdc,Oxfc0,
  0xf9c,0xf70,0xf3d,0xf03,0xec1,0xe79,0xe2a,0xdd5,0xd7a,0xd19,
  0xcb4,0xc49,0xbdb,0xb68,0xaf2,0xa79,0x9fd,0x980,0x901,0x881,
  0x800,0x77f,0x6ff,0x680,0x603,0x587,0x50e,0x498,0x425,0x3b7,
  0x34c,0x2e7,0x286,0x22b,0x1d6,0x187,0x13f,0xfd,0xc3,0x90,
  0x64,0x40,0x24,0x10,0x4,0x0,0x4,0x10,0x24,0x40,
  0x64,0x90,0xc3,0xfd,0x13f,0x187,0x1d6,0x22b,0x286,0x2e7,
0x34c,0x3b7,0x425,0x498,0x50e,0x587,0x603,0x680,0x6ff,0x77F;
//TRIANGLE WAVE FROM http://www.daycounter.com/Calculators/Triangle-WaveGenerator
//-Calculator.phtml
//PARAMETERS: 100 POINTS, AMPLITUDE FFF(4096)
uint16_t triangle[] = \{0x52,0xa4,0xf6,0x148,0x19a,0x1ec,0x23d,0x28f,0x2e1,0x333,
  0x385,0x3d7,0x429,0x47b,0x4cd,0x51f,0x571,0x5c3,0x614,0x666,
  0x6b8,0x70a,0x75c,0x7ae,0x800,0x852,0x8a4,0x8f6,0x948,0x99a,
  0x9ec,0xa3d,0xa8f,0xae1,0xb33,0xb85,0xbd7,0xc29,0xc7b,0xccd,
  0xd1f,0xd71,0xdc3,0xe14,0xe66,0xeb8,0xf0a,0xf5c,0xfae,0xfff,
  Oxfae, 0xf5c, 0xf0a, 0xeb8, 0xe66, 0xe14, 0xdc3, 0xd71, 0xd1f, 0xccd,
  0xc7b,0xc29,0xbd7,0xb85,0xb33,0xae1,0xa8f,0xa3d,0x9ec,0x99a,
  0x948,0x8f6,0x8a4,0x852,0x800,0x7ae,0x75c,0x70a,0x6b8,0x666,
  0x614,0x5c3,0x571,0x51f,0x4cd,0x47b,0x429,0x3d7,0x385,0x333,
0x2e1,0x28f,0x23d,0x1ec,0x19a,0x148,0xf6,0xa4,0x52,0x0;
#endif /* CONSTANTS_H_ */
```