

TABLE OF CONTENTS

1- ALIGNMENT PROCEDURE2
REVISION HISTORY3

1- ALIGNMENT PROCEDURE

1. Remove the cradle from both tables.
2. Center the dock assembly with the bridge, at the front of the magnet. Loosely attach the dock assembly to the front of the magnet. Do **not** secure the dock to the magnet floor.



dock contains highly ferrous material. loosen, but do NOT remove, dock mounting bolts.

3. Adjust both front casters of Table 1 so that the top of the casting above the wheel is 11.0 inches (479.4 mm) from the floor.
4. Position Table 1 to the dock, taking care not to move the dock. Do **not** actuate the docking pedal.
5. With Table 1 fully elevated, place a level perpendicular across the table at the end of the table closest to the magnet. Level the table by adjusting the two front casters. Raise and lower the casters as needed while keeping the center (between the two casters) close to the 11-inch (479.4-mm) height.

Note

The casters should never be adjusted more than ± 0.25 inches (6.35 mm) from the 11-inch (479.4-mm) height.

6. Move the table and dock left or right until the table rail and the bridge rail are in alignment.
7. Place a mark or piece of tape on the floor adjacent to the side of the dock.
8. Repeat Steps 3 through 7 for Table 2.
9. Mark the centerpoint between the two marks. Shift the dock assembly to align with the centerpoint mark.
10. Secure the dock assembly in position.
11. Complete the final lateral alignment by adjusting the two front casters. Raise and lower the casters as needed while keeping the center (between the two casters) close to the 11-inch (479.4-mm) height.

Note

The casters should not be adjusted more than ± 0.25 inches (6.35 mm).

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASON FOR CHANGE
0	Jan. 21, 2003	C. MacDonald	Initial version.
1	Sept. 30, 2010	R. Kohl	Per CAPA 1859392: Added Warning and additional text to Section 1, Step 2.