



GE Medical Systems

gemedical.com

Technical Publication

Direction 2353645-100

Revision 0

Mate-N-Lok Cross Reference

*Copyright © 2002, by General Electric Company, Inc.
All rights reserved.*



Page Left Intentionally Blank

LEGAL NOTES

TRADEMARKS

All products and their name brands are trademarks of their respective holders.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GEMS CQA Process to report all omissions, errors, and defects in this publication.

COPYRIGHTS

All Material, Copyright (c) 2002 by General Electric Company, Inc. All rights reserved.

IMPORTANT PRECAUTIONS

LANGUAGE

WARNING

- This Service Manual is available in English only.
- If a customer's service provider requires a language other than English, it is the customer's responsibility to provide translation services.
- Do not attempt to service the equipment unless this service manual has been consulted and is understood.
- Failure to heed this Warning may result in injury to the service provider, operator or patient from electric shock, mechanical or other hazards.

AVERTISSEMENT

- Ce Manuel de maintenance n'est disponible qu'en anglais.
- Si le technicien du client a besoin de ce manuel dans une autre langue que l'anglais, c'est au client qu'il incombe de le faire traduire.
- Ne pas tenter d'intervention sur les équipements tant que le manuel Service n'a pas été consulté et compris.
- Le non-respect de cet avertissement peut entraîner chez le technicien, l'opérateur ou le patient des blessures dues à des dangers électriques, mécaniques ou autres.

WARNUNG

- Dieses Kundendienst-Handbuch existiert nur in englischer Sprache.
- Falls ein fremder Kundendienst eine andere Sprache benötigt, ist es Aufgabe des Kunden für eine entsprechende Übersetzung zu sorgen.
- Versuchen Sie nicht, das Gerät zu reparieren, bevor dieses Kundendienst-Handbuch nicht zu Rate gezogen und verstanden wurde.
- Wird diese Warnung nicht beachtet, so kann es zu Verletzungen des Kundendiensttechnikers, des Bedieners oder des Patienten durch elektrische Schläge, mechanische oder sonstige Gefahren kommen.

AVISO

- Este Manual de Servicio sólo existe en inglés.
- Si algún proveedor de servicios ajeno a GEMS solicita un idioma que no sea el inglés, es responsabilidad del cliente ofrecer un servicio de traducción.
- No se deberá dar servicio técnico al equipo, sin haber consultado y comprendido este manual de servicio.
- La no observancia del presente aviso puede dar lugar a que el proveedor de servicios, el operador o el paciente sufran lesiones provocadas por causas eléctricas, mecánicas o de otra naturaleza.

LANGUAGE

ATENÇÃO

- Este Manual de Assistência Técnica só se encontra disponível em Inglês.
- Se qualquer outro serviço de assistência técnica, que não a GEMS, solicitar estes manuais noutro idioma, é da responsabilidade do cliente fornecer os serviços de tradução.
- Não tente reparar o equipamento sem ter consultado e compreendido este Manual de Assistência Técnica.
- O não cumprimento deste aviso pode por em perigo a segurança do técnico, operador ou paciente devido a' choques elétricos, mecânicos ou outros.

AVVERTENZA

- Il presente manuale di manutenzione è disponibile soltanto in inglese.
- Se un addetto alla manutenzione esterno alla GEMS richiede il manuale in una lingua diversa, il cliente è tenuto a provvedere direttamente alla traduzione.
- Si proceda alla manutenzione dell'apparecchiatura solo dopo aver consultato il presente manuale ed averne compreso il contenuto.
- Non tenere conto della presente avvertenza potrebbe far compiere operazioni da cui derivino lesioni all'addetto alla manutenzione, all'utilizzatore ed al paziente per folgorazione elettrica, per urti meccanici od altri rischi.

警告

このマニュアルは、英語でのみ提供されています。他の言語に翻訳されたマニュアルは、GEMS によって承認されたものではありません。このマニュアルは、英語でのみ提供されています。他の言語に翻訳されたマニュアルは、GEMS によって承認されたものではありません。このマニュアルは、英語でのみ提供されています。他の言語に翻訳されたマニュアルは、GEMS によって承認されたものではありません。

注意:

・ 本文英語版のみに従ってください。他の言語版は、参考としてのみ提供されています。
・ 翻訳されたマニュアルは、GEMS によって承認されたものではありません。
・ 本文英語版のみに従ってください。他の言語版は、参考としてのみ提供されています。
・ 本文英語版のみに従ってください。他の言語版は、参考としてのみ提供されています。

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent write "Damage In Shipment" on ALL copies of the freight or express bill BEFORE delivery is accepted or "signed for" by a GE representative or hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

Call Traffic and Transportation, Milwaukee, WI (414) 785 5052 or 8*323 5052 immediately after damage is found. At this time be ready to supply name of carrier, delivery date, consignee name, freight or express bill number, item damaged and extent of damage. Complete instructions regarding claim procedure are found in Section S of the Policy And Procedures Bulletins. 14 July 1993

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Medical personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Medical Systems Group, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Medical Systems Group, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment. Various protective materials and devices are available. It is urged that such materials or devices be used.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives. GE personnel, please use the GEMS CQA Process to report all omissions, errors, and defects in this publication.

REVISION HISTORY

REVISION HISTORY

Revision	Date	Reason for change
0	08/09/02	Initial Release

TABLE OF CONTENTS

Legal Notes	3
TRADEMARKS.....	3
OMISSIONS & ERRORS.....	3
COPYRIGHTS.....	3
Important Precautions.....	4
LANGUAGE.....	4
LANGUAGE.....	5
Revision History	7
Table of Contents.....	8
Identification of Connectors and Pins	9
INTRODUCTION.....	9
SECTION 1 – LIGHTSPEED QXI.....	10
SECTION 2 – LIGHTSPEED PLUS.....	12
SECTION 3 – LIGHTSPEED ULTRA.....	14
SECTION 4 – GANTRY WITH REFURBISHES DETECTOR.....	16
SECTION 5 – HSA GANTRY WITH GEMS LAN.....	18
SECTION 6 – VX PREFERRED.....	20
SECTION 7 – EMC GANTRY WITH RPIGP.....	22
SECTION 8 – FAST RHAP EMC GANTRY - RIM COVERS.....	24
SECTION 9 – FAST RHAP NON-EMC GANTRY - RIM COVERS	26
SECTION 10 – MALE-FEMALE CROSS REFERENCE	28

IDENTIFICATION OF CONNECTORS AND PINS

INTRODUCTION

This document serves to quickly identify the association of Mate-N-Lok connectors and pins, harnesses, and the LightSpeed product. The following pages show the Mate-N-Lok connectors and pins used on the LightSpeed product. Each row of information contains GE part number for a harness, AMP number for a connector or pin, a description, and the location in the gantry.

Listed below are the column headers with an explanation of the information:

Harness Part No.

This is the GE part number for a harness

Mate-N-Lok Part No.

This is the AMP Part No. for a connector or pin

Qty

This is the amount of connector or pin needed for a harness

Description/Comment

This is AMP description for a connector or pin

Connector Location

This is location of a connector or pin as found on GPCP

SECTION 1 – LIGHTSPEED QXI

The part number for the gantry is 2180482

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
2180562	AMP #350777-1	2	Mate-N-Lok 2 Position in Line Plug 94-VO	H1 Gantry
	AMP #166500-2	4	Terminal - Mate-N-Lok Crimp-Snap Gold 22 AWG	
	AMP #1-480700-0	1	Mate-N-Lok 3 Position in Line Plug 94-V2	
	AMP #172341-1	1	Mini Mate-N-Lok 12 Position Matrix Plug 94-V2	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #172338-1	3	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #166500-2	12	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350715-1	2	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #640585-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	
	AMP #350787-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	
	AMP #166500-2	19	Terminal - Mate-N-Lok Crimp-Snap Gold 22 AWG	
2180564	AMP #172157-1	1	Mini Mate-N-Lok 15 Position in Line Cap 94-VO	H1 Gantry
	AMP #770987-3	15	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2219102	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry;Top Cover Assy
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-V2	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172336-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-V2	
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172328-1	2	Mini Mate-N-Lok 2 Position in Line Plug 94-V2	
	AMP #770987-3	4	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350778-1	2	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #46-296214	2	Mini Mate-N-Lok 3 Position in Line Plug 94-V2	
	AMP #770988-3	4	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
46 297786	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	Gantry; Rear Cover Assy; Harness, Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2198749	AMP #350778-1	1	Mate-N-Lok 3 Position in Line Cap 94-V2	Gantry; OBC Assy
	AMP #350218-3	3	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2180569	AMP #640581-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	Gantry; HEMRC
	AMP #350550-7	6	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 3 Position in Line Cap 94-V2	
	AMP #350218-3	3	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350778-1	2	Mate-N-Lok 2 Position in Line Cap 94-V2	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-V2	
	AMP #350851-7	4	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2207332	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	H1 Gantry
	AMP #350550-7	3	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 3 Position in Line Cap 94-V2	
	AMP #350218-3	3	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-297100	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-VO	Gantry; Tilt Assy; Pot Harness
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2184185	AMP #350777-1	1	Mate-N-Lok 8 Position in Line Plug 94-V2	Gantry; Mod Lightspeed HEMRC; HEMRC Assy
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2118222	AMP #350777-1	1	Mate-N-Lok 8 Position in Line Plug 94-V2	EMC Table Assy; EMC Table Frame
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350778-1	2	Mate-N-Lok 3 Position in Line Cap 94-V2	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350781-1	1	Mate-N-Lok 15 Position Matrix Cap 94-V2	
	AMP #350851-7	11	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
	AMP #350809-1	1	Mate-N-Lok 5 Position in Line Plug 94-V2	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
	AMP #350777-1	2	Mate-N-Lok 2 Position in Line Plug 94-V2	
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350766-1	3	Mate-N-Lok 3 Position in Line Plug 94-V2	
	AMP #350550-7	6	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-V2	
	AMP #350550-7	9	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2118221	AMP #350809-1	1	Mate-N-Lok 5 Position in Line Plug 94-V2	EMC Table AssyEMC Table Frame
	AMP #350550-7	5	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
	AMP #350777-1	2	Mate-N-Lok 2 Position in Line Plug 94-V2	
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350715-1	1	Mate-N-Lok 6 Position Matrix Plug 94-V2	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-V2	
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350766-1	3	Mate-N-Lok 3 Position in Line Plug 94-V2	
	AMP #350550-7	6	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172161-1	3	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #66506-3	20	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172157-1	3	Mini Mate-N-Lok 2 Position in Line Cap 94-V2	
	AMP #770987-3	6	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172159-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	
	AMP #66506-3	4	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2118220	AMP #172330-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	EMC Gantry for HP; EMC Gantry Base Assy
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
46-297036	AMP #172167-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	Gantry Base Assy; Tilt Pot Harness
	AMP #770988-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	

Table 1 'LightSpeed QX/i' Mate-N-Lok Cross Reference

SECTION 2 – LIGHTSPEED PLUS

The part number for the gantry is 2260619

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
2240778	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Anode Inverter Harness
	AMP #350715-1	1	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2262946	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Anode Inverter Harness
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2243911	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350715-1	1	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #350851-7	6	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2239406	AMP #640581-1	1	Mate-N-Lok 6 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350550-7	6	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262940	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262942	AMP #350766-1	2	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262947	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2302145	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #172167-1	7	Mini Mate-N-Lok 4 Position Matrix Plug 94-VO	
	AMP #350550-7	8	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
	AMP #770988-3	14	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2245405	AMP #172167-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #770988-3	8	Terminal Mini Mate-N-Lok Socket Gold #18-22 AWG	
2265682	AMP #350720-1	2	Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Stationary Base
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350851-7	2	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2263291	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	Pwr Supply 5VDC ASM, F-Case
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2303589	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-VO	Gantry; Tilting Frame
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2303601	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-VO	Gantry
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	

Harness Part No.	Mate-N-	Qty	Description/Comment	Connector Location
2263289	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	ASM CC Case
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2263290	AMP #350787-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	Gantry; Tilting Frame; Rotating Base; DAS Pwr Supply R-Side; Pwr Supply 12VDC ASM, E-Case
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2268223	AMP #172169-1	1	Mini Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Tilt Pot; Harness, Tilt Switch
	AMP #770902-3	8	Terminal - Mini Mate-N-Lok Socket Gold #22-26 AWG	
2262943	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2262945	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350550-7	3	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262938	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350550-7	3	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262948	AMP #350809-1	1	Mate-N-Lok 5 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2240818	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350851-7	14	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2268222	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-VO	Gantry; Stationary Base
	AMP #172159-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-VO	
	AMP #66506-3	11	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	

Table 2 'LightSpeed Plus' Mate-N-Lok Cross Reference

SECTION 3 – LIGHTSPEED ULTRA

The part number for the gantry is 2281177

Harness Part No.	Mate-N-	Qty	Description/Comment	Connector Location
2240778	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Anode Inverter Harness
	AMP #350715-1	1	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2262946	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Anode Inverter Harness
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2243911	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350715-1	1	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #350851-7	6	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2239406	AMP #640581-1	1	Mate-N-Lok 6 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350550-7	6	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262940	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262942	AMP #350766-1	2	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262947	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2302145	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #172167-1	7	Mini Mate-N-Lok 4 Position Matrix Plug 94-VO	
	AMP #350550-7	8	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
	AMP #770988-3	14	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2245405	AMP #172167-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Cathode Inv/OBC Harness/Brkt ASM
	AMP #770988-3	8	Terminal Mini Mate-N-Lok Socket Gold #18-22 AWG	
2265682	AMP #350720-1	2	Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Stationary Base
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350851-7	2	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2263291	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	Gantry; Tilting; Rotating Base; DAS Pwr Supply; Pwr Supply 5VDC ASM, F-Case
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2303589	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-VO	Gantry; Tilting Frame
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2303601	AMP #172157-1	1	Mini Mate-N-Lok 2 Position in Line Cap 94-VO	Gantry
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #770987-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
2293763	AMP #350777-1	6	Mate-N-Lok 2 Position in Line Plug 94-VO	Harness, DAS Fuse/Power Supply; DHCB/Fuse Box Assy; H3 Rotating Base; Tilting Frame
	AMP #350536-3	12	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2263290	AMP #350787-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	Gantry; Tilting Frame; Rotating Base; DAS Pwr Supply R-Side; Pwr Supply 12VDC ASM, E-Case
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2268223	AMP #172169-1	1	Mini Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Tilt Pot; Harness, Tilt Switch
	AMP #770902-3	8	Terminal - Mini Mate-N-Lok Socket Gold #22-26 AWG	
2262943	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2262945	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350550-7	3	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262938	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350550-7	3	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2262948	AMP #350809-1	1	Mate-N-Lok 5 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350550-7	4	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2240818	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	Gantry; Tilting Frame; Rotating Base; OBC Assy
	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350851-7	14	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
2268222	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-VO	Gantry; Stationary Base
	AMP #172159-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-VO	
	AMP #66506-3	11	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2288184	AMP #350781-1	1	Mate-N-Lok 6 Position Matrix Cap 94-VO	Gantry; Tilting Frame; Rotating Base; Fuse Box Assy; Harness, Fusebox/OBC/DAS/RF/F0/DHCB
	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	
	AMP #350783-1	1	Mate-N-Lok 12 Position Matrix Cap 94-VO	
	AMP #350851-7	13	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	
	AMP #350536-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
2291845	AMP #350766-1	4	Mate-N-Lok 3 Position in Line Plug 94-VO	Gantry; Tilting Frame; Rotating Base; Fuse Box MDAS
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	

Table 3 'LightSpeed Ultra' Mate-N-Lok Cross Reference

SECTION 4 – GANTRY WITH REFURBISHES DETECTOR

The part number for the gantry is 46-296000G2

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
46-297100G1	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	GWRD; Zeus Gantry; Tilt Pot Harness Assy; Pot Harness
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2125039	AMP #350788-1	1	Mate-N-Lok 2 Position in Line Cap 94-V0	GWRD; Axial Motor Assy; Axial Drive Motor w/EMC Filter Plug; Axial Harness
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2100664	AMP #350715-1	4	Mate-N-Lok 6 Position Matrix Plug 94-V0	GWRD; Gantry Rotating Harness
	AMP #350536-3	14	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172166-1	1	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172341-1	2	Mini Mate-N-Lok 12 Position Matrix Plug 94-V2	
	AMP #166500-2	16	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350779-1	4	Mate-N-Lok 4 Position in Line Plug 94-V0	
	AMP #350536-3	12	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-V0	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-V0	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172167-1	4	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #770988-3	16	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-V0	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-V0	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-296748	AMP #172166-1	2	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	GWRD
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172160-1	2	Mini Mate-N-Lok 6 Position Matrix Cap 94-V2	
	AMP #66506-3	11	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172163-1	2	Mini Mate-N-Lok 15 Position Matrix Cap 94-V2	
	AMP #66506-3	22	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-V0	
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #172170-1	1	Mini Mate-N-Lok 12 Position Matrix Plug 94-V0	
	AMP #770988-3	11	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-V0	
	AMP #770988-3	14	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-V0	

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	
	AMP #350536-3	9	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172168-1	1	Mini Mate-N-Lok 6 Position Matrix Plug 94-V2	
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	
	AMP #66506-3	10	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #66506-3	8	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350783-1	1	Mate-N-Lok 12 Position Matrix Cap 94-VO	
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2100647	AMP #172158-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V0	GWRD; Control Assy; Gantry Harness
	AMP #170364-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	
	AMP #66506-3	7	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
46-296942	AMP #350766-1	4	Mate-N-Lok 3 Position in Line Plug 94-VO	GWRD
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-296943	AMP #350766-1	8	Mate-N-Lok 3 Position in Line Plug 94-VO	GWRD
	AMP #350536-3	16	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-297353	AMP #172168-1	1	Mini Mate-N-Lok 6 Position Matrix Plug 94-V2	GWRD; Top Cover Assy; Top Cover Fans AC Power Cable
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350766-1	4	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172166-1	2	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	
	AMP #770988-3	5	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
46-297786	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	GWRD; Rear Gantry Cover Assy; Harness, Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	

Table 4 'Gantry with Refurbishes Detector' Mate-N-Lok Cross Reference

SECTION 5 – HSA GANTRY WITH GEMS LAN

The part number for the gantry is 46-296000G5

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
46-297353	AMP #172168-1 AMP #770988-3 AMP #350766-1 AMP #350536-3 AMP #350777-1 AMP #350550-7 AMP #172166-1 AMP #770988-3	1 6 4 8 1 2 2 5	Mini Mate-N-Lok 6 Position Matrix Plug 94-V2 Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG Mate-N-Lok 3 Position in Line Plug 94-VO Terminal - Mate-N-Lok Socket Tin #14-20 AWG Mate-N-Lok 2 Position in Line Plug 94-VO Terminal - Mate-N-Lok Socket Gold #14-20 AWG Mini Mate-N-Lok 3 Position in Line Plug 94-V0 Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	HAS Gantry; Top Cover Assy; Top Cover Fans AC Power Cable
46-297786	AMP #172157-1 AMP #770987-3	1 3	Mini Mate-N-Lok 3 Position in Line Cap 94-V2 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	HSA; Rear Gantry Cover Assy; Harness, Microphone
46-297716	AMP #172171-1 AMP #170366-3 AMP #172161-1 AMP #170364-3	1 13 1 3	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO Terminal - Mini Mate-N-Lok Socket Brass #18-22 AWG Mini Mate-N-Lok 9 Position Matrix Cap 94-V2 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	HSA; Front Gantry Cover Assy; Display/Intercom Cable
46-327069	AMP #172166-1 AMP #770988-3 AMP #172160-1 AMP #66506-3 AMP #172163-1 AMP #66506-3 AMP #350778-1 AMP #350218-3 AMP #172170-1 AMP #770988-3 AMP #172171-1 AMP #770988-3 AMP #172165-1 AMP #770988-3 AMP #350720-1 AMP #350536-3 AMP #172168-1 AMP #770988-3 AMP #172162-1 AMP #66506-3 AMP #172161-1 AMP #66506-3 AMP #350783-1 AMP #350536-3	2 6 2 11 2 22 1 2 1 11 1 14 1 2 1 9 1 6 1 10 1 8 1 8	Mini Mate-N-Lok 3 Position in Line Plug 94-V0 Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG Mini Mate-N-Lok 6 Position Matrix Cap 94-V2 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG Mini Mate-N-Lok 15 Position Matrix Cap 94-V2 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG Mate-N-Lok 2 Position in Line Cap 94-VO Terminal - Mate-N-Lok Pin Tin #14-20 AWG Mini Mate-N-Lok 12 Position Matrix Plug 94-VO Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG Mini Mate-N-Lok 15 Position Matrix Plug 94-VO Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG Mini Mate-N-Lok 2 Position in Line Plug 94-VO Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG Mate-N-Lok 9 Position Matrix Plug 94-VO Terminal - Mate-N-Lok Socket Tin #14-20 AWG Mini Mate-N-Lok 6 Position Matrix Plug 94-V2 Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG Mini Mate-N-Lok 12 Position Matrix Cap 94-V2 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG Mini Mate-N-Lok 9 Position Matrix Cap 94-V2 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG Mate-N-Lok 12 Position Matrix Cap 94-VO Terminal - Mate-N-Lok Socket Tin #14-20 AWG	HSA; RP System w/ GEMS LAN Card
46-297092	AMP #350766-1 AMP #350536-3 AMP #350767-1 AMP #350218-3	1 2 1 3	Mate-N-Lok 3 Position in Line Plug 94-VO Terminal - Mate-N-Lok Socket Tin #14-20 AWG Mate-N-Lok 3 Position in Line Cap 94-VO Terminal - Mate-N-Lok Pin Tin #14-20 AWG	HSA; RP System w/ GEMS LAN Card
46-297371	AMP #172158-1 AMP #170364-3	1 3	Mini Mate-N-Lok 3 Position in Line Cap 94-V0 Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	HSA; RP System w/ GEMS LAN Card; Zeus Gantry
2100664	AMP #350715-1 AMP #350536-3	4 14	Mate-N-Lok 6 Position Matrix Plug 94-V0 Terminal - Mate-N-Lok Socket Tin #14-20 AWG	HSA; RP System w/ GEMS LAN Card; Gantry Rotating Harness

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #172166-1	1	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172341-1	2	Mini Mate-N-Lok 12 Position Matrix Plug 94-V2	
	AMP #166500-2	16	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350779-1	4	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350536-3	12	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172167-1	4	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #770988-3	16	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2100647	AMP #172158-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V0	HSA; RP System w/ GEMS LAN Card; Control Assy; Gantry Harness
	AMP #170364-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	
	AMP #66506-3	7	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
46-296942	AMP #350766-1	4	Mate-N-Lok 3 Position in Line Plug 94-VO	HSA; RP System w/ GEMS LAN Card
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-296943	AMP #350766-1	8	Mate-N-Lok 3 Position in Line Plug 94-VO	HSA; RP System w/ GEMS LAN Card
	AMP #350536-3	16	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-297100	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	HSA; RP System w/ GEMS LAN Card; Base Assy (w/o baseplates); Tilt Pot Harness; Pot Harness
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
46-296564	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	HSA; RP System w/ GEMS LAN Card; Base Assy (w/o baseplates)
	AMP #170366-3	13	Terminal - Mini Mate-N-Lok Socket Brass #18-	
	AMP #172167-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #170364-3	4	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
46-297368	AMP #350767-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	HSA; RP System w/ GEMS LAN Card; STC Assy (w/ GEMS LAN Card + Compatible CPU)
	AMP #350218-3	3	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2125039	AMP #350788-1	1	Mate-N-Lok 2 Position in Line Cap 94-V0	HSA; RP System w/ GEMS LAN Card; Support ASM; Axial Motor Assy; Axial Drive Motor w/EMC; Axial Motor Harness
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-297352	AMP #350767-1	2	Mate-N-Lok 3 Position in Line Cap 94-VO	HSA; RP System w/ GEMS LAN Card; Support ASM, compatible w/GEMS
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-297376	AMP #350767-1	2	Mate-N-Lok 3 Position in Line Cap 94-VO	HSA; RP System w/ GEMS LAN Card; Support ASM; OBC Assy, comp. w/ GEMS LAN
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-296825	AMP #350781-1	1	Mate-N-Lok 6 Position Matrix Cap 94-V0	HSA; RP System w/ GEMS LAN Card; Support ASM; OBC Assy, comp. w/ GEMS LAN
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-296824	AMP #350767-1	2	Mate-N-Lok 3 Position in Line Cap 94-VO	HSA; RP System w/ GEMS LAN Card; Support ASM; OBC Assy, comp. w/ GEMS LAN
	AMP #3-520140-2	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	

Table 5 'HSA Gantry with GEMS LAN' Mate-N-Lok Cross Reference

SECTION 6 – VX PREFERRED

The part number for the gantry is 2118213-2

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
46-297786G1	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	VXNE; Rear Gantry Cover Assy; Harness, Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
46-297786G1	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	VXNE; 'Mark 45B'; Harness, Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2136745	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	VXNE; Front Cover w/ Gantry Controls; EMC/Cable Gantry Harness
	AMP #170366-3	13	Terminal - Mini Mate-N-Lok Socket Brass #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2143938	AMP #172166-1	2	Mini Mate-N-Lok 3 Position in Line Plug 94-VO	VXNE; VX Non EMC Gantry Assy; Gantry Non/EMC Stationary Harness
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172160-1	2	Mini Mate-N-Lok 6 Position Matrix Cap 94-V2	
	AMP #66506-3	11	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172163-1	2	Mini Mate-N-Lok 15 Position Matrix Cap 94-V2	
	AMP #66506-3	22	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #172170-1	1	Mini Mate-N-Lok 12 Position Matrix Plug 94-VO	
	AMP #770988-3	11	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	
	AMP #770988-3	14	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	
	AMP #350536-3	9	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172168-1	1	Mini Mate-N-Lok 6 Position Matrix Plug 94-V2	
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	
	AMP #66506-3	10	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #66506-3	8	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350783-1	1	Mate-N-Lok 12 Position Matrix Cap 94-VO	
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2113158	AMP #350715-1	4	Mate-N-Lok 6 Position Matrix Plug 94-VO	VXNE; VX Non EMC Gantry Assy; Gantry Rotating Harness
	AMP #350536-3	14	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172166-1	1	Mini Mate-N-Lok 3 Position in Line Plug 94-VO	

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172341-1	2	Mini Mate-N-Lok 12 Position Matrix Plug 94-V2	
	AMP #166500-2	16	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350779-1	4	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350536-3	12	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172167-1	4	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #770988-3	16	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-297100	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	VXNE; VX Non EMC Gantry Assy; Non EMC Base Assy; Tilt Pot Harness Assy; Pot Harness
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2118220	AMP #172330-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	VXNE; VX Non EMC Gantry Assy; Non EMC Base Assy; Tilt Limit Switch Cable
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	VXNE; VX Non EMC Gantry Assy; Non EMC Base Assy; Tilt Limit Switch Cable
2125039	AMP #350788-1	1	Mate-N-Lok 2 Position in Line Cap 94-V0	VXNE; VX Non EMC Gantry Assy; Non EMC Support Assy; Axial Motor Assy; Axial Drive Motor w/EMC Filter Plug; Axial Motor Harness
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-297352	AMP #350767-1	2	Mate-N-Lok 3 Position in Line Cap 94-VO	VXNE; VX Non EMC Gantry Assy; Non EMC Support Assy; Filament Power Assy
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	

Table 6 'VX Preferred' Mate-N-Lok Cross Reference

SECTION 7 – EMC GANTRY WITH RPIGP

The part number for the gantry is 2119734

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
46-297786G1	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	RPIGP; Rear Gantry Cover Assy; Harness, Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2136745	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	RPIGP; Front Cover w/ Gantry Controls; EMC/Cable/Gantry Display
	AMP #170366-3	13	Terminal - Mini Mate-N-Lok Socket Brass #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2143937	AMP #172166-1	2	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	RPIGP; EMC Gantry for HP DAS; Gantry EMC Stationary Harness
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172160-1	2	Mini Mate-N-Lok 6 Position Matrix Cap 94-V2	
	AMP #66506-3	11	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172163-1	2	Mini Mate-N-Lok 15 Position Matrix Cap 94-V2	
	AMP #66506-3	22	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #172170-1	1	Mini Mate-N-Lok 12 Position Matrix Plug 94-VO	
	AMP #770988-3	11	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	
	AMP #770988-3	14	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350720-1	1	Mate-N-Lok 9 Position Matrix Plug 94-VO	
	AMP #350536-3	9	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172168-1	1	Mini Mate-N-Lok 6 Position Matrix Plug 94-V2	
	AMP #770988-3	6	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	
	AMP #66506-3	10	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #66506-3	8	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #350783-1	1	Mate-N-Lok 12 Position Matrix Cap 94-VO	
	AMP #350536-3	8	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2113158	AMP #350715-1	4	Mate-N-Lok 6 Position Matrix Plug 94-V0	RPIGP; EMC Gantry for HP DAS; Gantry Rotating Harness
	AMP #350536-3	14	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172166-1	1	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172341-1	2	Mini Mate-N-Lok 12 Position Matrix Plug 94-V2	

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #166500-2	16	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350779-1	4	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350536-3	12	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #172167-1	4	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #770988-3	16	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
46-297100	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	RPIGP; EMC Gantry for HP DAS; Base Assy (w/o baseplates); Tilt Pot Harness Assy; Pot Harness
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2118220	AMP #172330-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	RPIGP; EMC Gantry for HP DAS; EMC Gantry Base Assy (w/o baseplates); Tilt Limit Switch Cable
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2125039	AMP #350788-1	1	Mate-N-Lok 2 Position in Line Cap 94-V0	RPIGP; EMC Gantry for HPDAS; Support Assy; Axial Motor Assy; Axial Drive w/EMC; Axial Motor Harness
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2120493	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	RPIGP; EMC Gantry for HPDAS; Support Assy; Filament Power; CTVRC Module; CTVRC Fast Enhanced; Stator Cable W6
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	

Table 7 'EMC Gantry with RPIGP' Mate-N-Lok Cross Reference

SECTION 8 – FAST RHAP EMC GANTRY - RIM COVERS

The part number for the gantry is 2183250-3

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
2153642	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	RHAPE; Gemini Three Piece Casing Assy; Gemini Thermal Switch Assy
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
46-297786G1	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	RHAPE; Rear Cover Assy; Harness, Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2136745	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	RHAPE; Front Gantry Cover Assy; EMC/Cable/Gantry Display - Intercom
	AMP #170366-3	13	Terminal - Mini Mate-N-Lok Socket Brass #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2188443	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	RHAPE; Fast RHAP EMC Gantry Sonata Ready; FRHAP/Control Assy; AC Control Harness for OBC
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350767-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	
	AMP #350218-3	8	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2183248-2	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	RHAPE; Fast RHAP EMC Gantry Sonata Ready; FRHAP Gantry Rot Harness (Zeus)
	AMP #166500-2	2	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #166500-2	2	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #172170-1	1	Mini Mate-N-Lok 12 Position Matrix Plug 94-VO	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #172167-1	3	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #166500-2	12	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350715-1	2	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #640585-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	
	AMP #166500-2	6	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2225314	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	RHAPE; FRHAP EMC Gantry Sonata Ready; EMC Sonata Ready Gantry Stat. Harn
	AMP #170364-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172163-1	1	Mini Mate-N-Lok 15 Position Matrix Cap 94-V2	
	AMP #170364-3	11	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
	AMP #172166-1	1	Mini Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #170364-3	2	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #170366-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2219102	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	RHAPE; Top Cover Assy - Two Fans; Harness for Top Cover w/ Two Fans
	AMP #350536-3	3	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172166-1	2	Mini Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #770988-3	4	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350778-1	2	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-297100	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	RHAPE; FRHAP EMC Gantry Sonata; EMC Gantry Base Assy; Tilt Pot Harness; Pot Harn
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2118220	AMP #172330-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	RHAPE; FRHAP EMC Gantry Sonata; EMC Gantry Base Assy; Tilt Limit Switch Cable
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2125039	AMP #350788-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	RHAPE; FRHAPE EMC Gantry Sonata; FRHAPE Support ASM EMC W/HPDAS; Axial Motor Assy; Axial Drive w/EMC; Axial Motor Harness
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2174036	AMP #640585-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	RHAPE; FRHAPE EMC Gantry Sonata; FRHAPE Support ASM EMC W/HPDAS; HEMRC Assy; HEMRC/Power Harness
	AMP #350218-3	6	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	8	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350767-1	2	Mate-N-Lok 3 Position in Line Cap 94-VO	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2184185	AMP #640586-1	1	Mate-N-Lok 8 Position in Line Plug 94-V2	RHAPE; FRHAPE EMC Gantry Sonata; FRHAPE Support ASM EMC W/HPDAS; HEMRC Assy; Resistor Harness R-HEMRC
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2120629	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	RHAPE; FRHAPE EMC Gantry Sonata; FRHAPE Support ASM EMC W/HPDAS; EMC Project/Axial MTR; EMC/Axial Drive
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2119349	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	RHAPE; FRHAPE EMC Gantry Sonata; FRHAPE Support ASM EMC W/HPDAS; PWR CBL ASM; Gantry AC Cable Filter
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350767-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	
	AMP #350218-3	3	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	

Table 8 'Fast RHAP EMC Gantry - Rim Covers' Mate-N-Lok Cross Reference

SECTION 9 – FAST RHAP NON-EMC GANTRY - RIM COVERS

The part number for the gantry is 2183255-3

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
2153642	AMP #172162-1	1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	FRHAPNE Gantry Sub - Rim Covers; Gemini 3 Piece Casing Assy; Gemini Thermal Switch
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2219102	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	FRHAPNE Gantry Sub - Rim Covers; Top Cover Assy - Two Fans; Harness for Top Cover w/ Two Fans
	AMP #350536-3	3	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #172166-1	2	Mini Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #770988-3	4	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #172165-1	1	Mini Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #770988-3	2	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350550-7	2	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	
	AMP #350778-1	2	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-297786G1	AMP #172157-1	1	Mini Mate-N-Lok 3 Position in Line Cap 94-V2	FRHAPNE Gantry Sub - Rim Covers; Rear Cover Assy; Harness Microphone
	AMP #770987-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2136745	AMP #172171-1	1	Mini Mate-N-Lok 15 Position Matrix Plug 94-VO	FRHAPNE Gantry Sub - Rim Covers; Front Cover; EMC/Cable/Gantry Display - Intercom
	AMP #170366-3	13	Terminal - Mini Mate-N-Lok Socket Brass #18-22 AWG	
	AMP #172161-1	1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2183248-2	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; FRHAP Gantry Rot Harn (Zeus)
	AMP #166500-2	2	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350766-1	1	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #166500-2	2	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #172170-1	1	Mini Mate-N-Lok 12 Position Matrix Plug 94-VO	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #172167-1	3	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	
	AMP #166500-2	12	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350715-1	2	Mate-N-Lok 6 Position Matrix Plug 94-VO	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #166500-2	8	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #640585-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	
	AMP #166500-2	6	Terminal - Mini Mate-N-Lok Crimp Gold 22 AWG	
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	4	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2188443	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; FRHAP Gantry/Central Harness

Harness Part No.	Mate-N-Lok Part No.	Qty	Description/Comment	Connector Location
	AMP #350780-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	Gantry Sonata; FRHAP Gantry/Control Harness for OBC
	AMP #350767-1	1	Mate-N-Lok 3 Position in Line Cap 94-VO	
	AMP #350218-3	8	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2123743	AMP #350766-1	4	Mate-N-Lok 3 Position in Line Plug 94-VO	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; Non EMC 550DC/120AC Cathode Rot
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2183256	AMP #350779-1	6	Mate-N-Lok 4 Position in Line Plug 94-VO	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; FRHAPNE Anode Rot Cable
	AMP #350766-1	6	Mate-N-Lok 3 Position in Line Plug 94-VO	
	AMP #350536-3	42	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
46-297100	AMP #172338-1	1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; Non EMC Base; Tilt Pot Harness; Pot Harness
	AMP #170366-3	3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	
2118220	AMP #172330-1	1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; Non EMC Base; Tilt Limit Switch Cable
	AMP #170364-3	3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	
2125039	AMP #350788-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	FRHAPNE; FHAPNE Gantry Sonata; FRHAP Support NEMC; Axial Motor; Axial Drive Motor w/ EMC; Axial Motor Harn
	AMP #350218-3	2	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
2174032	AMP #640585-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	FRHAPNE Gantry Sub - Rim Covers; FHAPNE Gantry Sonata; FRHAP Support Assy for Non EMC; HEMRC; HEMRC/550V
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2174036	AMP #640585-1	1	Mate-N-Lok 6 Position in Line Plug 94-V2	FRHAPNE Gantry Sub; FHAPNE Gantry Sonata; FRHAP Support Assy for Non EMC; HEMRC; HEMRC/Power
	AMP #350218-3	6	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350779-1	2	Mate-N-Lok 4 Position in Line Plug 94-VO	
	AMP #350218-3	8	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	
	AMP #350767-1	2	Mate-N-Lok 3 Position in Line Cap 94-VO	
	AMP #350536-3	6	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350778-1	1	Mate-N-Lok 2 Position in Line Cap 94-VO	
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2184185	AMP #640586-1	1	Mate-N-Lok 8 Position in Line Plug 94-V2	FRHAPNE Gantry Sub; FHAPNE Gantry Sonata; FRHAP Support Assy for Non EMC; HEMRC; Resistor Harn
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
2120629	AMP #350779-1	1	Mate-N-Lok 4 Position in Line Plug 94-VO	FRHAPNE Gantry Sub; FHAPNE Gantry Sonata; FRHAP Support Assy NEMC; EMC Project/Axial MTR; EMC/Axial Drive
	AMP #350536-3	4	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	
	AMP #350777-1	1	Mate-N-Lok 2 Position in Line Plug 94-VO	
	AMP #350536-3	2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	

Table 9 'Fast RHAP Non-EMC Gantry - Rim Covers' Mate-N-Lok Cross Reference

SECTION 10 – MALE-FEMALE CROSS REFERENCE

Item	Qty	Part Number	Description/Comment	Mate Combo
1	1	AMP #1-480700-0	Mate-N-Lok 3 Position in Line Plug 94-V2	1-480701-0
2	8	AMP #172157-1	Mini Mate-N-Lok 15 Position in Line Cap 94-V0	172165-1
3	2	AMP #172158-1	Mini Mate-N-Lok 3 Position in Line Cap 94-V0	172166-1
4	2	AMP #172159-1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	172167-1
5	2	AMP #172160-1	Mini Mate-N-Lok 6 Position Matrix Cap 94-V2	172168-1
6	6	AMP #172161-1	Mini Mate-N-Lok 9 Position Matrix Cap 94-V2	172169-1
7	5	AMP #172162-1	Mini Mate-N-Lok 12 Position Matrix Cap 94-V2	172170-1
8	2	AMP #172163-1	Mini Mate-N-Lok 15 Position Matrix Cap 94-V2	172171-1
9	8	AMP #172165-1	Mini Mate-N-Lok 2 Position in Line Plug 94-V0	172157-1, 172233-1
10	8	AMP #172166-1	Mini Mate-N-Lok 3 Position in Line Plug 94-V0	172158-1, 172234-1
11	6	AMP #172167-1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	172159-1
12	2	AMP #172168-1	Mini Mate-N-Lok 6 Position Matrix Plug 94-V2	172160-1
13	1	AMP #172169-1	Mini Mate-N-Lok 9 Position Matrix Plug 94-V0	172161-1
14	2	AMP #172170-1	Mini Mate-N-Lok 12 Position Matrix Plug 94-V0	172162-1
15	5	AMP #172171-1	Mini Mate-N-Lok 15 Position Matrix Plug 94-V0	172163-1
16	1	AMP #172328-1	Mini Mate-N-Lok 2 Position in Line Plug 94-V2	172336-1
17	2	AMP #172330-1	Mini Mate-N-Lok 4 Position Matrix Cap 94-V2	172338-1
18	1	AMP #172336-1	Mini Mate-N-Lok 2 Position in Line Plug 94-V2	172328-1, 172343-1
19	4	AMP #172338-1	Mini Mate-N-Lok 4 Position Matrix Plug 94-V2	172330-1
20	2	AMP #172341-1	Mini Mate-N-Lok 12 Position Matrix Plug 94-V2	172333-1
21	6	AMP #350715-1	Mate-N-Lok 6 Position Matrix Plug 94-V2	350781-1
22	6	AMP #350720-1	Mate-N-Lok 9 Position Matrix Plug 94-V2	350782-1
23	15	AMP #350766-1	Mate-N-Lok 3 Position in Line Plug 94-V2	350767-1
24	5	AMP #350767-1	Mate-N-Lok 3 Position in Line Cap 94-V0	350766-1
25	10	AMP #350777-1	Mate-N-Lok 2 Position in Line Plug 94-V2	350778-1
26	10	AMP #350778-1	Mate-N-Lok 2 Position in Line Cap 94-V2	350777-1
27	10	AMP #350779-1	Mate-N-Lok 4 Position in Line Plug 94-V2	350780-1
28	4	AMP #350780-1	Mate-N-Lok 4 Position in Line Plug 94-V0	350779-1
29	1	AMP #350781-1	Mate-N-Lok 15 Position Matrix Cap 94-V2	350715-1
30	1	AMP #350783-1	Mate-N-Lok 12 Position Matrix Cap 94-V0	350735-1
31	2	AMP #350787-1	Mate-N-Lok 3 Position in Line Cap 94-V0	350831-1
32	2	AMP #1-480699-0	Mate-N-Lok 2 Position in Line Cap 94-V0	1-480698-0
33	2	AMP #350809-1	Mate-N-Lok 5 Position in Line Plug 94-V2	350810-1
34	1	AMP #172337-1	Mini Mate-N-Lok 3 Position in Line Plug 94-V2	172344-1, 172234-1
35	2	AMP #640581-1	Mate-N-Lok 6 Position in Line Plug 94-V2	926307-3
36	2	AMP #640585-1	Mate-N-Lok 6 Position in Line Plug 94-V2	926307-1
37	1	AMP #640586-1	Mate-N-Lok 8 Position in Line Plug 94-V2	926308-1
38	70	AMP #166500-2	Terminal - Mate-N-Lok Crimp-Snap Gold 22 AWG	No mate
39	70	AMP #170364-3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	170366-3
40	70	AMP #170366-3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	170364-3
41	200	AMP #350218-3	Terminal - Mate-N-Lok Pin Tin #14-20 AWG	350536-3
42	200	AMP #350536-3	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	350218-3
43	30	AMP #350536-7	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	350218-7
44	150	AMP #350550-7	Terminal - Mate-N-Lok Socket Gold #14-20 AWG	350547-7
45	30	AMP #350851-7	Terminal - Mate-N-Lok Socket Gold #18-24 AWG	350561-7
46	30	AMP #3-520140-2	Terminal - Mate-N-Lok Socket Tin #14-20 AWG	3-521013-2
47	70	AMP #66506-3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	66504-3
48	30	AMP #770902-3	Terminal - Mini Mate-N-Lok Socket Gold #22-26 AWG	770901-3
49	200	AMP #770987-3	Terminal - Mini Mate-N-Lok Pin Gold #18-22 AWG	770988-3
50	200	AMP #770988-3	Terminal - Mini Mate-N-Lok Socket Gold #18-22 AWG	770987-3



GE Medical Systems

P.O. BOX 414

MILWAUKEE WISCONSIN 53201-0414 U.S.A.