

820-0311 – Install instructions for PN 205-0121-23 Pump Hose (GE P/N 5402967)

Tools Included in Kit:

- Strap wrench (Lytron PN 530-0790)
- Teflon (PTFE) tape

Tools Required:

- 3/8" wrench or adjustable wrench
- Large slip-joint pliers

Optional Tool:

Procedure:

1. Perform shutdown of system in accordance with Lytron manual #820-0190. (GE P/N 5161931 Heat Exchanger Cabinet Installation) found in the cabinet or on the Service DVD.
2. Lockout/Tagout system in accordance with GE procedures.
3. Drain system. Drain system in accordance with Lytron manual #820-0190. *It is also acceptable to drain the system through the pump drain.*

To install the molded hose:

4. Remove existing pump suction hose assembly from HEC. (Leave gate valve in place; ensure gate valve does not rotate when removing fittings with slip-joint pliers.)



Figure 1 Removing existing hose assembly detail.

5. Wrap threads of supplied plastic barbed fitting with the supplied PTFE tape. Wrap entire area of threads with two full wraps (in a clockwise direction when looking at the threaded end).
6. Thread new hose barb fitting into bottom of gate valve to make a leak-tight connection.



Figure 2 Installing new hose bard fitting detail.

7. Place the supplied Breeze-brand hose clamps over pump suction hose and install over barb on front of the pump and beneath the gate valve. (Hose is orientation specific and can only be installed one way) Refer to photo below:



Figure 3 Detail of Hose orientation

8. Tighten Breeze hose clamps with 3/8" wrench until the stacked washers flatten.
9. Fill the system in accordance with Lytron manual #820-0190 (GE P/N 5161931).
10. Clear the Lockout/Tagout in accordance with GE procedures.
11. Perform a normal startup according to Lytron manual #820-0190.
12. Check for any leakage. Repair if necessary.

End of Procedure

Revision History

REV	ECN# / REASON FOR CHANGE	DATE	ENG APPV'D	SERV APPRV'D
A	Initial Release	5/5/2011	NG	HB