

## 820-0230 – Install Instructions for GC & PE Mixing Valves (P/N: 205-0121-02) GE P/N: 5156318

### Tools Required:

- 10 foot ladder
- 2 Slip lock pliers
- Slip wrench
- Utility knife
- Insulated foam tape

### Removal Procedure:

1. Perform shutdown of system in accordance with Lytron manual #820-0190.
2. Lockout/Tag out system in accordance with GE procedures.
3. Drain system. Drain system in accordance with Lytron manual #820-0190. Draining may also be accomplished by using the pump drain method.

**NOTE:** Removal of the PE Mixing valve will require the removal of the GC Mixing valve located directly in front of the PE valve. The procedure for removal applies to both valves.

4. Disconnect the 5 pin connector to the valve.
5. Remove insulation around either side of mixing valve using a utility knife or equivalent. (Refer to photo 1)



**Photo 1**

6. Remove the exhaust manifold (Port A) of the mixing valve by using a slip wrench. The nut will remain on the manifold. (Refer to photo 2)



**Photo 2**

7. Remove exhaust manifold (Port AB) of the mixing valve by using a slip wrench. The nut will remain on the manifold. (Refer to photo 2)

8. Remove the exhaust manifold (Port B) of the mixing valve by using a slip wrench. The nut will remain on the manifold. (Refer to photo 2)
9. Remove the valve.
10. Repeat Steps 4 thru 9 to remove PE mixing valve.

End of Procedure

---

## Install Procedure:

**NOTE:** If replacing PE mixing valve, GC mixing valve will also have to be removed/installed due to location of PE mixing valve.

1. Mate the new valve to the manifold (Port B). Be careful to make it flush with the manifold.
2. Tighten nut with 1/1/2" wrench and slip lock pliers.
3. Repeat procedure for manifolds connecting to Port A and Port AB (as marked on the mixing valve).
4. Wrap each connection with insulated tape.
5. Connect 5 pin connector to appropriate control plug.
6. Repeat Steps 1 thru 5 for GC mixing valve if that was taken out previously.
7. Refill system in accordance with Lytron manual #820-0190.
8. Clear Lockout/Tag out for the system in accordance with GE procedures.
9. Restart system.
10. Check for leaks around the manifolds of mixing valve(s) replaced.

End of Procedure