

GLOSSARY

Accuvar	An MOV type spike and surge protector that protects the regulator. Excessive input surge will cause this fail lamp to turn on.
Dead front	The panel inside outer door of Lightning PDU which covers the load panel and its output circuit breakers.
Circuit Breaker Panel	(See <i>load panel</i> .)
Current transformer	The transformer used to feed back a current signal to the logic board.
Distribution panel	(See <i>load panel</i> .)
Load panel (A5)	The set of circuit breakers controlling power output from Lightning PDU to the loads.
Models 46- -317099 P20 &P21	Different models included in the reference are indicated by a forward slash, followed by the last two characters of the model number.
MOSFET	Metal Oxide Semiconductor Field Effect Transistor
NEMA	National Electrical Manufacturers Association
Outer door	The front door on Lightning PDU. It covers the front panel and load panel, and, when closed, prevents opening the electrical outlet cover.
PDU	Power Distribution Unit — A device which receives electric power from a source and distributes the power to the components of a medical system. It provides for connections to ground and isolates the components of the system from each other and from line power.
PO	Power Off — A switch on the front panel which disconnects all loads from line power.
PWB	Printed Wiring Board — A surface for the mounting and interconnection of electronic components.
Regulated models	Lightning PDU models which include a transformer with multiple taps. Lightning PDU senses the input voltage and, based on the input voltage, automatically selects the transformer tap so the output voltage has the desired characteristics.
Reset (a circuit breaker)	Snap the breaker first to OFF position, then to ON.
SCR	Silicon- -Controlled Rectifier

REV 1

DIRECTION 46- -2213107

Shunt Trip	A device for tripping a circuit breaker indirectly, using a signal to activate a solenoid, instead of directly, because of an overcurrent condition.
Trip	A circuit breaker in an open position as a result of an overcurrent condition to the load, or as the result of a remote trip command (shunt trip). In a tripped condition, power to the load is off. The tripped circuit breaker position differs from the off position in that the breaker must first be turned to the off position before restoring power to the load.
TB	Terminal Block