



ELLIS & WATTS INTERNATIONAL, INC
4400 GLEN WILLOW LAKE LANE BATAVIA, OH 45103
(513) 752-9000

8/10/01 SB-007

This bulletin is in regard to the same subject matter as service bulletin # SB-006

SERVICE BULLETIN

Start-up Issues

The purpose of this bulletin is to address an important service issue:

Important

It is often necessary for the Service Provider to perform many tasks during the course of a start-up visit, that do not fall within the scope of work that E & W arranged with GE. Servicing the customer is always our primary goal. Therefore, these, "out of scope," efforts will likely continue.

The purpose of this bulletin is to advise all service providers that **you need to make sure** that this, "out of scope," work is documented and **agreed upon by the GE Site Installation Specialist**. The scope of work is outlined in the INSTALLATION RESPONSIBILITY MATRIX found on page 1-3 of Technical Publication 468 Rev 0. A modification of this matrix is attached, and is to be used for the approval of excess costs. It is very important that a GE representative signs this document and indicates an **account number for the changes**. If you encounter resistance in getting a signature please contact Ellis and Watts Service Department so we can work with you to resolve the problem. If there is no GE representative available to sign the document, please get the general contractor or a representative to sign the report and print his title.

Notice that there is a note on the bottom of the document, as follows:

- (*) Asterisk indicates items for which the start-up technician either assisted in or completed the task.

Please place an asterisk by those items and get the appropriate signature and account number.

Installation Site Map LC10M	Cust. Contr.	GE Service	E&W Service	Who Pays
Once Cooling Cabinets Arrive				
Unload TGWC from Truck. Refer to section 4	X			Customer
Move TGWC to equipment room and mount (Use Seismic Tie Down Brackets where required by law). See Section 5-1	X			Customer
Connect customer supplied power cable from MDP to TGWC. See Section 5-3	X			Customer
Install anti tipping legs. See Section 5-2	X			Customer
Once MR System Arrives				
Install water lines from TGWC to Gradient Coil		X		GE
Fill TGWC with Propylene Glycol		X		GE
Start up TGWC and ensure proper phasing and inspect for leaks.		X		GE
Verify operation per E&W checklist when load is available.			X	E&W

*Asterisk indicates items for which start-up technician either assisted in or completed tasks.

GE Installation Specialists (or Rep.) _____
Signature
Printed Name
Date

Account # for charges to items with Asterisk. _____

Installation Site Map LC20M/RAC	Cust. Contr	GE Service	E&W Service	Who Pays
Once Cooling Cabinets Arrive				
Unload SCC1, RAC and SCC2 from Truck	X			Customer
Move SCC1 to Equipment Room and mount on Vibration Isolators (Use seismic Tie down brackets where required by law and will be included in FDO when customer order seismic package for site (ref# M0709)) See Section 5	X			Customer
Inflate vibration isolators with air or dry nitrogen. (See Section 5-1-1)	X			Customer
Connect customer supplied power cable from MDP to SCC1 See Section 5-2-2-	X			Customer
Move SCC2 to equipment room	X			Customer
Move RAC to Installation point (M2085KE Only) and assemble See Section 5-3	X			Customer
Install Refrigeration Piping for RAC (Remote Air-cooled Condenser) (M2085KE Only – See GEMS Pre-Install for details)	X			Customer
Install Electrical Conduit from SCC1 to RAC See Section 5-3-2	X			Customer
Make final connection of Refrigerant Lines between SCC1 and RAC See Section 5-3-1	X			Customer
Fill refrigerant lines with Dry Nitrogen and <u>LEAK TEST</u> See Section 5-3-1	X			Customer
Install Facility Backup Chilled Water Supply and Return Lines to SCC1 (Optional) (Emergency Water Back-up) See Section 5-1-7	X			Customer
Connect Customer supplied power cable from SCC1 to RAC through conduit	X			Customer
Evacuate nitrogen from refrigerant lines, pull vacuum to 500 microns and fill with a holding charge of 10 pounds of R-134a refrigerant See Section 5-3-1	X			Customer
Operate and add final refrigerant charge of R-134a refrigerant (M2085KE Only – See Pre-Install for details)			X	E&W
Install power and control cable between SCC2 and SCC1 (M2085KE Only. KC and KG will have cable installed once Magnet Arrives)See Section 5-2-2			X	E&W
Ensure that SCC1, SCC2 and RAC are operational (I.e. turn unit on) for magnet arrival (M2085KE Only. KC and KG are staged at E&W prior to shipping)			X	E&W

Installation Site Map LC20M/RAC	Cust. Contr	GE Service	E&W Service	Who Pays
Once Magnet Arrives				
Install water lines from SCC1 to 1) Gradient Coil 2) Cryo Cooler Compressor 3) Shield Cooler Compressor 4) SCC2 (Note: If Gradient or SCC2 not connected, they must be short looped on SCC1)		X		GE
Install 2" Air Hose from SCC2 to Air Duct on Back of Magnet		X		GE
Fill SCC1 with Propylene Glycol			X	E&W
Install power and control cable between SCC2 and SCC1 (M2085KC and KG only) See Section 5-2-2			X	E&W
Start up SCC1, SCC2, RAC and ensure proper operation as per E&W Chiller Startup Check List			X	E&W

*Asterisk indicates items for which start-up technician either assisted in or completed tasks.

GE Installation Specialists (or Rep.) _____
Signature
Printed Name
Date

Account # for charges to items with Asterisk.

Installation Site Map LC20M	Cust. Contr	GE Service	E&W Service	Who Pays
Once Cooling Cabinets Arrive				
Unload SCC1 and SCC2 from Truck	X			Customer
Move SCC1 to Equipment Room and mount on Vibration Isolators (Use seismic Tie down brackets where required by law and will be included in FDO when customer order seismic package for site (ref # M0709)) (Sections 3-3 to 3-9, 5-1-1, and 5-1-2)	X			Customer
Inflate vibration isolators with air or dry nitrogen. (Section 5-1-1)	X			Customer
Connect customer supplied power cable from MDP to SCC1 (Section 5-1-3)	X			Customer
Install Facility Backup Chilled Water Supply and Return Lines to SCC1 (Optional) (Emergency Water Back-up) (Section 5-1-8)	X			Customer
Move SCC2 to equipment room	X			Customer
Once Magnet Arrives				
Install water lines from SCC1 to 1) Gradient Coil 2) Cryo Cooler Compressor 3) Shield Cooler Compressor 4) SCC2 (Note: If Gradient or SCC2 not connected, they must be short looped on SCC1) (Section 5-1-5 and 5-1-6)		X		GE
Install 2" Air Hose from SCC2 to Air Duct on Back of Magnet		X		GE
Fill SCC1 with Propylene Glycol			X	E&W
Install power and control cable between SCC2 and SCC1 (M2085KC and KG only) (Section 5-2-2)			X	E&W
Start up SCC1 and SCC2, ensure proper operation as per E&W Chiller Startup Check List			X	E&W

*Asterisk indicates items for which start-up technician either assisted in or completed tasks.

GE Installation Specialists (or Rep.) _____
Signature Printed Name Date

Account # for charges to items with Asterisk. _____

Installation Site Map LC10MTO	Cust. Contr	GE Service	E&W Service	Who Pays
Once Cooling Cabinets Arrive				
Unload TGWC from Truck	X			Customer
Install concrete pad.	X			Customer
Move TGWC to outdoor location and mount (Use seismic Tie down brackets where required by law). See Section 5.	X			Customer
Connect customer supplied power cable from MDP to TGWC. See Section 5-2.	X			Customer
Install Remote Control Panel in Equipment Room	X			Customer
Once MR System Arrives				
Install water lines from Equipment Room to Gradient Coil		X		GE
Fill TGWC with Propylene Glycol		X		GE
Start up TGWC and ensure proper phasing and inspect for leaks.		X		GE
Install interconnecting cables between Remote Control Panel and TGWC	X			Customer
Install copper water lines with shutoff valves from TGWC to Equipment Room	X			Customer
Verify operation per E&W checklist when load is available.			X	E&W

*Asterisk indicates items for which start-up technician either assisted in or completed tasks.

GE Installation Specialists (or Rep.) _____
Signature Printed Name Date

Account # for charges to items with Asterisk. _____

Installation Site Map LC20MWC	Cust. Contr	GE Service	E&W Service	Who Pays
Once Cooling Cabinets Arrive				
Unload SCC1 and SCC2 from Truck	X			Customer
Move SCC1 to Equipment Room and mount on Vibration Isolators (Use seismic Tie down brackets where required by law and will be included in FDO when customer order seismic package for site (ref# M0709)) (See Section 5-1-1)	X			Customer
Inflate vibration isolators with air or dry nitrogen. (See Section 5-1-1))	X			Customer
Connect customer supplied power cable from MDP to SCC1 (See Section 5-1-3)	X			Customer
Install condenser water supply and return lines for water cooled SCC (M2085KG Only - See GEMS Pre-Install for details) (See Section 5-1-5)	X			Customer
Install Facility Backup Chilled Water Supply and Return Lines to SCC1 (Optional) (Emergency Water Back-up) (See Section 5-1-7)	X			Customer
Move SCC2 to equipment room	X			Customer
Once Magnet Arrives				
Install water lines from SCC1 to 1) Gradient Coil 2) Cryo Cooler Compressor 3) Shield Cooler Compressor 4) SCC2 (Note: If Gradient or SCC2 not connected, they must be short looped on SCC1)		X		GE
Install 2" Air Hose from SCC2 to Air Duct on Back of Magnet		X		GE
Fill SCC1 with Propylene Glycol		X		GE
Install power and control cable between SCC2 and SCC1 (M2085KC and KG only) (See Section 5-2-2)		X		GE
Start up SCC1 and SCC2 ensure proper phasing and there are no leaks.		X		GE
Verify proper Chiller system installation and operation per E&W Chiller Startup Check List when SCC1 installation is complete.			X	E&W

*Asterisk indicates items for which start-up technician either assisted in or completed tasks.

GE Installation Specialists (or Rep.) _____
Signature Printed Name Date

Account # for charges to items with Asterisk. _____