

## TABLE OF CONTENTS

|                                                   |   |
|---------------------------------------------------|---|
| TABLE OF CONTENTS .....                           | 1 |
| 1- SGI POWER SUPPLY FUNCTIONAL CHECK .....        | 2 |
| 2- PERIPHERAL POWER SUPPLY FUNCTIONAL CHECK ..... | 2 |
| REVISION HISTORY .....                            | 4 |

**Description** - There are two power supplies located in the SGI host computer chassis. One is called the *SGI power supply*. The other is called the *peripheral power supply*. Both of these power supplies have functional checks.

## 1- SGI POWER SUPPLY FUNCTIONAL CHECK

The functional check for the SGI power supply is incorporated in the Power Up Diagnostics section of the procedure for Operator Workspace (OW) Diagnostics. See the procedure for Operator Workspace (OW) Diagnostics.

## 2- PERIPHERAL POWER SUPPLY FUNCTIONAL CHECK

The peripheral power supply (also called the *auxiliary power supply*) used in the host computer provides power for the floptical, CDROM, MOD and hard disk drives. In addition, this supply is used in the system to provide power to the work space interface module (WIM) and the 10\_Base\_T LAN Hub (also called Model 800 Hub). This power is available to measure at a 9-pin female sub-D connector at the rear of the host computer. See Illustration L1 and Illustration L2.

 **9 Pin Sub-D connector symbol.**

| Pin #             | Output Voltage |                                                                             |
|-------------------|----------------|-----------------------------------------------------------------------------|
| 1, 2              | +12V $\pm$ 5%  | Measure these voltages at the corresponding pins referenced to ground pins. |
| 3, 4              | +5V $\pm$ 5%   |                                                                             |
| 5                 | -12V $\pm$ 5%  |                                                                             |
| 6, 7, 8, 9 ground |                |                                                                             |

**MEASURING POWER AT THE 9 PIN CONNECTOR**  
ILLUSTRATION L1

| Pin # | Output Voltage |                                                                                                                   |
|-------|----------------|-------------------------------------------------------------------------------------------------------------------|
| 1     | +12V $\pm$ 5%  | It is also possible to measure the +5V and +12V outputs at any of the unused drive power connectors (4 contacts). |
| 4     | +5V $\pm$ 5%.  |                                                                                                                   |
| 2, 3  | ground         |                                                                                                                   |

MEASURING POWER AT THE 9 PIN CONNECTOR  
ILLUSTRATION L2

## REVISION HISTORY

| REV | DATE          | AUTHOR        | PRIMARY REASONS FOR CHANGE                |
|-----|---------------|---------------|-------------------------------------------|
| 0   | July 14, 1998 | J. Saperstein | Initial conversion from Toolbook to Word. |
|     |               |               |                                           |
|     |               |               |                                           |
|     |               |               |                                           |
|     |               |               |                                           |