


TABLE OF CONTENTS

TABLE OF CONTENTS 1
1- BLOWER BOX MG6 2
REVISION HISTORY 3

Description - Procedure for adjusting the air flow in the magnet bore for patient comfort.

1- BLOWER BOX MG6

The Blower Box contains a constant speed AC motor. Bore vent air flow speed is changed by adjusting an air baffle in the Blower Box. See Illustration L4780A for procedure.



L4780A

BLOWER BOX AIR FLOW ADJUSTMENT
ILLUSTRATION L4780A

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASONS FOR CHANGE
A	April 17, 1998	W. Pasciak	Initial release converted to Word