

LVAC POWER

UPS POWER

PDU SHIPPED WITH JUMPERS A,B,C ON TS4

TO CONNECT THREE
 1 - REMOVE JUMPERS
 2 - CONNECT UPS INPUT POWER TO
 3 - CONNECT UPS OUTPUT POWER TO
 4 - CONNECT INPUT & OUTPUT NEUTRAL & WIRES TO TS4-4, 5, 9,

KT G-
 KT G-
 KT G-
 GANTRY-PWR

208Y120- 1 2
 208Y120- 3 4
 208Y120- 5 6
 SYSLIT
 PDU-PGN

