

820-0235 – Install Instructions Liquid Pressure Transducer (XDCR) (P/N: 205-0121-07) GE P/N: 5267643

Tools Required:

- Adjustable or open end Wrench
- Loctite[™] 565
- Loctite[™] 7649 Primer

Removal Procedure:

1. Perform shutdown of system in accordance with Lytron manual #820-0190.
2. Lockout/Tag out system in accordance with GE procedures.
3. Drain system in accordance with Lytron manual #820-0190.
4. Locate Pressure Transducer (xdcr) to remove.
5. Remove electrical connection by pressing down on xdcr retention tab and carefully extracting the connection. (Refer to Photo 1)



Photo 1

6. Using an adjustable or open end wrench, remove the pressure xdcr from the system. Leave the cable in place.

Install Instructions for Liquid Pressure Transducer (XDCR)

1. Prepare threaded end of transducer (xdcr) with Light coating of Loctite 7649 primer and allow to dry (approx 2 min) then apply a bead of Loctite 565 around the threads starting 1 thread from end of xdcr.
2. Carefully screw xdcr into manifold.
3. Using an adjustable or open end wrench, tighten to hand tight.
4. Connect signal harness to xdcr.
5. Fill system in accordance with Lytron manual #820-0190.
6. Check for leaks around unit just installed.
7. Return machine to running condition per Lytron manual #820-0190.
8. Check pressure reading associated with pressure transducer just replaced.

