

820-0239 – Install Instructions for Tank Level Switch (P/N: 205-0121-11) GE P/N: 5267644

Tools Required:

- 1" wrench or slip wrench
- 1 ½" wrench or slip wrench
- Loctite[™] 739 or equivalent

Removal Procedure:

1. Perform shutdown of system in accordance with Lytron manual #820-0190.
2. Lockout/Tag out system in accordance with GE procedures.
3. Drain system. Drain system in accordance with Lytron manual #820-0190. Alternate draining through the pump housing is also acceptable.

NOTE: Removal of lower Tank Level Switch requires removal of the pump discharge hose to the tank.

4. Remove pump discharge hose from left side of tank (looking from the front of the system).



Remove

Photo 1 Tank inlet location

5. Disconnect the switch leads from Tank Level switch.
6. Remove the Tank Level switch using a 1" wrench or slip wrench.

End of Procedure

Install Instructions:

1. Apply a generous amount of Loctite 739 or equivalent around the threads of the tank level switch.
2. Screw the tank level switch into the tank.
3. Allow some time for the Loctite to setup (approx. 10min).
4. Attach leads to tank switch.
5. Re-attach pump discharge to tank.
6. Fill system in accordance with Lytron manual #820-0190.
7. Start system normally.
8. Refer to PLC screen to verify proper level switch operation.

End of Procedure