

Table 1: TEST SWITCH AND TEST LED DEFINITIONS

Task	Switch Number	Position	Item Controlled	LED Bank 1	LED Bank 2
Normal Operation:	1	Down		MDS comm status	Head T/R fault
	2	-----	(When one	NB comm status	Body T/R fault
	3	-----	of these 10 is in use, the others	Monitor A comm status	Spectro T/R fault
	4	-----	are inactive)	Monitor B comm status	Body Coil 1 fault
	5	-----		PS fault	Dyn Disable fault
	6	-----		top cover open	Body Coil 2 fault
	7	-----		MC faults disabled	Multi-coil 1 fault
	8	-----		T/R faults disabled	Multi-coil 2 fault
	9	-----		DD faults disabled	Multi-coil 3 fault
	10	-----		DD faults disabled	Multi-coil 4 fault
Static Control of Drivers:	1	UP		DD faults disabled	Dyn Disable open
	2	DOWN		Head T/R short	Dyn Disable short
	3	DOWN		Body T/R open	Dyn Disable short
	4	DOWN		Body T/R short	Multi-coil 1 open
	5	UP	MC1 drv enable	Spectro T/R open	Multi-coil 2 short
	5	DOWN	MC1 drv disable		
	6	UP	MC2 drv enable	Spectro T/R open	Multi-coil 2 open
	6	DOWN	MC2 drv disable		
T/Rs Disabled:	7	UP	MC3 drv enable	Body Coil 1 open	Multi-coil 3 short
	7	DOWN	MC3 drv disable		
	8	UP	MC3 drv disable	Body Coil 1 short	Multi-coil 3 open
	8	DOWN	MC4 drv disable		
	9	UP	Source Mode	Body Coil 2 open	Multi-coil 4 short
	10	UP			
	9	DOWN	Sink Mode	Body Coil 2 short	Multi-coil 4 open
	10	DOWN			
Pulse Control of Drivers:	1	UP		Head T/R open	Dyn Disable open
	2	DOWN		Head T/R open	Dyn Disable open
	3	UP		Body T/R open	Multi-coil 1 short
	4	DOWN		Body T/R short	Multi-coil 1 open
	5	UP	MC1 drv enable	Spectro T/R open	Multi-coil 2 short
	5	DOWN	MC1 drv disable		
	6	UP	MC2 drv enable	Spectro T/R short	Multi-coil 2 open
	6	DOWN	MC2 drv disable		
	7	UP	MC3 drv enable	Spectro T/R short	Multi-coil 2 open
	7	DOWN	MC3 drv disable		

	8	UP	MC4 drv enable	Body Coil 1 short	Multi-coil 3 open
	8	DOWN	MC4 drv disable		
	9	UP	Source Mode	Body Coil 2 open	Multi-coil 4 short
	10	UP			
	9	DOWN	Sink Mode	Body Coil 2 short	Multi-coil 4 open
	10	DOWN			
PS Override Tests	1	UP		Dock enable	-----
	2	DOWN		PAC 8V	-----
	3	DOWN		PAC 9V	+5V Supply too high
	4	UP			+15V Supply too high
	5	UP	Dock disable	Bore vent	+15V Supply too high
	5	DOWN	Dock enable		
	6	UP	Dock enable	Patient Alignment Light	HV Sense too high
	6	DOWN	PAC 8V		
	7	UP	Bore light enable	Bore light	+5V Supply too low
	7	DOWN	Bore light disable		
	8	UP	PAL enable	-----	+15V Supply too low
	8	DOWN	PAL disable		
	9	UP	Bore vent enable	MCD enable	+15V Supply too low
	9	DOWN	Bore vent disable		
	10	-----		-----	HV sense too low
				Monitor A	Monitor B
Monitor Fault Summary	1	UP		RF without unblank	RF without unblank
	2	UP		+15V Supply fault	+15V supply fault
	3	DOWN		Body Pwr limit fault	Body pwr limit fault
	4	UP		Head Pwr limit fault	Head pwr limit fault
	5	-----		Spectro Pwr limit fault	Spectro pwr limit fault
	6	-----		Duty Cycle fault	Duty cycle fault
	7	-----		RF Pulse Width fault	RF pulse width fault
	8	-----		+15V Supply fault	+15V supply fault
	9	-----		Body Cable fault	Body cable fault
	10	-----		Head/Spectro Cable fault	Head/spectro cable fault
Multi-coil Configuration	1	UP		Head/Spectro Cable fault	-----
	2	DOWN		Multi-coil 2 enable	-----
	3	UP		Multi-coil 3 enable	-----

	4	UP		Multi-coil 4 enable	-----
	5	UP	MC1 enable	-----	-----
	5	DOWN	MC1 disable		
	6	UP	MC2 enable	-----	-----
	6	DOWN	MC2 enable		
	7	UP	MC3 enable	-----	-----
	7	DOWN	MC3 disable		
	8	UP	MC4 enable	-----	-----
	8	DOWN	MC4 disable		
	9	-----		-----	-----
	10	UP, then DOWN	Program	-----	-----
Monitor Type Configuration	1	UP		-----	-----
	2	UP		Monitor A 1.0T	Monitor B 1.0T
	3	UP		-----	-----
	4	UP		Monitor A 1.5T w/EFB	Monitor A 1.5T w/EFB
	5	UP, 6 DOWN=1.0T		-----	-----
	5	UP AND 6 UP=1.5T		-----	-----
	7	-----		-----	-----
	8	-----		-----	-----
	9	-----		-----	-----
	10	UP, then DOWN	Program	-----	-----