

Installing and Deleting Service Tools

Overview

The ONI install and Uninstall tools copy the required service files into the proper directories of the host computer and remove the files after service is complete. On the Optima CD the Install and Uninstall tools are located in the root directory. On the 1.0T Specialty MR CD or the MSK Extreme 1.5T CD the tools are located in ONI Service Documentation\Tools, SW, Drivers, etc.

- **ONISvcToolInstall.exe**
- **ONISvcToolUninstall.exe**

Use **ONISvcToolInstall.exe**, described below to install files on the host computer. When you complete service, use **ONISvcToolUninstall.exe**, also described below, to remove the files.

Required Equipment

- | | |
|---------------------------|---|
| Service Tools Software CD | <ul style="list-style-type: none">• Optima MR430s Service Tool Sw Part number 5000-9311-001• 1.0T Specialty MR Service CD Part number 7000-9300-001• MSK Extreme 1.5T Part number 5000-9300-001 |
|---------------------------|---|

Procedures

Installing Files on the Host Computer

To install service files onto the host computer:

1. Insert the **Service Tools Software CD** in the host computer drive.
2. In Windows Explorer, navigate to **ONISvcToolInstall.exe** on the Service Tools Software CD.
3. Double-click **ONISvcToolInstall.exe**. The program installs the files on the host computer.
4. Exit the system and log back in.
5. Enter **Service Mode**.
6. Enter the service password, **service**

Removing Files From the Host Computer After Service

You must remove the service files from the host computer after you have finished the service procedure. To remove service files:

1. Enter **Service Mode**.
2. Enter the service password, **service**
3. Click **Service Tools** and select **ONISvcToolUninstall.exe** from the drop-down menu. See Figure 1.

The service files are removed from the host computer.

Figure 1: Service Mode

