

Intera 0.5 T		Intera 1.0 T		Intera 1.5 T	
Standard	Omni	Power	Omni	Power	Master

Section 21.1

Options

Contents

21.2.	Service Access.....	BCD 21.2
21.3	Reserved	BCD 21.3
21.4.	Hardcopy option	BCD 21.4
21.5.	Reserved	BCD 21.5
21.6.	Reserved	BCD 21.6
21.7.	Reserved	BCD 21.7
21.8.	Audio option.....	BCD 21.8
21.9.	Reserved	BCD 21.9
21.10.	Reserved.....	BCD 21.10
21.11.	Video Option	BCD 21.11
21.12:	Networking	BCD 21.12
21.13.	Optional Coils.....	BCD 21.13
21.14.	Reserved.....	BCD 21.14
21.15.	Reserved.....	BCD 21.15

Service documentation of some options is not included in this manual but is supplied with the hardware of the option. Store these manuals in this section after you have installed the option.