## Thank you for purchasing my module and supporting the maker community!

Your order number is:#

## Mike P.

## Installation Instructions for the Type-C PD Mod for Lenovo Thinkpad Laptops :

In order to install the module please follow the steps listed below:

- 1. Unplug the laptop from the charger
- 2. Shut down the laptop
- 3. Enter Bios and disable the internal battery (if your laptop has one)
- 4. Remove the external battery
- 5. Remove the back/bottom case
- 6. Disconnect the internal battery (if your laptop has one)
- 7. Remove the old original connector and place the new one in it's place
- 8. Plug back the internal battery (if your laptop has one)
- 9. Place back the bottom/back case and screws
- 10. Plug/Connect the external battery
- 11. Connect power thru type-c connector and power on the laptop.

If you encounter any issue please get in touch with me thru Tindie messenger or at <a href="mikepdiy@gmail.com">mikepdiy@gmail.com</a>

## Important:

- 1) To use this module you have to use a PD charger with 20V output; it will not work with mobile phone chargers or power banks that can not deliver 20V at output. The current output has to be 2.25Amp, 3.25Amp or 4.5Amp (according to the power of the module that you have purchased).
- 2) All the modules are tested in laptops before being sent to you so they will all work out of the box. If you have noticed any damage or you think your module was damaged during shipping, please take 2-3 pictures to highlight the problem and send an email to me at <a href="mikepdiy@gmail.com">mikepdiy@gmail.com</a> and I will assist you further. (very likely by replacing the module unless there is an easy fix that you agree to do and are happy to do it.)
- 3) For any other issues with the modules or questions about their functionality, please email me at <a href="mikepdiy@gmail.com">mikepdiy@gmail.com</a>.

Best Regards, MikeP

Tindie Shop: https://www.tindie.com/stores/mikepdiy/