
Your channels, first.

A live favourites row above New & Trending, with Live moved beside Home.



Home in build 15: saved channel order, live video previews and the revised navigation.

01 Choose favourites

Use the star in Live, or Edit channels on Home, to add and remove channels.

02 Arrange your row

Move favourites left or right in Edit channels. The order is saved for the next launch.

03 See what is on

Each visible card has a muted live preview, channel name and current programme. Select a card to watch.


Navigation, simplified

Home	**Live**	Browse	Saved	Downloads	Settings

Left and Right move through the favourites row. Live is now one position to the right of Home.


A fuller Live schedule.

The grid fills the available screen while date controls, programme information and the live preview stay at the top.



Today's guide shows earlier programmes on the left, live programmes in cyan and upcoming programmes to the right.

Previously aired programmes are now included



01 Keep browsing in view

Channel names stay on the left. Scroll through times and channels without replacing the compact information area.

02 Preview the channel

The selected channel has a live preview in the top-right corner, separate from full-screen playback.

03 Go back in time


Browse earlier broadcasts or change the day. Select a past programme for Watch from start or Check catch-up.

Example: the earlier BBC Two gymnastics broadcast is selected, with Watch from start available. Catch-up still depends on BBC availability.

Stability fix: schedule loading was changed after the Live-tab crash. The guide was checked by opening and reopening Live on Apple TV.

Change channel from the player.

Two Down presses separate normal playback controls from live channel switching.



Native playback controls retain programme information, timeline, subtitles/audio options and a received-quality badge.



Channel mode adds a clear Left / Right hint and the current channel name along the bottom.

1 DOWN

Show playback controls.

2 DOWN AGAIN

Enter channel-switching mode.

3 RIGHT / LEFT

Next channel / previous channel.

4 UP


Return to playback controls.

Channel order: matches the guide, with favourites first in your saved order. Switching wraps from the final channel to the first.

Scope: channel switching applies to live playback. On-demand episodes keep their existing playback controls. Switching channels may briefly buffer.

Downloads, quality and the fork.

Best available streams, a local Downloads library and a public source copy of the customised app.




A past programme opens episode options. The circled down-arrow beside Play starts a download; no completed download is shown here.

Download an episode

Open a programme, select the down-arrow, and keep Beeb open while it downloads. Use Downloads to see progress, cancel, play a saved episode or delete it.

4K where supplied

Playback and downloads prefer the best available source, including 4K where supported and supplied. Actual quality can be HD or lower. Apple TV may clear cached downloads when space is needed.



Source published

github.com/miketeevan/Beeb-public

custom-tv is the default branch, based on v0.8.2. Upstream history and GPL attribution are retained. Build 15 is installed on Apple TV; public source uses neutral signing settings.