

Mikey's Mobile Detailing window decal, hand-cut template. Print at Actual size (100%), not Fit to page. The steps are on page 2.

MIKEY'S
MOBILE DETAILING
425-600-7897
mikeysdetailing.com

This bar has to measure exactly 9 inches. If it doesn't, the letters are off too.

Cutting it by hand

1. Tape page 1 on top of white permanent outdoor vinyl (Oracal 651), on a cutting mat or thick cardboard.
2. With a brand new hobby knife blade, cut along every letter edge, the holes inside letters too: through the paper and the vinyl, not the backing under it. Change the blade when it starts to drag.
3. Lift off the paper and peel away all the vinyl that isn't a letter. Pick out the holes: the O, B, D and A, the 6, 0, 8 and 9, and the e, d, a, g and o in the website. The dots on the i's and the full stop are small, so leave them on the backing.
4. Lay transfer tape over the letters and rub it down hard.
5. Get the glass ready: polish any RainX or sealant off that spot until water sheets off instead of beading, wipe it with rubbing alcohol and let it dry.
6. Put it on: tape it in place with a strip of masking tape across the middle. Flip one half up, peel the backing off that half, cut it away and squeegee that half down from the middle out. Pull the tape and do the other half. Then peel the transfer tape back slowly, flat against itself. Give it a couple of days before it gets washed.