
Przerwania (ISR)
UARTE0: FIFO
RTC1: rtc_evt
GPIOTE: on_button, on_edge (DCF_OUT), on_int1, on_busy
SWI2 (SoftDevice): on_ble_evt, qwr_cb
main.c: pętla główna
main(): app_poll(), potem draw() albo board_sleep()
3. poll_alarm
2. poll_clock
4. poll_dcf
1. poll_uart
5. poll_ble
draw
6. arm_wake
Moduły firmware/src
buzzer
lis3dh
motion_count
alarm
clock
sched_store
dcf77_sync
ble_sched
epd
clock_face
board