

October 2011 analogLib Components

#### © Agilent Technologies, Inc. 2000-2011

5301 Stevens Creek Blvd., Santa Clara, CA 95052 USA No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

#### **Acknowledgments**

Mentor Graphics is a trademark of Mentor Graphics Corporation in the U.S. and other countries. Mentor products and processes are registered trademarks of Mentor Graphics Corporation. \* Calibre is a trademark of Mentor Graphics Corporation in the US and other countries. "Microsoft®, Windows®, MS Windows®, Windows NT®, Windows 2000® and Windows Internet Explorer® are U.S. registered trademarks of Microsoft Corporation. Pentium® is a U.S. registered trademark of Intel Corporation. PostScript® and Acrobat® are trademarks of Adobe Systems Incorporated. UNIX® is a registered trademark of the Open Group. Oracle and Java and registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners. SystemC® is a registered trademark of Open SystemC Initiative, Inc. in the United States and other countries and is used with permission. MATLAB® is a U.S. registered trademark of The Math Works, Inc.. HiSIM2 source code, and all copyrights, trade secrets or other intellectual property rights in and to the source code in its entirety, is owned by Hiroshima University and STARC. FLEXIm is a trademark of Globetrotter Software, Incorporated. Layout Boolean Engine by Klaas Holwerda, v1.7 http://www.xs4all.nl/~kholwerd/bool.html . FreeType Project, Copyright (c) 1996-1999 by David Turner, Robert Wilhelm, and Werner Lemberg. QuestAgent search engine (c) 2000-2002, JObjects. Motif is a trademark of the Open Software Foundation. Netscape is a trademark of Netscape Communications Corporation. Netscape Portable Runtime (NSPR), Copyright (c) 1998-2003 The Mozilla Organization. A copy of the Mozilla Public License is at http://www.mozilla.org/MPL/ . FFTW, The Fastest Fourier Transform in the West, Copyright (c) 1997-1999 Massachusetts Institute of Technology. All rights reserved.

The following third-party libraries are used by the NlogN Momentum solver:

"This program includes Metis 4.0, Copyright © 1998, Regents of the University of Minnesota", <a href="http://www.cs.umn.edu/~metis">http://www.cs.umn.edu/~metis</a>, METIS was written by George Karypis (karypis@cs.umn.edu).

Intel@ Math Kernel Library, http://www.intel.com/software/products/mkl

SuperLU\_MT version 2.0 - Copyright © 2003, The Regents of the University of California, through Lawrence Berkeley National Laboratory (subject to receipt of any required approvals from U.S. Dept. of Energy). All rights reserved. SuperLU Disclaimer: THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF

SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

7-zip - 7-Zip Copyright: Copyright (C) 1999-2009 Igor Pavlov. Licenses for files are: 7z.dll: GNU LGPL + unRAR restriction, All other files: GNU LGPL. 7-zip License: This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version. This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details. You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA. unRAR copyright: The decompression engine for RAR archives was developed using source code of unRAR program. All copyrights to original unRAR code are owned by Alexander Roshal. unRAR License: The unRAR sources cannot be used to re-create the RAR compression algorithm, which is proprietary. Distribution of modified unRAR sources in separate form or as a part of other software is permitted, provided that it is clearly stated in the documentation and source comments that the code may not be used to develop a RAR (WinRAR) compatible archiver. 7-zip Availability: http://www.7-zip.org/

AMD Version 2.2 - AMD Notice: The AMD code was modified. Used by permission. AMD copyright: AMD Version 2.2, Copyright © 2007 by Timothy A. Davis, Patrick R. Amestoy, and Iain S. Duff. All Rights Reserved. AMD License: Your use or distribution of AMD or any modified version of AMD implies that you agree to this License. This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version. This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details. You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA Permission is hereby granted to use or copy this program under the terms of the GNU LGPL, provided that the Copyright, this License, and the Availability of the original version is retained on all copies. User documentation of any code that uses this code or any modified version of this code must cite the Copyright, this License, the Availability note, and "Used by permission." Permission to modify the code and to distribute modified code is granted, provided the Copyright, this License, and the Availability note are retained, and a notice that the code was modified is included. AMD Availability: http://www.cise.ufl.edu/research/sparse/amd

UMFPACK 5.0.2 - UMFPACK Notice: The UMFPACK code was modified. Used by permission. UMFPACK Copyright: UMFPACK Copyright © 1995-2006 by Timothy A. Davis. All Rights Reserved. UMFPACK License: Your use or distribution of UMFPACK or any modified version of UMFPACK implies that you agree to this License. This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License

#### analogLib Components

as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version. This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details. You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA Permission is hereby granted to use or copy this program under the terms of the GNU LGPL, provided that the Copyright, this License, and the Availability of the original version is retained on all copies. User documentation of any code that uses this code or any modified version of this code must cite the Copyright, this License, the Availability note, and "Used by permission." Permission to modify the code and to distribute modified code is granted, provided the Copyright, this License, and the Availability note are retained, and a notice that the code was modified is included. UMFPACK Availability: http://www.cise.ufl.edu/research/sparse/umfpack UMFPACK (including versions 2.2.1 and earlier, in FORTRAN) is available at http://www.cise.ufl.edu/research/sparse . MA38 is available in the Harwell Subroutine Library. This version of UMFPACK includes a modified form of COLAMD Version 2.0, originally released on Jan. 31, 2000, also available at http://www.cise.ufl.edu/research/sparse. COLAMD V2.0 is also incorporated as a built-in function in MATLAB version 6.1, by The MathWorks, Inc. http://www.mathworks.com . COLAMD V1.0 appears as a column-preordering in SuperLU (SuperLU is available at http://www.netlib.org ). UMFPACK v4.0 is a built-in routine in MATLAB 6.5. UMFPACK v4.3 is a built-in routine in MATLAB 7.1.

Qt Version 4.6.3 - Qt Notice: The Qt code was modified. Used by permission. Qt copyright: Qt Version 4.6.3, Copyright (c) 2010 by Nokia Corporation. All Rights Reserved. Qt License: Your use or distribution of Qt or any modified version of Qt implies that you agree to this License. This library is free software; you can redistribute it and/or modify it under the

terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version. This library is distributed in the hope that it will be useful,

but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details. You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA Permission is hereby granted to use or copy this program under the terms of the GNU LGPL, provided that the Copyright, this License, and the Availability of the original version is retained on all copies.User

documentation of any code that uses this code or any modified version of this code must cite the Copyright, this License, the Availability note, and "Used by permission."

Permission to modify the code and to distribute modified code is granted, provided the

Permission to modify the code and to distribute modified code is granted, provided the Copyright, this License, and the Availability note are retained, and a notice that the code was modified is included. Qt Availability: <a href="http://www.qtsoftware.com/downloads">http://www.qtsoftware.com/downloads</a> Patches Applied to Qt can be found in the installation at:

\$HPEESOF\_DIR/prod/licenses/thirdparty/qt/patches. You may also contact Brian Buchanan at Agilent Inc. at brian\_buchanan@agilent.com for more information.

The HiSIM\_HV source code, and all copyrights, trade secrets or other intellectual property rights in and to the source code, is owned by Hiroshima University and/or STARC.

**Errata** The ADS product may contain references to "HP" or "HPEESOF" such as in file names and directory names. The business entity formerly known as "HP EEsof" is now part of Agilent Technologies and is known as "Agilent EEsof". To avoid broken functionality and to maintain backward compatibility for our customers, we did not change all the names and labels that contain "HP" or "HPEESOF" references.

**Warranty** The material contained in this document is provided "as is", and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this documentation and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

**Technology Licenses** The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license. Portions of this product include the SystemC software licensed under Open Source terms, which are available for download at <a href="http://systemc.org/">http://systemc.org/</a>. This software is redistributed by Agilent. The Contributors of the SystemC software provide this software "as is" and offer no warranty of any kind, express or implied, including without limitation warranties or conditions or title and non-infringement, and implied warranties or conditions merchantability and fitness for a particular purpose. Contributors shall not be liable for any damages of any kind including without limitation direct, indirect, special, incidental and consequential damages, such as lost profits. Any provisions that differ from this disclaimer are offered by Agilent only.

**Restricted Rights Legend** U.S. Government Restricted Rights. Software and technical data rights granted to the federal government include only those rights customarily provided to end user customers. Agilent provides this customary commercial license in Software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

#### analogLib Components

Introduction to analogLib	8
Active Components	9
diode (analoglib)	10
nbsim	11
nbsim4	12
njfetnjet	13
nmes	14
nmos	15
nmos4	16
npn	17
pbsim	18
pbsim4	19
pdiode	20
pjfet	21
pmos	22
pmos4	23
pnp	24
schottky	25
zener	26
Analysis Components	27
iprobe	28
Parasitics	29
pcapacitor	30
pdiode (Parasitics)	32
pinductor	33
presistor	35
Passive Components	36
cap	37
delay (analoglib)	39
ind	
mind	41
res (analoglib)	
tline	41
xfmr	45
Sources (analoglib)	46
CCCS	49
	51
cccs4	52
CCVS	54
ccvs4	55
	57
iexp	5 <i>7</i>
ipulse	
ipwl	62
isin	66
isource	68
n1port	73
n2port	74 75
n3port	75
n4port	76
pcccs	77
U	

#### analogLib Components

pccvs																																					
pdc .																																					
pexp																																					
port .																																					
ppulse	9																											 	 								90
ppwl																												 	 								92
psin .																												 	 								96
pvccs																												 	 								98
pvcvs																												 	 								99
vccs .																												 	 							1	.02
vcvs .																																					
vdc .																												 	 							1	.06
vexp																												 	 							1	.07
vpulse																																					
vpwl																												 	 							1	.11
vsin .																												 	 							1	.16
venur	~	_																																		1	18

### Introduction to analogLib

RFIC Dynamic Link comes with a modified version of Cadence's analogLib. This documentation describes the components in the modified version of analogLib that are supported by RFIC Dynamic Link.

The Agilent Technologies version of analogLib enables you to use an ADS Analog RF Simulator ( *ADSsim* ) native netlist format instead of the Cadence Spectre Simulator netlist format.

To use the ADSsim netlist format instead of the Spectre netlist format, modify your *cds.lib* file to point to the modified analogLib which is located under

\$HPEESOF\_DIR/cdslibs/5.1.0/analogLib

which only works with Cadence IC 5.1.41 (CDBA version)

If you want to use the analogLib that is provided by Cadence under

\$CDSHOME/tools/dfII/etc/cdslibs/artist

you must be setup to netlist in *Spectre-Compatible* mode. For more information on *Spectre-Compatible* mode, refer to the *Spectre-Compatible Process Design Kits* documentation in the RF Design Environment documentation set. If you do not already have local access to RFDE documentation, you can access this information from the Agilent EEsof EDA Product Documentation Web site at <a href="http://www.agilent.com/find/eesof-docs/">http://www.agilent.com/find/eesof-docs/</a>

### **Active Components**

This section includes information on the following analogLib components:


- diode (analoglib) (anloglib)
- nbsim (anloglib)
- nbsim4 (anloglib)
- njfet (anloglib)
- nmes (anloglib)
- nmos (anloglib)
- nmos4 (anloglib)
- npn (anloglib)
- pbsim (anloglib)
- pbsim4 (anloglib)
- pdiode (anloglib)
- pjfet (anloglib)
- pmos (anloglib)
- pmos4 (anloglib)
- pnp (anloglib)
- schottky (anloglib)
- zener (anloglib)

# diode (analoglib)




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
region	Estimated operating region		cyclic
isnoisy	Generate noise?		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
scale	Scale factor		string
perim	Junction perimeter factor		string
I	Length		string
w	Width		string
off	Device initially off		boolean
Vd	Initial diode voltage		string
pj	Periphery of junction		string
wp	Width of polysilicon		string
lp	Length of polysilicon		string
wm	Width of metal capacitor		string
lm	Length of metal capacitor		string
dtemp	Temperature difference		string

#### nbsim




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
bn	Bulk node connection	S	string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

#### nbsim4




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

## njfet




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
region	Estimated operating region		cyclic
dtemp	Temperature difference		string
m	Multiplier		string
bn	Bulk node connection		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vgbs	Gate to bulk and src voltage		string
W	Width		string
I	Length		string

#### nmes




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
dtemp	Temperature difference		string
m	Multiplier		string
bn	Bulk node connection		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
w	Width		string
I	Length		string
region	Estimated operating region		cyclic

#### nmos




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
bn	Bulk node connection	S	string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

#### nmos4




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

#### npn




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
isnoisy	Generate noise?		cyclic
m	Multiplier		string
bn	Bulk node connection		string
Vbe	Base-emitter voltage		string
Vce	Collector-emitter voltage		string
off	Device initially off		boolean
dtemp	Temperature difference		string
areab	Base area		string
areac	Collector area		string

## pbsim




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
W	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
bn	Bulk node connection	S	string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

### pbsim4




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

## pdiode




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
pj	Periphery of junction		string
wp	Width of polysilicon		string
lp	length of polysilicon		string
wm	Width of metal capacitor		string
lm	Length of metal capacitor		string
I	Length		string
W	Width		string
off	Device initially off		boolean
Vd	Initial diode voltage		string
m	Multiplier		string
dtemp	Temperature difference		string
perim	Junction perimeter factor		string
scale	Scale factor		string
trise	Temp rise form ambient		string
region	Estimated operation region		cyclic - on, off

# pjfet




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
region	Estimated operating region		cyclic
dtemp	Temperature difference		string
m	Multiplier		string
bn	Bulk node connection		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vgbs	Gate to bulk and src voltage		string
w	Width		string
I	Length		string

#### pmos




Name	Description	<b>Default Value</b>	Туре
model	Model name		string
l	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
bn	Bulk node connection	S	string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

#### pmos4



Name	Description	<b>Default Value</b>	Туре
model	Model name		string
I	Length		string
w	Width		string
ad	Drain diffusion area		string
as	Source diffusion area		string
pd	Drain diffusion periphery		string
ps	Source diffusion periphery		string
nrd	Drain diffusion res squares		string
nrs	Source diffusion res squares		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
ld	Drain diffusion length		string
ls	Source diffusion length		string
off	Device initially off		boolean
Vds	Drain source initial voltage		string
Vgs	Gate source initial voltage		string
Vbs	Bulk source initial voltage		string
rdc	Additional drain resistance		string
rsc	Additional source resistance		string
dtemp	Temperature difference		string
geo	Source/drain selector		string

#### pnp



Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
region	Estimated operating region		cyclic
trise	Temp rise from ambient		string
isnoisy	Generate noise?		cyclic
m	Multiplier		string
bn	Bulk node connection		string
Vbe	Base-emitter voltage		string
Vce	Collector-emitter voltage		string
off	Device initially off		boolean
dtemp	Temperature difference		string
areab	Base area		string
areac	Collector area		string

### schottky



Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
region	Estimated operating region		cyclic
isnoisy	Generate noise?		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
scale	Scale factor		string
perim	Junction perimeter factor		string
I	Length		string
w	Width		string
off	Device initially off		boolean
Vd	Initial diode voltage		string
pj	Periphery of junction		string
wp	Width of polysilicon		string
lp	Length of polysilicon		string
wm	Width of metal capacitor		string
lm	Length of metal capacitor		string
dtemp	Temperature difference		string

#### zener



Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
region	Estimated operating region		cyclic
isnoisy	Generate noise?		cyclic
trise	Temp rise from ambient		string
m	Multiplier		string
scale	Scale factor		string
perim	Junction perimeter factor		string
I	Length		string
w	Width		string
off	Device initially off		boolean
Vd	Initial diode voltage		string
pj	Periphery of junction		string
wp	Width of polysilicon		string
lp	Length of polysilicon		string
wm	Width of metal capacitor		string
lm	Length of metal capacitor		string
dtemp	Temperature difference		string

# **Analysis Components**

This section includes information on the following analogLib component:

• iprobe (anloglib)

### iprobe





This component does not have parameters.

### **Parasitics**

This section includes information on the following analogLib components:


- pcapacitor (anloglib)
- pdiode (Parasitics) (anloglib)
- pinductor (anloglib)
- presistor (anloglib)

## pcapacitor




Name	Description	Default Value	Туре
wBV	Breakdown Voltage (V)		string
С	Capacitance	1p	string
trise	Temp rise from ambient		string
tnom	Nominal temperature		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
ic	Initial condition		string
m	Multiplier		string
model	Model name		string
w	Width		string
I	Length		string
scale	Scale factor		string
dtemp	Temperature difference		string
polyCoef	Number of Polynomial Coeffs	0	int
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
c3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
c8	Poly Coeff 8		string
c9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string

# pdiode (Parasitics)



Name	Description	<b>Default Value</b>	Туре
model	Model name		string
area	Device area		string
pj	Periphery of junction		string
wp	Width of polysilicon		string
lp	length of polysilicon		string
wm	Width of metal capacitor		string
lm	Length of metal capacitor		string
I	Length		string
W	Width		string
off	Device initially off		boolean
Vd	Initial diode voltage		string
m	Multiplier		string
dtemp	Temperature difference		string
perim	Junction perimeter factor		string
scale	Scale factor		string
trise	Temp rise form ambient		string
region	Estimated operation region		cyclic - on, off

## pinductor



analogLib Components

Name	Description	<b>Default Value</b>	Туре
model	Model name		
I	Inductance	1n	string
r	Resistance	1k	string
tc1	Temperature coefficent 1		string
tc2	Temperature coefficent 2		string
scale	Scale factor		string
m	Multiplier		string
dtemp	Temperature difference		string
trise	Temp rise from ambient		string
ic	Initial condition		string
polyCoef	Max Coefficent Number	4	int
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
c3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
c8	Poly Coeff 8		string
c9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string

## presistor



Name	Description	<b>Default Value</b>	Туре
wPmax	Max Power dissipation (W)		string
wImax	Max Current (A/m)		string
model	Model name		string
r	Resistance	1K	string
trise	Temp rise from ambient		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
w	Width		string
I	Length		string
isnoisy	Generate noise?		cyclic
m	Multiplier		string
scale	Scale factor		string
С	Capacitance	0	string
ac	AC resistance		string
dtemp	Temperature difference		string
hrc	Capacitance connected		string
resform	Resistance Form		string

# **Passive Components**

This section includes information on the following analogLib components:

- cap (anloglib)
- delay (analoglib) (anloglib)
- ind (anloglib)
- mind (anloglib)
- res (analoglib) (anloglib)
- tline (anloglib)
- xfmr (anloglib)

### cap



Name	Description	<b>Default Value</b>	Туре
wBV	Breakdown Voltage (V)		string
С	Capacitance	1p	string
trise	Temp rise from ambient		string
tnom	Nominal temperature		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
ic	Initial condition		string
m	Multiplier		string
model	Model name		string
w	Width		string
I	Length		string
scale	Scale factor		string
dtemp	Temperature difference		string
polyCoef	Number of Polynomial Coeffs	0	int
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
с3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
c8	Poly Coeff 8		string
с9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string

# delay (analoglib)



Name	Description	<b>Default Value</b>	Туре
gain	Gain	1.0	string
td	Delay time		string
m	Multiplier		string

# ind



Name	Description	Default Value	Туре
I	Inductance	1n	string
r	Resistance		string
trise	Temp rise from ambient		string
tnom	Nominal temperature		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
ic	Initial condition		string
isnoisy	Generate noise?		cyclic
m	Multiplier		string
model	Model name		string
scale	Scale factor		string
dtemp	Temperature difference		string
polyCoef	Number of Polynomial Coeffs	0	int
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
c3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
с8	Poly Coeff 8		string
с9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string

## mind




Name	Description	<b>Default Value</b>	Туре
k	Coupling coefficient	0	string
ind1	First coupled inductor		string
ind2	Second coupled inductor		string

# res (analoglib)




Name	Description	<b>Default Value</b>	Туре
wPmax	Max Power dissipation (W)		string
wImax	Max Current (A/m)		string
model	Model name		string
r	Resistance	1K	string
trise	Temp rise from ambient		string
tnom	Nominal temperature		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
w	Width		string
I	Length		string
isnoisy	Generate noise?		cyclic
m	Multiplier		string
scale	Scale factor		string
ac	AC resistance		string
dtemp	Temperature difference		string
hrc	Capacitance connected		string
resform	Resistance Form		string

# tline



Name	Description	<b>Default Value</b>	Туре
ZO	Characteristic impedance	50	string
I	Length		string
vel	Propagation velocity normalized to c		string
sloss	Series Loss per meter	0	string
freq	Frequency		string
ploss	Shunt Loss per meter	0	string
model	Model name		string
td	Delay time		string
nl	Normalized length	0.25	string
len	Physical length		string
m	Multiplier		string
v1	Voltage 1	0.0	string
i1	Current 1	0.0	string
v2	Voltage 2	0.0	string
i2	Current 2	0.0	string

## xfmr



Name	Description	Default Value	Туре
n1	Number of turns on primary		string
n2	Num of turns on secondary		string
_dummy000	Turn ratio (ADS t )	iPar(\n1\\)/iPar(\n2 )	string
k	Coupling coefficient	0	string
pi	Primary inductor		string
si	Secondary inductor		string

# Sources (analoglib)

This section includes information on the following analogLib components:

- cccs (anloglib)
- cccs4 (anloglib)
- ccvs (anloglib)
- ccvs4 (anloglib)
- idc (anloglib)
- iexp (anloglib)
- ipulse (anloglib)
- ipwl (anloglib)
- isin (anloglib)
- isource (anloglib)
- *n1port* (anloglib)
- n2port (anloglib)
- n3port (anloglib)
- n4port (anloglib)
- pcccs (anloglib)
- pccvs (anloglib)
- pdc (anloglib)
- pexp (anloglib)
- port (anloglib)
- ppulse (anloglib)
- ppwl (anloglib)
- psin (anloglib)
- pvccs (anloglib)
- pvcvs (anloglib)
- vccs (anloglib)
- vcvs (anloglib)
- vdc (anloglib)
- vexp (anloglib)
- vpulse (anloglib)
- vpwl (anloglib)
- vsin (anloglib)
- vsource (anloglib)

**Source Types** 

Name of Source	Name of Source Type of Source		
	Dependent	Independent	Port
cccs	x		
cccs4	x		
ccvs	x		
ccvs4	x		
idc		x	
iexp		x	
ipulse		x	
ipwl		x	
isin		×	
isource		x	
n1port			x
n2port			x
n3port			x
n4port			x
oscport			x
pcccs	x		
pccvs	x		
pdc		×	x
pexp		×	x
port		×	x
ppulse		×	x
ppwl		×	x
psin		×	x
pvccs	x		
pvcvs	x		
vccs	x		
vcvs	x		
vdc		x	
vexp		x	
vpulse		x	
vpwl		×	
vsin		×	
vsource		x	

### **Using S-parameter File Devices from analogLib**

Cadence provides four S-parameter file components in the analogLib library:

- *n1port* (anloglib)
- *n2port* (anloglib)
- n3port (anloglib)
- *n4port* (anloglib)

Spectre and ADSsim simulators do not use the same format for S-parameter files. However, there is a single parameter that is used to designate the S-parameter file name for both simulators. While you can use a full path name in the file parameter, it is recommended that you input the file name without a path, and then set up paths for Spectre and ADSsim that will point to different directories where the files with the proper format can be found.

With Spectre and with ADSsim, the search path for the S-parameter files is the same as the search path for the model files. It is set up from the Analog Circuit Design Environment window by using the **Setup > Simulation Files** menu. Set the *Include Path* to either an absolute or relative path. If the path is set to be relative, it is relative to the directory that Cadence is started from. You may enter multiple paths in the *Include Path* and they should be separated by a space character.

If you have a design kit that contains the S-parameter files, it might be convenient to add a search path that does not need to be set by the user. To do this, you can add the configuration variable USER\_SIM\_FILE\_PATH to your hpeesofsim.cfg file (this can be in \$HPEESOF\_DIR/config, \$HPEESOF\_DIR/custom/config, or \$HOME/hpeesof/config). By default (the \$HPEESOF\_DIR/config/hpeesofsim.cfg file), the data file search path is ...../data:./cell. Each of the above directories is searched and if the USER\_SIM\_FILE\_PATH variable is found, it takes precedence over the previous value. Each path must be delimited with a colon character. It is recommended that you keep ...../data:./cell in the path for compatibility. If you use a relative path, it is relative to your simulation/ <cellName> /ADSsim/schematic/netlist directory which is different than in the Include Path above. These paths are added to the simulator search path after the Include Path described above.

If you are using RFIC Dynamic Link, you can only use the USER\_SIM\_FILE\_PATH method to control the search path.

Cadence provides a utility program that can translate Cadence spectre S-parameter files to ADS touchstone S-parameter files. The program is called sptr (S-parameter translation). With no options specified, it will convert a spectre format file to an ADS file (e.g., sptr spar.s2p sparads.s2p). The program can also convert ADS format files to Cadence format. The program is in the same directory as the spectre executable, and should install with the spectre package.

### CCCS



Name	Description	<b>Default Value</b>	Туре
fgain	Current gain	1.0	string
m	Multiplier		string
ic	Initial condition		string
csType	Туре	linear	cyclic
hfgain	Current gain	1.0	string
maxi	Maximum output current		string
mini	Minimum output current		string
scale	Scale factor		string
hm	Multiplier	1	string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
habs	Absolute value		string
hic	Initial condition		string
delta	Delta		string
htd	Delay time		string
xypairs	Number of controlling pairs	2	int
x1	Controlling Volt 1		string
x2	Controlling Volt 2		string
x3	Controlling Volt 3		string
x4	Controlling Volt 4		string
x5	Controlling Volt 5		string
x6	Controlling Volt 6		string
x7	Controlling Volt 7		string
x8	Controlling Volt 8		string
x9	Controlling Volt 9		string
x10	Controlling Volt 10		string
x11	Controlling Volt 11		string
x12	Controlling Volt 12		string
x13	Controlling Volt 13		string
x14	Controlling Volt 14		string
x15	Controlling Volt 15		string
x16	Controlling Volt 16		string
x17	Controlling Volt 17		string
x18	Controlling Volt 18		string

x20	Controlling Volt 20	string
y1	Corresp Element 1	string
y2	Corresp Element 2	string
у3	Corresp Element 3	string
y4	Corresp Element 4	string
у5	Corresp Element 5	string
у6	Corresp Element 6	string
у7	Corresp Element 7	string
y8	Corresp Element 8	string
у9	Corresp Element 9	string
y10	Corresp Element 10	string
y11	Corresp Element 11	string
y12	Corresp Element 12	string
y13	Corresp Element 13	string
y14	Corresp Element 14	string
y15	Corresp Element 15	string
y16	Corresp Element 16	string
y17	Corresp Element 17	string
y18	Corresp Element 18	string
y20	Corresp Element 20	string

### cccs4



Name	Description	<b>Default Value</b>	Туре
fgain	Current gain	1.0	string
td	Delay time		string
r1	Input resistance		string
r2	Output resistance		string
f3db	3dB frequency		string

### **CCVS**



Name	Description	<b>Default Value</b>	Туре
hgain	Transresistance	1.0	string
vref	Name of voltage source		string
ic	Initial condition		string
csType	Туре	linear	cyclic
hhgain	Transresistance	1.0	string
maxv	Maximum output voltage		string
minv	Minimum output voltage		string
scale	Scale factor		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
habs	Absolute value		string
hic	Initial condition		string
delta	Delta		string
htd	Delay time		string
xypairs	Number of controlling pairs	2	int
x1	Controlling Volt 1		string
x2	Controlling Volt 2		string
x3	Controlling Volt 3		string
x4	Controlling Volt 4		string
x5	Controlling Volt 5		string
х6	Controlling Volt 6		string
x7	Controlling Volt 7		string
x8	Controlling Volt 8		string
x9	Controlling Volt 9		string
x10	Controlling Volt 10		string
x11	Controlling Volt 11		string
x12	Controlling Volt 12		string
x13	Controlling Volt 13		string
x14	Controlling Volt 14		string
x15	Controlling Volt 15		string
x16	Controlling Volt 16		string
x17	Controlling Volt 17		string
x18	Controlling Volt 18		string

y1	Corresp Element 1	string
y2	Corresp Element 2	string
у3	Corresp Element 3	string
y4	Corresp Element 4	string
у5	Corresp Element 5	string
у6	Corresp Element 6	string
у7	Corresp Element 7	string
у8	Corresp Element 8	string
у9	Corresp Element 9	string
y10	Corresp Element 10	string
y11	Corresp Element 11	string
y12	Corresp Element 12	string
y13	Corresp Element 13	string
y14	Corresp Element 14	string
y15	Corresp Element 15	string
y16	Corresp Element 16	string
y17	Corresp Element 17	string
y18	Corresp Element 18	string
y20	Corresp Element 20	string

### ccvs4



Name	Description	<b>Default Value</b>	Туре
hgain	Transresistance	1.0	string
td	Delay time		string
r1	Input resistance		string
r2	Output resistance		string
f3db	3dB frequency		string

# idc



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	dc	string
idc	DC current		string
acm	AC magnitude		string
аср	AC phase		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
m	Multiplier		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string

# iexp



Name	Description	Default Value	Туре
srcType	Source type	exp	string
i1	Current 1	0.0	string
i2	Current 2	0.0	string
idc	DC current		string
td1	Delay time 1		string
td2	Delay time 2		string
tau1	Damping factor 1		string
tau2	Damping factor 2		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
acm	AC magnitude		string
аср	AC phase		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string
m	Multiplier		string
td	Delay time		string
dc	DC source		string

# ipulse



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	pulse	string
i1	Current 1	0.0	string
i2	Current 2	0.0	string
idc	DC current		string
per	Period		string
td	Delay time		string
tr	Rise time		string
tf	Fall time		string
pw	Pulse width		string
acm	AC magnitude		string
аср	AC phase		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
fundname	Frequency name for 1/period		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string

N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string
m	Multiplier	string
dc	DC source	string

# ipwl



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	pwl	string
idc	DC current		string
acm	AC magnitude		string
аср	AC phase		string
tvpairs	Number of pairs of points	2	int
td	Delay time		string
io	Offset current		string
scale	Scale factor		string
stretch	Time scale factor		string
pwlperiod	Period of the PWL		string
twidth	Transition width		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
sinephase	Initial phase for Sinusoid		string
sinephase2	Initial phase for Sinusoid 2		string
t1	Time 1		string
i1	Current 1	0.0	string
t2	Time 2		string
i2	Current 2	0.0	string
t3	Time 3		string
i3	Current 3	0.0	string
t4	Time 4		string
i4	Current 4	0.0	string
t5	Time 5		string
i5	Current 5	0.0	string
t6	Time 6		string
i6	Current 6	0.0	string
t7	Time 7		string
i7	Current 7	0.0	string
t8	Time 8		string
i8	Current 8	0.0	string
t9	Time 9		string
i9	Current 9	0.0	string

t10	Time 10		string
i10	Current 10	0.0	string
t11	Time 11		string
i11	Current 11	0.0	string
t12	Time 12		string
i12	Current 12	0.0	string
t13	Time 13		string
i13	Current 13	0.0	string
t14	Time 14		string
i14	Current 14	0.0	string
t15	Time 15		string
i15	Current 15	0.0	string
t16	Time 16		string
i16	Current 16	0.0	string
t17	Time 17		string
i17	Current 17	0.0	string
t18	Time 18		string
i18	Current 18	0.0	string
t19	Time 19		string
i19	Current 19	0.0	string
t20	Time 20		string
i20	Current 20	0.0	string
t21	Time 21		string
i21	Current 21	0.0	string
t22	Time 22		string
i22	Current 22	0.0	string
t23	Time 23		string
i23	Current 23	0.0	string
t24	Time 24		string
i24	Current 24	0.0	string
t25	Time 25		string
i25	Current 25	0.0	string
t26	Time 26		string
i26	Current 26	0.0	string
t27	Time 27		string
i27	Current 27	0.0	string
t28	Time 28		string
i28	Current 28	0.0	string
t29	Time 29		string
i29	Current 29	0.0	string
t30	Time 30		string
i30	Current 30	0.0	string
t31	Time 31		string

		anaiogLio	Components
i31	Current 31	0.0	string
t32	Time 32		string
i32	Current 32	0.0	string
t33	Time 33		string
i33	Current 33	0.0	string
t34	Time 34		string
i34	Current 34	0.0	string
t35	Time 35		string
i35	Current 35	0.0	string
t36	Time 36		string
i36	Current 36	0.0	string
t37	Time 37		string
i37	Current 37	0.0	string
t38	Time 38		string
i38	Current 38	0.0	string
t39	Time 39		string
i39	Current 39	0.0	string
t40	Time 40		string
i40	Current 40	0.0	string
t41	Time 41		string
i41	Current 41	0.0	string
t42	Time 42		string
i42	Current 42	0.0	string
t43	Time 43		string
i43	Current 43	0.0	string
t44	Time 44		string
i44	Current 44	0.0	string
t45	Time 45		string
i45	Current 45	0.0	string
t46	Time 46		string
i46	Current 46	0.0	string
t47	Time 47		string
i47	Current 47	0.0	string
t48	Time 48		string
i48	Current 48	0.0	string
t49	Time 49		string
i49	Current 49	0.0	string
t50	Time 50		string
i50	Current 50	0.0	string
fundname	Frequency name for 1/period		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string

		analogLib Components
N1	Noise 1	string
F2	Freq 2	string
N2	Noise 2	string
F3	Freq 3	string
N3	Noise 3	string
F4	Freq 4	string
N4	Noise 4	string
F5	Freq 5	string
N5	Noise 5	string
F6	Freq 6	string
N6	Noise 6	string
F7	Freq 7	string
N7	Noise 7	string
F8	Freq 8	string
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string
m	Multiplier	string
dc	DC source	string
rpt	Repeated function	string

# isin



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	sine	string
acm	AC magnitude		string
аср	AC phase		string
idc	DC current		string
ia	Amplitude		string
ia2	Amplitude 2		string
freq	Frequency		string
freq2	Frequency 2		string
td	Delay time		string
theta	Damping factor		string
phi	Phase delay		string
io	Offset current		string
fmmodindex	FM modulation index		string
fmmodfreq	FM modulation frequency		string
ammodindex	AM modulation index		string
ammodfreq	AM modulation frequency		string
ammodphase	AM modulation phase		string
sinephase	Initial phase for Sinusoid		string
sinephase2	Initial phase for Sinusoid 2		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
fundname	First frequency name		string
fundname2	Second frequency name		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string

		analogLib Components
N4	Noise 4	string
F5	Freq 5	string
N5	Noise 5	string
F6	Freq 6	string
N6	Noise 6	string
F7	Freq 7	string
N7	Noise 7	string
F8	Freq 8	string
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string

Multiplier

DC source

Noise temperature

m

dc

noisetemp

string

string

string

# isource



Name	Description	<b>Default Value</b>	Туре
pwlEntryMethod	Waveform Entry Method	File	radio
numofsines	Display second sinusoid		boolean
modulation	Display modulation params		boolean
srcType	Source type	sine	cyclic
ia	Amplitude 1 (Ipk)		string
ia2	Amplitude 2 (Ipk)		string
freq	Frequency 1		string
freq2	Frequency 2		string
theta	Damping factor 1		string
phi	Phase delay		string
fmmodindex	FM modulation index 1		string
fmmodfreq	FM modulation freq 1		string
ammodindex	AM modulation index 1		string
ammodfreq	AM modulation freq 1		string
ammodphase	AM modulation phase 1		string
i1	Current 1		string
i2	Current 2		string
td1	Rise time start		string
td2	Fall time start		string
tau1	Rise time constant		string
tau2	Fall time constant		string
per	Period of waveform		string
td	Delay time		string
tr	Rise time		string
tf	Fall time		string
pw	Pulse width		string
idc	DC current		string
acm	AC Magnitude		string
аср	AC phase		string
tvpairs	Number of PWL/Time pairs	0	int
io	DC offset current		string
offset	DC offset		string
scale	Amplitude scale factor		string
stretch	Time scale factor		string


pwlperiod	Period	string
twidth	Transition width	string
tc1	Linear temp. coefficient	string
tc2	Quadratic temp. coeff.	string
tnom	Nominal temperature	string
sinephase	Phase for Sinusoid 1	string
sinephase2	Phase for Sinusoid 2	string
sinedc	Sine DC level	string
val0	Zero value	string
val1	One value	string
t1	Time 1	string
t2	Time 2	string
t3	Time 3	string
i3	Current 3	string
t4	Time 4	string
i4	Current 4	string
t5	Time 5	string
i5	Current 5	string
t6	Time 6	string
i6	Current 6	string
t7	Time 7	string
i7	Current 7	string
t8	Time 8	string
i8	Current 8	string
t9	Time 9	string
i9	Current 9	string
t10	Time 10	string
i10	Current 10	string
t11	Time 11	string
i11	Current 11	string
t12	Time 12	string
i12	Current 12	string
t13	Time 13	string
i13	Current 13	string
t14	Time 14	string
i14	Current 14	string
t15	Time 15	string
i15	Current 15	string
t16	Time 16	string
i16	Current 16	string
t17	Time 17	string
i17	Current 17	string
t18	Time 18	string

	an:	analogLib Components	
i18	Current 18	string	
t19	Time 19	string	
i19	Current 19	string	
t20	Time 20	string	
i20	Current 20	string	
t21	Time 21	string	
i21	Current 21	string	
t22	Time 22	string	
i22	Current 22	string	
t23	Time 23	string	
i23	Current 23	string	
t24	Time 24	string	
i24	Current 24	string	
t25	Time 25	string	
i25	Current 25	string	
t26	Time 26	string	
i26	Current 26	string	
t27	Time 27	string	
i27	Current 27	string	
t28	Time 28	string	
i28	Current 28	string	
t29	Time 29	string	
i29	Current 29	string	
t30	Time 30	string	
i30	Current 30	string	
t31	Time 31	string	
i31	Current 31	string	
t32	Time 32	string	
i32	Current 32	string	
t33	Time 33	string	
i33	Current 33	string	
t34	Time 34	string	
i34	Current 34	string	
t35	Time 35	string	
i35	Current 35	string	
t36	Time 36	string	
i36	Current 36	string	
t37	Time 37	string	
i37	Current 37	string	
t38	Time 38	string	
i38	Current 38	string	
t39	Time 39	string	
i39	Current 39	string	

		ilogLib Comj	
t40	Time 40		string
i40	Current 40		string
t41	Time 41		string
i41	Current 41		string
t42	Time 42		string
i42	Current 42		string
t43	Time 43		string
i43	Current 43		string
t44	Time 44		string
i44	Current 44		string
t45	Time 45		string
i45	Current 45		string
t46	Time 46		string
i46	Current 46		string
t47	Time 47		string
i47	Current 47		string
t48	Time 48		string
i48	Current 48		string
t49	Time 49		string
i49	Current 49		string
t50	Time 50		string
i50	Current 50		string
m	Multiplier		string
fundname	Frequency name 1		string
fundname2	Frequency name 2		string
noisefile	Noise file name		string
fileName	File name		string
tempParam	Display temperature params		boolean
smallSig	Display small signal params		boolean
noiseParam	Display noise parameters		boolean
FNpairs	Num. of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string

F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
noiseEntryMethod	Noise Entry Method	File	radio
pacm	PAC Magnitude		string
раср	PAC phase		string
xfm	XF Magnitude		string
noisetemp	Noise temperature		string
allbrkpts	Breakpoints		cyclic

# n1port



Name	Description	<b>Default Value</b>	Туре
dataFile	S-parameter data file		string
romdatfile	ROM data file		string
m	Multiplier		string
scale	Scale factor		string
relerr	Relative error		string
abserr	Absolute error		string
ratorder	Rational order		string
interp	Interpolation method		cyclic

#### **Notes**

## n2port




Name	Description	<b>Default Value</b>	Туре
dataFile	S-parameter data file		string
romdatfile	ROM data file		string
m	Multiplier		string
scale	Scale factor		string
relerr	Relative error		string
abserr	Absolute error		string
ratorder	Rational order		string
interp	Interpolation method		cyclic

## n3port




Name	Description	<b>Default Value</b>	Туре
dataFile	S-parameter data file		string
romdatfile	ROM data file		string
m	Multiplier		string
scale	Scale factor		string
relerr	Relative error		string
abserr	Absolute error		string
ratorder	Rational order		string
interp	Interpolation method		cyclic

## n4port



Name	Description	<b>Default Value</b>	Туре
dataFile	S-parameter data file		string
romdatfile	ROM data file		string
m	Multiplier		string
scale	Scale factor		string
relerr	Relative error		string
abserr	Absolute error		string
ratorder	Rational order		string
interp	Interpolation method		cyclic


## pcccs



Name	Description	<b>Default Value</b>	Туре
gain	Gain	1.0	string
polyCoef	Max Coefficent Number	4	int
с0	Poly Coeff 0		string
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
c3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
c8	Poly Coeff 8		string
c9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string
probeCnt	Number of Probes	4	int
p1	Probe 1		string
p2	Probe 2		string
р3	Probe 3		string
p4	Probe 4		string
p5	Probe 5		string
р6	Probe 6		string
p7	Probe 7		string

p8	Probe 8	string
р9	Probe 9	string
p10	Probe 10	string
p11	Probe 11	string
p12	Probe 12	string
p13	Probe 13	string
p14	Probe 14	string
p15	Probe 15	string
p16	Probe 16	string
p17	Probe 17	string
p18	Probe 18	string
p19	Probe 19	string
p20	Probe 20	string
m	Multiplier	string
tc1	Temperature coefficient 1	string
tc2	Temperature coefficient 2	string

### pccvs



Name	Description	<b>Default Value</b>	Туре
gain	Gain	1.0	string
polyCoef	Max Coefficent Number	4	int
c0	Poly Coeff 0		string
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
с3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
c8	Poly Coeff 8		string
c9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string
probeCnt	Number of Probes	4	int
p1	Probe 1		string
p2	Probe 2		string
р3	Probe 3		string
p4	Probe 4		string
p5	Probe 5		string

p6	Probe 6	string
p7	Probe 7	string
p8	Probe 8	string
р9	Probe 9	string
p10	Probe 10	string
p11	Probe 11	string
p12	Probe 12	string
p13	Probe 13	string
p14	Probe 14	string
p15	Probe 15	string
p16	Probe 16	string
p17	Probe 17	string
p18	Probe 18	string
p19	Probe 19	string
p20	Probe 20	string
m	Multiplier	string
tc1	Temperature coefficient 1	string
tc2	Temperature coefficient 2	string

# pdc



Name	Description	Default Value	Туре
srcType	Source type	dc	string
r	Resistance	50	string
num	Port number		string
vdc	DC voltage		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
acm	AC magnitude		string
аср	AC phase		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
m	Multiplier		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string

### pexp



Name	Description	Default Value	
srcType	Source type	exp	string
r	Resistance	50	string
num	Port number		string
vdc	DC voltage		string
td1	Delay time 1		string
tau1	Damping factor 1		string
td2	Delay time 2		string
tau2	Damping factor 2		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
td	Delay time		string
m	Multiplier		string
acm	AC magnitude		string
аср	AC phase		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string

# port



Name	Description	<b>Default Value</b>	Туре
pwlEntryMethod	Waveform Entry Method	File	radio
numofsines	Display second sinusoid		boolean
modulation	Display modulation params		boolean
srcType	Source type	sine	cyclic
r	Resistance	50	string
num	Port number		string
vdc	DC voltage		string
td	Delay time		string
val0	Zero value		string
val1	One value		string
per	Period of waveform		string
tr	Rise time		string
tf	Fall time		string
pw	Pulse width		string
td1	Rise time start		string
tau1	Rise time constant		string
td2	Fall time start		string
tau2	Fall time constant		string
freq	Frequency 1		string
va	Amplitude 1 (Vpk)		string
vaDBm	Amplitude 1 (dBm)		string
sinephase	Phase for Sinusoid 1		string
sinedc	Sine DC level		string
freq2	Frequency 2		string
va2	Amplitude 2 (Vpk)		string
vaDBm2	Amplitude 2 (dBm)		string
sinephase2	Phase for Sinusoid 2		string
fmmodindex	FM modulation index 1		string
fmmodfreq	FM modulation freq 1		string
ammodindex	AM modulation index 1		string
ammodfreq	AM modulation freq 1		string
ammodphase	AM modulation phase 1		string

lth oto		alogLib Comp	
theta	Damping factor 1		string
tc1	Linear temp. coefficient		string
tc2	Quadratic temp. coeff.		string
tnom	Nominal temperature		string
acm	AC Magnitude		string
аср	AC phase		string
offset	DC offset		string
scale	Amplitude scale factor		string
stretch	Time scale factor		string
pwlperiod	Period		string
twidth	Transition width		string
sourceType	Source type	port	radio
tvpairs	Number of PWL/Time pairs	0	int
t1	Time 1		string
v1	Voltage 1		string
t2	Time 2		string
v2	Voltage 2		string
t3	Time 3		string
v3	Voltage 3		string
t4	Time 4		string
v4	Voltage 4		string
t5	Time 5		string
v5	Voltage 5		string
t6	Time 6		string
v6	Voltage 6		string
t7	Time 7		string
v7	Voltage 7		string
t8	Time 8		string
v8	Voltage 8		string
t9	Time 9		string
v9	Voltage 9		string
t10	Time 10		string
v10	Voltage 10		string
t11	Time 11		string
v11	Voltage 11		string
t12	Time 12		string
v12	Voltage 12		string
t13	Time 13		string
v13	Voltage 13		string
t14	Time 14		string
v14	Voltage 14		string
t15	Time 15		string
v15	Voltage 15		string
• ± 5	voitage 15		Janny

t16	Time 16	alogLib Components
v16	Voltage 16	string
t17	Time 17	string
v17	Voltage 17	string
t18	Time 18	string
v18	Voltage 18	string
t19	Time 19	string
v19	Voltage 19	string
t20	Time 20	string
v20	Voltage 20	string
t21	Time 21	string
v21	Voltage 21	string
t22	Time 22	string
v22	Voltage 22	string
t23	Time 23	string
v23	Voltage 23	string
t24	Time 24	string
v24	Voltage 24	string
t25	Time 25	string
v25	Voltage 25	string
t26	Time 26	string
v26	Voltage 26	string
t27	Time 27	string
v27	Voltage 27	string
t28	Time 28	string
v28	Voltage 28	string
t29	Time 29	string
v29	Voltage 29	string
t30	Time 30	string
v30	Voltage 30	string
t31	Time 31	string
v31	Voltage 31	string
t32	Time 32	string
v32	Voltage 32	string
t33	Time 33	string
v33	Voltage 33	string
t34	Time 34	string
v34	Voltage 34	string
t35	Time 35	string
v35	Voltage 35	string
t36	Time 36	string
v36	Voltage 36	string
t37	Time 37	string

v37	Voltage 37	ilogLib Compon 	string
t38	Time 38		string
v38	Voltage 38		string
t39	Time 39		string
v39	Voltage 39		string
t40	Time 40		string
v40	Voltage 40		string
t41	Time 41		string
v41	Voltage 41		string
t42	Time 42		string
v42	Voltage 42		string
t43	Time 43		string
v43	Voltage 43		string
t44	Time 44		string
v44	Voltage 44		string
t45	Time 45		string
v45	Voltage 45		string
t46	Time 46		string
v46	Voltage 46		string
t47	Time 47		string
v47	Voltage 47		string
t48	Time 48		string
v48	Voltage 48		string
t49	Time 49		string
v49	Voltage 49		string
t50	Time 50		string
v50	Voltage 50		string
fundname	Frequency name 1		string
fundname2	Frequency name 2		string
noisefile	Noise file name		string
fileName	File name		string
tempParam	Display temperature params		boolean
smallSig	Display small signal params		boolean
noiseParam	Display noise parameters		boolean
FNpairs	Num. of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string

F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
noiseEntryMethod	Noise Entry Method	File	radio
pacm	PAC Magnitude		string
pacDBm	PAC Magnitude (dBm)		string
раср	PAC phase		string
xfm	XF Magnitude		string
noisetemp	Noise temperature		string
m	Multiplier		string
allbrkpts	Breakpoints		cyclic

# ppulse



Name	Description	<b>Default Value</b>	Type
srcType	Source type	pulse	string
r	Resistance	50	string
num	Port number		string
vdc	DC voltage		string
td	Delay time		string
v1	Voltage 1	0.0	string
v2	Voltage 2	0.0	string
per	Period		string
tr	Rise time		string
tf	Fall time		string
pw	Pulse width		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
fundname	Frequency name for 1/period		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string

		ununogene component
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
m	Multiplier	string
acm	AC magnitude	string
аср	AC phase	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string

# ppwl



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	pwl	string
r	Resistance	50	string
num	Port number		string
vdc	DC voltage		string
td	Delay time		string
twidth	Transition width		string
pwlperiod	Period of the PWL		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
scale	Scale factor		string
stretch	Time scale factor		string
offset	Offset voltage		string
tvpairs	Number of pairs of points	2	Type int
t1	Time 1		string
v1	Voltage 1	0.0	string
t2	Time 2		string
v2	Voltage 2	0.0	string
t3	Time 3		string
v3	Voltage 3	0.0	string
t4	Time 4		string
v4	Voltage 4	0.0	string
t5	Time 5		string
v5	Voltage 5	0.0	string
t6	Time 6		string
v6	DescriptionVoltage 6	0.0	string
t7	DescriptionTime 7		string
v7	DescriptionVoltage 7	0.0	string
t8	Time 8		string
v8	Voltage 8	0.0	string
t9	Time 9		string
v9	Voltage 9	0.0	string
t10	Time 10		string

v10	Voltago 10	0.0	Lib Components
v10	Voltage 10	0.0	string
t11	Time 11		string
v11	Voltage 11	0.0	string
t12	Time 12		string
v12	Voltage 12	0.0	string
t13	Time 13		string
v13	Voltage 13	0.0	string
t14	Time 14		string
v14	Voltage 14	0.0	string
t15	Time 15		string
v15	Voltage 15	0.0	string
t16	Time 16		string
v16	Voltage 16	0.0	string
t17	Time 17		string
v17	Voltage 17	0.0	string
t18	Time 18		string
v18	Voltage 18	0.0	string
t19	Time 19		string
v19	Voltage 19	0.0	string
t20	Time 20		string
v20	Voltage 20	0.0	string
t21	Time 21		string
v21	Voltage 21	0.0	string
t22	Time 22		string
v22	Voltage 22	0.0	string
t23	Time 23		string
v23	Voltage 23	0.0	string
t24	Time 24		string
v24	Voltage 24	0.0	string
t25	Time 25		string
v25	Voltage 25	0.0	string
t26	Time 26		string
v26	Voltage 26	0.0	string
t27	Time 27		string
v27	Voltage 27	0.0	string
t28	Time 28		string
v28	Voltage 28	0.0	string
t29	Time 29		string
v29	Voltage 29	0.0	string
t30	Time 30		string
v30	Voltage 30	0.0	string
t31	Time 31		string
v31	Voltage 31	0.0	string

	<u> </u>	analogLib Co	
t32	Time 32		string
v32	Voltage 32	0.0	string
t33	Time 33		string
v33	Voltage 33	0.0	string
t34	Time 34		string
v34	Voltage 34	0.0	string
t35	Time 35		string
v35	Voltage 35	0.0	string
t36	Time 36		string
v36	Voltage 36	0.0	string
t37	Time 37		string
v37	Voltage 37	0.0	string
t38	Time 38		string
v38	Voltage 38	0.0	string
t39	Time 39		string
v39	Voltage 39	0.0	string
t40	Time 40		string
v40	Voltage 40	0.0	string
t41	Time 41		string
v41	Voltage 41	0.0	string
t42	Time 42		string
v42	Voltage 42	0.0	string
t43	Time 43		string
v43	Voltage 43	0.0	string
t44	Time 44		string
v44	Voltage 44	0.0	string
t45	Time 45		string
v45	Voltage 45	0.0	string
t46	Time 46		string
v46	Voltage 46	0.0	string
t47	Time 47		string
v47	Voltage 47	0.0	string
t48	Time 48		string
v48	Voltage 48	0.0	string
t49	Time 49		string
v49	Voltage 49	0.0	string
t50	Time 50		string
v50	Voltage 50	0.0	string
fundname	Frequency name for 1/period		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string

analogLib Components

F2	Freq 2	string
N2	Noise 2	string
F3	Freq 3	string
N3	Noise 3	string
F4	Freq 4	string
N4	Noise 4	string
F5	Freq 5	string
N5	Noise 5	string
F6	Freq 6	string
N6	Noise 6	string
F7	Freq 7	string
N7	Noise 7	string
F8	Freq 8	string
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
vo	Offset voltage	string
m	Multiplier	string
acm	AC magnitude	string
аср	AC phase	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string
allbrkpts	All are breakpoints "D	string

# psin




Name	Description	<b>Default Value</b>	Туре
srcType	Source type	sine	string
r	Resistance	50	string
jx	Reactance	0	string
num	Port number		string
vdc	DC voltage		string
td	Delay time		string
freq	Frequency		string
va	Amplitude		string
vaDBm	Amplitude (dBm)		string
sinephase	Initial phase for Sinusoid		string
sinedc	Sine DC level		string
freq2	Frequency 2		string
va2	Amplitude 2		string
vaDBm2	Amplitude 2 (dBm)		string
sinephase2	Initial phase for Sinusoid 2		string
theta	Damping factor		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
acm	AC magnitude		string
аср	AC phase		string
fmmodindex	FM modulation index		string
fmmodfreq	FM modulation frequency		string
ammodindex	AM modulation index		string
ammodfreq	AM modulation frequency		string
ammodphase	AM modulation phase		string
fundname	Frequency name		string
fundname2	Second frequency name		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string

analogLib Components


	11	unurogene components
N2	Noise 2	string
F3	Freq 3	string
N3	Noise 3	string
F4	Freq 4	string
N4	Noise 4	string
F5	Freq 5	string
N5	Noise 5	string
F6	Freq 6	string
N6	Noise 6	string
F7	Freq 7	string
N7	Noise 7	string
F8	Freq 8	string
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
m	Multiplier	string
noisetemp	Noise temperature	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
pacDBm	PAC magnitude (dBm)	string
раср	PAC phase	string

### pvccs



Name	Description	<b>Default Value</b>	Туре
gain	Gain	1.0	string
polyCoef	Max Coefficent Number	4	int
c0	Poly Coeff 0		string
c1	Poly Coeff 1		string
c2	Poly Coeff 2		string
c3	Poly Coeff 3		string
c4	Poly Coeff 4		string
c5	Poly Coeff 5		string
с6	Poly Coeff 6		string
c7	Poly Coeff 7		string
c8	Poly Coeff 8		string
c9	Poly Coeff 9		string
c10	Poly Coeff 10		string
c11	Poly Coeff 11		string
c12	Poly Coeff 12		string
c13	Poly Coeff 13		string
c14	Poly Coeff 14		string
c15	Poly Coeff 15		string
c16	Poly Coeff 16		string
c17	Poly Coeff 17		string
c18	Poly Coeff 18		string
c19	Poly Coeff 19		string
c20	Poly Coeff 20		string
m	Multiplier		string
scale	Scale factor		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
abs	Absolute value		string
ic	Initial condition		string

### pvcvs



analogLib Components

Name	Description	<b>Default Value</b>	Туре
gain	Gain	1.0	string
polyCoef	Max Coefficent Number	4	int
c0	Poly Coeff	0	string
c1	Poly Coeff	1	string
c2	Poly Coeff	2	string
c3	Poly Coeff	3	string
c4	Poly Coeff	4	string
c5	Poly Coeff	5	string
с6	Poly Coeff	6	string
c7	Poly Coeff	7	string
c8	Poly Coeff	8	string
c9	Poly Coeff	9	string
c10	Poly Coeff	10	string
c11	Poly Coeff	11	string
c12	Poly Coeff	12	string
c13	Poly Coeff	13	string
c14	Poly Coeff	14	string
c15	Poly Coeff	15	string
c16	Poly Coeff	16	string
c17	Poly Coeff	17	string
c18	Poly Coeff	18	string
c19	Poly Coeff	19	string
c20	Poly Coeff	20	string
m	Multiplier		string
scale	Scale factor		string
tc1	Temperature coefficient	1	string
tc2	Temperature coefficient	2	string
abs	Absolute value		string
ic	Initial condition		string

### **VCCS**



Name	Description	<b>Default Value</b>	Туре
ggain	Transconductance	1.0	string
td	Delay time		string
r1	Input resistance		string
r2	Output resistance		string
f3db	3dB frequency		string
m	Multiplier		string
ic	Initial condition		string
csType	Туре	linear	cyclic
hggain	Transconductance	1.0	string
maxi	Maximum output current		string
mini	Minimum output current		string
scale	Scale factor		string
hm	Multiplier	1	string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
habs	Absolute value		string
hic	Initial condition		string
pwlType	Pwl type	pwl	cyclic
delta	Delta		string
htd	Delay time		string
xypairs	Number of controlling pairs	2	int
x1	Controlling Volt 1		string
x2	Controlling Volt 2		string
x3	Controlling Volt 3		string
x4	Controlling Volt 4		string
x5	Controlling Volt 5		string
x6	Controlling Volt 6		string
x7	Controlling Volt 7		string
x8	Controlling Volt 8		string
x9	Controlling Volt 9		string
x10	Controlling Volt 10		string
x11	Controlling Volt 11		string
x12	Controlling Volt 12		string
			102

x13	Controlling Volt 13	string
x14	Controlling Volt 14	string
x15	Controlling Volt 15	string
x16	Controlling Volt 16	string
x17	Controlling Volt 17	string
x18	Controlling Volt 18	string
x20	Controlling Volt 20	string
у1	Corresp Element 1	string
y2	Corresp Element 2	string
у3	Corresp Element 3	string
y4	Corresp Element 4	string
у5	Corresp Element 5	string
у6	Corresp Element 6	string
у7	Corresp Element 7	string
у8	Corresp Element 8	string
у9	Corresp Element 9	string
y10	Corresp Element 10	string
y11	Corresp Element 11	string
y12	Corresp Element 12	string
y13	Corresp Element 13	string
y14	Corresp Element 14	string
y15	Corresp Element 15	string
y16	Corresp Element 16	string
y17	Corresp Element 17	string
y18	Corresp Element 18	string
y20	Corresp Element 20	string

### **VCVS**



Name	Description	<b>Default Value</b>	Туре
egain	Voltage gain	1.0	string
td	Delay time		string
f3db	3dB frequency		string
r1	Input resistance		string
r2	Output resistance		string
ic	Initial condition		string
csType	Туре	linear	cyclic
hegain	Voltage gain	1.0	string
maxv	Maximum output voltage		string
minv	Minimum output voltage		string
scale	Scale factor		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
habs	Absolute value		string
hic	Initial condition		string
delta	Delta		string
htd	Delay time		string
xypairs	Number of controlling pairs	2	int
x1	Controlling Volt 1		string
x2	Controlling Volt 2		string
x3	Controlling Volt 3		string
x4	Controlling Volt 4		string
x5	Controlling Volt 5		string
x6	Controlling Volt 6		string
x7	Controlling Volt 7		string
x8	Controlling Volt 8		string
x9	Controlling Volt 9		string
x10	Controlling Volt 10		string
x11	Controlling Volt 11		string
x12	Controlling Volt 12		string
x13	Controlling Volt 13		string
x14	Controlling Volt 14		string
x15	Controlling Volt 15		string

		analogicio Comp
x16	Controlling Volt 16	string
x17	Controlling Volt 17	string
x18	Controlling Volt 18	string
x20	Controlling Volt 20	string
y1	Corresp Element 1	string
y2	Corresp Element 2	string
у3	Corresp Element 3	string
y4	Corresp Element 4	string
у5	Corresp Element 5	string
y6	Corresp Element 6	string
у7	Corresp Element 7	string
y8	Corresp Element 8	string
у9	Corresp Element 9	string
y10	Corresp Element 10	string
y11	Corresp Element 11	string
y12	Corresp Element 12	string
y13	Corresp Element 13	string
y14	Corresp Element 14	string
y15	Corresp Element 15	string
y16	Corresp Element 16	string
y17	Corresp Element 17	string
y18	Corresp Element 18	string
y20	Corresp Element 20	string

# vdc



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	dc	string
vdc	DC voltage		string
acm	AC magnitude		string
аср	AC phase		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string

## vexp



Name	Description	Default Value	
srcType	Source type	exp	string
vdc	DC voltage		string
v1	Voltage 1	0.0	string
v2	Voltage 2	0.0	string
td1	Delay time 1		string
td2	Delay time 2		string
tau1	Damping factor 1		string
tau2	Damping factor 2		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
acm	AC magnitude		string
аср	AC phase		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string
td	Delay time		string
dc	DC source		string

# vpulse



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	pulse	string
v1	Voltage 1	0.0	string
v2	Voltage 2	0.0	string
vdc	DC voltage		string
per	Period		string
td	Delay time		string
tr	Rise time		string
tf	Fall time		string
pw	Pulse width		string
acm	AC magnitude		string
аср	AC phase		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
fundname	Frequency name for 1/period		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string
N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
xfm	XF magnitude		string
pacm	PAC magnitude		string
раср	PAC phase		string
dc	DC source		string

# vpwl



Name	Description	Default Value	Туре
srcType	Source type	pwl	string
vdc	DC voltage		string
acm	AC magnitude		string
аср	AC phase		string
tvpairs	Number of pairs of points	2	int
td	Delay time		string
vo	Offset voltage		string
scale	Scale factor		string
stretch	Time scale factor		string
pwlperiod	Period of the PWL		string
twidth	Transition width		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
t1	Time 1		string
v1	Voltage 1	0.0	string
t2	Time 2		string
v2	Voltage 2	0.0	string
t3	Time 3		string
v3	Voltage 3	0.0	string
t4	Time 4		string
v4	Voltage 4	0.0	string
t5	Time 5		string
v5	Voltage 5	0.0	string
t6	Time 6		string
v6	Voltage 6	0.0	string
t7	Time 7		string
v7	Voltage 7	0.0	string
t8	Time 8		string
v8	Voltage 8	0.0	string
t9	Time 9		string
v9	Voltage 9	0.0	string
t10	Time 10		string
v10	Voltage 10	0.0	string

t11	Time 11	analog	Lib Component string
v11	Voltage 11	0.0	string
t12	Time 12	0.0	string
v12	Voltage 12	0.0	string
t13	Time 13	0.0	string
v13	Voltage 13	0.0	string
t14	Time 14	0.0	string
v14	Voltage 14	0.0	string
t15	Time 15	0.0	string
v15	Voltage 15	0.0	string
t16	Time 16	0.0	string
v16	Voltage 16	0.0	string
t17	Time 17	0.0	string
v17	Voltage 17	0.0	string
t18	Time 18	0.0	string
v18	Voltage 18	0.0	string
t19	Time 19	0.0	string
v19	Voltage 19	0.0	string
t20	Time 20	0.0	string
v20	Voltage 20	0.0	string
t21	Time 21	0.0	string
v21	Voltage 21	0.0	string
t22	Time 22	0.0	string
v22	Voltage 22	0.0	string
t23	Time 23	0.0	string
v23	Voltage 23	0.0	string
t24	Time 24	0.0	string
v24	Voltage 24	0.0	string
t25	Time 25	0.0	string
v25	Voltage 25	0.0	string
t26	Time 26	0.0	string
v26	Voltage 26	0.0	string
t27	Time 27	0.0	string
v27	Voltage 27	0.0	string
t28	Time 28	0.0	string
v28	Voltage 28	0.0	string
t29	Time 29	0.0	string
v29	Voltage 29	0.0	string
t30	Time 30	0.0	string
v30	Voltage 30	0.0	string
t31	Time 31	0.0	string
v31	Voltage 31	0.0	string
t32	Time 32	0.0	string

		analogLib C	omponent
v32	Voltage 32	0.0	string
t33	Time 33		string
v33	Voltage 33	0.0	string
t34	Time 34		string
v34	Voltage 34	0.0	string
t35	Time 35		string
v35	Voltage 35	0.0	string
t36	Time 36		string
v36	Voltage 36	0.0	string
t37	Time 37		string
v37	Voltage 37	0.0	string
t38	Time 38		string
v38	Voltage 38	0.0	string
t39	Time 39		string
v39	Voltage 39	0.0	string
t40	Time 40		string
v40	Voltage 40	0.0	string
t41	Time 41		string
v41	Voltage 41	0.0	string
t42	Time 42		string
v42	Voltage 42	0.0	string
t43	Time 43		string
v43	Voltage 43	0.0	string
t44	Time 44		string
v44	Voltage 44	0.0	string
t45	Time 45		string
v45	Voltage 45	0.0	string
t46	Time 46		string
v46	Voltage 46	0.0	string
t47	Time 47		string
v47	Voltage 47	0.0	string
t48	Time 48		string
v48	Voltage 48	0.0	string
t49	Time 49		string
v49	Voltage 49	0.0	string
t50	Time 50		string
v50	Voltage 50	0.0	string
fundname	Frequency name for 1/period		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string

N2	Noise 2	string
F3	Freq 3	string
N3	Noise 3	string
F4	Freq 4	string
N4	Noise 4	string
F5	Freq 5	string
N5	Noise 5	string
F6	Freq 6	string
N6	Noise 6	string
F7	Freq 7	string
N7	Noise 7	string
F8	Freq 8	string
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string
dc	DC source	string
rpt	Repeated function	string

## vsin



Name	Description	<b>Default Value</b>	Туре
srcType	Source type	sine	string
acm	AC magnitude		string
аср	AC phase		string
vdc	DC voltage		string
va	Amplitude		string
va2	Amplitude 2		string
freq	Frequency		string
freq2	Frequency 2		string
td	Delay time		string
theta	Damping factor		string
phi	Phase delay		string
vo	Offset voltage		string
fmmodindex	FM modulation index		string
fmmodfreq	FM modulation frequency		string
ammodindex	AM modulation index		string
ammodfreq	AM modulation frequency		string
ammodphase	AM modulation phase		string
sinephase	Initial phase for Sinusoid		string
sinephase2	Initial phase for Sinusoid 2		string
tc1	Temperature coefficient 1		string
tc2	Temperature coefficient 2		string
tnom	Nominal temperature		string
fundname	First frequency name		string
fundname2	Second frequency name		string
noisefile	Noise file name		string
FNpairs	Number of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string

analogLib Components

F5	Freq 5	string
N5	Noise 5	string
F6	Freq 6	string
N6	Noise 6	string
F7	Freq 7	string
N7	Noise 7	string
F8	Freq 8	string
N8	Noise 8	string
F9	Freq 9	string
N9	Noise 9	string
F10	Freq 10	string
N10	Noise 10	string
xfm	XF magnitude	string
pacm	PAC magnitude	string
раср	PAC phase	string
noisetemp	Noise temperature	string
dc	DC source	string

### **vsource**



Name	Description	<b>Default Value</b>	Туре
pwlEntryMethod	Waveform Entry Method	File	radio
numofsines	Display second sinusoid		boolean
modulation	Display modulation params		boolean
srcType	Source type	sine	cyclic
va	Amplitude 1 (Vpk)		string
va2	Amplitude 2 (Vpk)		string
freq	Frequency 1		string
freq2	Frequency 2		string
theta	Damping factor 1		string
phi	Phase delay		string
fmmodindex	FM modulation index 1		string
fmmodfreq	FM modulation freq 1		string
ammodindex	AM modulation index 1		string
ammodfreq	AM modulation freq 1		string
ammodphase	AM modulation phase 1		string
v1	Voltage 1		string
v2	Voltage 2		string
td1	Rise time start		string
td2	Fall time start		string
tau1	Rise time constant		string
tau2	Fall time constant		string
per	Period of waveform		string
td	Delay time		string
tr	Rise time		string
tf	Fall time		string
pw	Pulse width		string
vdc	DC voltage		string
acm	AC Magnitude		string
аср	AC phase		string
tvpairs	Number of PWL/Time pairs	0	int
vo	Offset voltage		string
offset	DC offset		string
scale	Amplitude scale factor		string
stretch	Time scale factor		string

pwlperiod	Period	string
twidth	Transition width	string
tc1	Linear temp. coefficient	string
tc2	Quadratic temp. coeff.	string
tnom	Nominal temperature	string
sinephase	Phase for Sinusoid 1	string
sinephase2	Phase for Sinusoid 2	string
sinedc	Sine DC level	string
val0	Zero value	string
val1	One value	string
t1	Time 1	string
t2	Time 2	string
t3	Time 3	string
v3	Voltage 3	string
t4	Time 4	string
v4	Voltage 4	string
t5	Time 5	string
v5	Voltage 5	string
t6	Time 6	string
v6	Voltage 6	string
t7	Time 7	string
v7	Voltage 7	string
t8	Time 8	string
v8	Voltage 8	string
t9	Time 9	string
v9	Voltage 9	string
t10	Time 10	string
v10	Voltage 10	string
t11	Time 11	string
v11	Voltage 11	string
t12	Time 12	string
v12	Voltage 12	string
t13	Time 13	string
v13	Voltage 13	string
t14	Time 14	string
v14	Voltage 14	string
t15	Time 15	string
v15	Voltage 15	string
t16	Time 16	string
v16	Voltage 16	string
t17	Time 17	string
v17	Voltage 17	string
t18	Time 18	string

	an	alogLib Components
v18	Voltage 18	string
t19	Time 19	string
v19	Voltage 19	string
t20	Time 20	string
v20	Voltage 20	string
t21	Time 21	string
v21	Voltage 21	string
t22	Time 22	string
v22	Voltage 22	string
t23	Time 23	string
v23	Voltage 23	string
t24	Time 24	string
v24	Voltage 24	string
t25	Time 25	string
v25	Voltage 25	string
t26	Time 26	string
v26	Voltage 26	string
t27	Time 27	string
v27	Voltage 27	string
t28	Time 28	string
v28	Voltage 28	string
t29	Time 29	string
v29	Voltage 29	string
t30	Time 30	string
v30	Voltage 30	string
t31	Time 31	string
v31	Voltage 31	string
t32	Time 32	string
v32	Voltage 32	string
t33	Time 33	string
v33	Voltage 33	string
t34	Time 34	string
v34	Voltage 34	string
t35	Time 35	string
v35	Voltage 35	string
t36	Time 36	string
v36	Voltage 36	string
t37	Time 37	string
v37	Voltage 37	string
t38	Time 38	string
v38	Voltage 38	string
t39	Time 39	string
v39	Voltage 39	string

ı		llogLib Compo	11
t40	Time 40		string
v40	Voltage 40		string
t41	Time 41		string
v41	Voltage 41		string
t42	Time 42		string
v42	Voltage 42		string
t43	Time 43		string
v43	Voltage 43		string
t44	Time 44		string
v44	Voltage 44		string
t45	Time 45		string
v45	Voltage 45		string
t46	Time 46		string
v46	Voltage 46		string
t47	Time 47		string
v47	Voltage 47		string
t48	Time 48		string
v48	Voltage 48		string
t49	Time 49		string
v49	Voltage 49		string
t50	Time 50		string
v50	Voltage 50		string
fundname	Frequency name 1		string
fundname2	Frequency name 2		string
noisefile	Noise file name		string
fileName	File name		string
tempParam	Display temperature params		boolean
smallSig	Display small signal params		boolean
noiseParam	Display noise parameters		boolean
FNpairs	Num. of noise/freq pairs	0	int
F1	Freq 1		string
N1	Noise 1		string
F2	Freq 2		string
N2	Noise 2		string
F3	Freq 3		string
N3	Noise 3		string
F4	Freq 4		string
N4	Noise 4		string
F5	Freq 5		string
N5	Noise 5		string
F6	Freq 6		string
N6	Noise 6		string
F7	Freq 7		string

N7	Noise 7		string
F8	Freq 8		string
N8	Noise 8		string
F9	Freq 9		string
N9	Noise 9		string
F10	Freq 10		string
N10	Noise 10		string
noiseEntryMethod	Noise Entry Method	File	radio
noiseEntryMethod pacm	Noise Entry Method PAC Magnitude	File	radio string
	<u>'</u>	File	
pacm	PAC Magnitude	File	string
pacm pacp	PAC Magnitude PAC phase	File	string string
pacm pacp xfm	PAC Magnitude PAC phase XF Magnitude	File	string string string