

7.4 ROBUST DESIGN RULES


7.4.1 LONELY VIA RULE


VIAs located in a very isolated environment can show a systematic VIA opening failure.






Critical VIAs can be located with the following rule:







OK

LON-VIAx_30



- increasing the number of connected VIAs in the near vicinity of the lonely VIAs. This might require enlarging the metal lines below and/or above.
- placing "islands" of metal-VIA-metal, in case connected VIAs cannot be placed due to space limitations as for instance in case of neighbouring metal lines.

