

## Tank Drive

BEHAVIOR = "tank\_drive"

Controller

Double Motor

Left stick drives the left wheel, right stick the right. Push both to go straight, opposite to spin on the spot.

*puck behavior · needs 2 devices*

## Arcade Drive

BEHAVIOR = "arcade\_drive"

Controller

Double Motor

Right stick is the gas, left stick steers. Easy one-hand driving.

*puck behavior · needs 2 devices*

## Light Theremin

BEHAVIOR = "light\_theremin"

Color Sensor

Single Motor

Wave your hand over the color sensor — brighter light spins the motor faster, like a theremin.

*puck behavior · needs 2 devices*

## Spin

BEHAVIOR = "spin"

Single Motor

Spins the motor continuously. Simple and satisfying.

*puck behavior · needs 1 device*

## Gyro Straight-Line Drive

BEHAVIOR = "gyro\_drive"

Controller

Double Motor

Push forward and it drives perfectly straight on its own. Nudge the left stick to steer; it holds the new heading.

*puck behavior · needs 2 devices*

## Precision Turn

BEHAVIOR = "precision\_turn"

Controller

Double Motor

Flick the right stick left or right to spin exactly in place. It beeps when the turn is finished.

*puck behavior · needs 2 devices*

## Line Follower

BEHAVIOR = "line\_follower"

● Color Sensor

● Double Motor

Set it on the edge of a dark line and it follows the line by itself. Beeps if it loses the line.

*puck behavior · needs 2 devices*

## Tilt Steering

BEHAVIOR = "tilt\_steer"

● Controller

● Double Motor

Right stick is the throttle — steer by tilting the whole robot left and right.

*puck behavior · needs 2 devices*

## Motor Knob

BEHAVIOR = "motor\_knob"

● Single Motor

● Double Motor

Turn the single motor by hand like a dial to set the drive motor's speed. One motor controls the other.

*puck behavior · needs 2 devices*

## Color Gearbox

BEHAVIOR = "color\_gearbox"

● Color Sensor

● Controller

● Double Motor

Show it a color to pick a gear — green = fast, yellow = half, red = reverse — then drive as normal.

*puck behavior · needs 3 devices*

## Color Soundboard

BEHAVIOR = "color\_soundboard"

● Color Sensor

Each color you show the sensor plays a different note. Make a little tune with colored cards.

*puck behavior · needs 1 device*

## Simon Says (color memory)

BEHAVIOR = "simon\_says"

● Color Sensor

The sensor beeps out a color sequence — repeat it by showing the colors in order. It grows each round.

*puck behavior · needs 1 device*

## Parking-Sensor Radar

BEHAVIOR = "radar"

● Single Motor

● Color Sensor

The sensor sweeps side to side and beeps faster the closer something gets — like a car parking sensor.

*puck behavior · needs 2 devices*

## Gesture Drum Kit

BEHAVIOR = "gesture\_drum"

● Double Motor

● Controller

Tap, shake or bump the double motor to play drum sounds. The left stick changes the pitch.

*puck behavior · needs 2 devices*