Traveling and Standing Waves

Standing Waves

In the previous section, we introduced the voltage reflection coefficient that relates the forward to reflected voltage phasor.

$$\tilde{V}(z) = \tilde{V}_0^+ (e^{-j\beta z} + \Gamma_L e^{j\beta z}) \tag{1}$$

$$I(z) = \frac{\tilde{V}_0^+}{Z_0} (e^{-j\beta z} - \Gamma_L e^{j\beta z}) \tag{2}$$

Let us look at the physical meaning of these variables.

- (a) Γ_L is the voltage reflection coefficient at the load (z=0),
- (b) z is the axis in the direction of wave propagation,
- (c) β is the phase constant,
- (d) Z_0 is the impedance of the transmission line.
- (e) \tilde{V}_0^+ is the phasor of the forward-going wave at the load,
- (f) $\Gamma_L \tilde{V}_0^+$ is the phasor of the reflected going wave at the load,
- (g) $\tilde{V}_0^+ e^{-j\beta z}$ is a forward voltage anywhere on the line,
- (h) $\Gamma_L \tilde{V}_0^+ e^{j\beta z}$ is a reflected voltage anywhere on the line,
- (i) $\tilde{V}(z)$ is the total voltage phasor on the line, the sum of forward and reflected voltage.
- (j) \tilde{I}_0^+ is the phasor of the forward-going current at the load,
- (k) $-\Gamma_L \frac{\tilde{V}_0^+}{Z_0}$ is the phasor of the reflected current at the load,
- (l) $\tilde{I}_0^+ e^{-j\beta z}$ is the phasor of a forward current anywhere on the line,

Learning outcomes: Describe forward and reflected wave on a transmission line. Author(s): Milica Markovic

- (m) $-\Gamma_L \frac{\tilde{V}_0^+}{Z_0} e^{j\beta z}$ is the phasor of a reflected current anywhere on the line,
- (n) I(z) is the phasor of the total current on the line, the sum of forward and reflected voltage.

The magnitude of a complex number can be found as $|z| = \sqrt{zz^*}$. Therefore the magnitude of the voltage anywhere on the line is $|\tilde{V}(z)| = \sqrt{\tilde{V}(z)\tilde{V}(z)^*}$. We can simplify this equation as shown in Figure ??.

$$|\tilde{V}(z)| = \sqrt{\tilde{V}(z)\tilde{V}(z)^{*}}$$

$$|\tilde{V}(z)| = \sqrt{(\tilde{V}_{0}^{+})^{2}(e^{-j\beta z} - |\Gamma_{L}|e^{j\beta z + \Theta_{r}})\tilde{V}_{0}^{+}(e^{j\beta z} - |\Gamma_{L}|e^{-(j\beta z + \angle\Gamma_{L})})}$$

$$|\tilde{V}(z)| = \tilde{V}_{0}^{+}\sqrt{(e^{-j\beta z} - |\Gamma_{L}|e^{j\beta z + |\angle\Gamma_{L}})(e^{j\beta z} - |\Gamma_{L}|e^{-(j\beta z + \angle\Gamma_{L})})}$$

$$|\tilde{V}(z)| = \tilde{V}_{0}^{+}\sqrt{1 + |\Gamma_{L}|e^{-(2j\beta z + |\angle\Gamma_{L})} + |\Gamma_{L}|e^{j2\beta z + \angle\Gamma_{L}} + |\Gamma_{L}|^{2})}$$

$$|\tilde{V}(z)| = \tilde{V}_{0}^{+}\sqrt{1 + |\Gamma_{L}|^{2} + |\Gamma_{L}|(e^{-(2j\beta z + \angle\Gamma_{L})} \angle\Gamma_{L} + e^{(j2\beta z + \angle\Gamma_{L})})}$$

$$|\tilde{V}(z)| = \tilde{V}_{0}^{+}\sqrt{1 + |\Gamma_{L}|^{2} + 2|\Gamma_{L}|\cos(2\beta z + \angle\Gamma_{L})}$$
(3)

The Equation ?? is written in terms of z. We set up the load at z=0, and the generator at z=-l. The positions of the maximums and minimum total voltage on the line will be at some position at the negative part of z-axis $z_{max}=-l_{max}$, and the minimums will be at $z_{max}=-l_{min}$.

The magnitude of the total voltage on the transmission line is given by Eq.??. We will now visualize how the magnitude of the voltage looks on the transmission line.

Example 1. Find the magnitude of the total voltage anywhere on the transmission line if $\Gamma_L = 0$.

Explanation. Let us start from a simple case when the voltage reflection coefficient on the transmission line is $\Gamma_L = 0$ and draw the magnitude of the total voltage as a function of z. Equation ?? shows the magnitude of the total voltage anywhere on the line is equal to the magnitude of the voltage at the load $|\tilde{V}(z)| = |\tilde{V}_0^+|$. The magnitude of the voltage is constant everywhere on the transmission line, and so the line is called "flat," and it represents a single, forward traveling wave from the generator to the load. The magnitude is the green line in Figure ??. To see the movie of this transmission line, go to the class web page under Instructional Videos. Forward voltage is shown in red, reflected voltage in pink, and the magnitude of the voltage is green.

Example 2. Find the magnitude of the total voltage anywhere on the transmission line if $\Gamma_L = 0.5e^{j0}$.




Figure 1: Flat line.

Explanation.

Let's look at another case, $\Gamma_L = 0.5$ and $\angle \Gamma_L = 0$. Equation ?? represents the magnitude of the voltage on the transmission line, and Figure ?? shows in green how this function looks on a transmission line. This case is shown in Figure ??.

$$|\tilde{V}(z)| = \tilde{V}_0^+ \sqrt{\frac{5}{4} + \cos 2\beta z} \tag{4}$$




Figure 2: Voltage on a transmission line with reflection coefficient magnitude 0.5, and zero phase.

The function in Equation ?? is at its maximum when $\cos(2\beta z + \angle \Gamma_L) = 1$ or $z = \frac{k}{2}\lambda$, and the function value is $\tilde{V}(z) = 1.5\tilde{V}_0^+$. It is at its minimum when $\cos(2\beta z + \angle \Gamma_L) = -1$ or $z = \frac{2k+1}{4}\lambda$ and the function value is $\tilde{V}(z) = 0.5\tilde{V}_0^+$

The function that we see looks like a cosine with an average value of \tilde{V}_0^+ , but it is not a cosine. The minimums of the function are sharper than the maximums.

Question 1 Observe waves in the app below.

Geogebra link: https://tube.geogebra.org/m/bmr8euzu

Is the black wave moving left or right?

Multiple Choice:

- (a) left
- (b) right ✓

Is the black wave a forward, reflected or the sum of the two?

Multiple Choice:

- (a) Forward
- (b) Reflected
- (c) The sum of the two ✓

Example 3. Find the magnitude of the total voltage anywhere on the transmission line if $\Gamma_L = 1$.

Explanation. Another case we will look at is when the reflection coefficient is at its maximum of $\Gamma_L = 1$. The function is shown if Figure ??. In this case, we have a pure standing wave on a transmission line.




Figure 3: Shorted Transmission Line.

Question 2 Observe waves in the app below.

Geogebra link: https://tube.geogebra.org/m/fwebfheh

Is the black wave moving left or right? The wave is not moving left or right, it is standing in place, so it is called a standing wave. Is the black wave a forward, reflected or the sum of the two?

Multiple Choice:

- (a) Forward
- (b) Reflected
- (c) The sum of the two \checkmark

Example 4. Find the magnitude of the total voltage anywhere on the transmission line for any Γ_L , and the position of voltage maximums on the line.

Explanation. The magnitude of the total voltage on the line is given in Equation??. In general the voltage maximums will occur when the cosine function is at its maximum $\cos(2\beta z + \angle \Gamma_L) = 1$. In this case, the maximum value of the magnitude of total voltage on the line is shown in Equation ??.

$$|\tilde{V}(z)_{max}| = |\tilde{V}_0^+|\sqrt{1 + |\Gamma_L|^2 + 2|\Gamma_L|} |\tilde{V}(z)_{max}| = |\tilde{V}_0^+|\sqrt{(1 + |\Gamma_L|)^2} |\tilde{V}(z)_{max}| = |\tilde{V}_0^+|(1 + |\Gamma_L|)$$
(5)

The Equation ?? shows position of voltage maximums z_{max} on the line.

$$cos(-2\beta l_{max} + \angle \Gamma_L) = 1$$

$$cos(2\beta l_{max} - \angle \Gamma_L) = 1$$

$$2\beta z_{max} - \angle \Gamma_L = 2n\pi$$

$$z_{max} = \frac{2n\pi + \angle \Gamma_L}{2\beta}$$

$$z_{max} = \lambda \frac{2n\pi + \angle \Gamma_L}{4\pi}$$
(6)

In general the voltage minimums will occur when $cos(2\beta z) = -1$.

$$|\tilde{V}(z)_{min}| = |\tilde{V}_0^+|\sqrt{1 + |\Gamma_L|^2 - 2|\Gamma_L|} |\tilde{V}(z)_{min}| = |\tilde{V}_0^+|\sqrt{(1 - |\Gamma_L|)^2} |\tilde{V}(z)_{min}| = |\tilde{V}_0^+|(1 - |\Gamma_L|)$$
(7)

The Equation ?? shows the position of voltage minimums on the line.

$$cos(2\beta z_{max} - \angle\Gamma_L) = -1$$

$$2\beta z_{max} + \angle\Gamma_L = (2n+1)\pi$$

$$z_{max} = \frac{(2n+1)\pi + \angle\Gamma_L}{2\beta}$$

$$z_{max} = \lambda \frac{(2n+1)\pi + \angle\Gamma_L}{4\pi}$$
(8)

Voltage Standing Wave Ratio (VSWR) - pron: "vee-s-uh-are"

The ratio of voltage minimum on the line over the voltage maximum is called the Voltage Standing Wave Ratio (VSWR) or just Standing Wave Ratio (SWR).

$$SWR = \frac{\tilde{V}(z)_{max}}{\tilde{V}(z)_{min}}$$

$$SWR = \frac{1 + |\Gamma_L|}{1 - |\Gamma_L|}$$
(9)

Note that the SWR is always equal or greater than 1.