Example: Track Hold $V_{in} \ _{\blacktriangle}$ $V_{\text{in}} \\$ V_{out} Igate $V_{out} \
ight \}$ Ideal Droop due to Igate