

E

Ε

E

centrations for (a) intrinsic, (b) *n*-type, and (c) *p*-type semiconductors at thermal equilibrium. Note that $pn = n_i^2$ for all three cases.