## Quick reference guide.

Changing the display language	5 3 1 d b [select language] [OK];
Activating/deactivating the handset	the hold down
Activating/deactivating key- pad protection	# hold down
Activating/deactivating ringer	* hold down
Activating/deactivating handsfree	<b>■</b> •
Making an external call	[enter number]
Redialling a number	short press 🖒 [select entry if necessary] 🚓
Dialling with the directory	↓ III [name] ↓ Iselect entry if necessary] ←
Dialling with the online directory	press and hold [enter the first letter of the name] if necessary $\Diamond$ [select entry]
Using quick dialling (Digit key has been assigned a number)	press and hold the digit key e. g. 3
Copying a telephone number to the directory	[open entry in calls, last number redial or SMS list] [Optionen] / [Menü] → Nr. ins Tel.buch [OK] ♣ Ⅲ [name] [Sichern];
Calling from the calls list	
Setting the handset and handsfree volume (during an external call)	⟨♣⟩
Making an internal call	(♣) III [internal number] or (♣) (♣) [select handset]
Calling all handsets	press ♣ vr ♣ An alle ♣
Transferring a call to another handset (during an external call)	Ç♭ <b>  </b> [internal number] <b> </b>
Internal inquiry call (during an external call)	Ç♭ <b>iii</b> [internal number]; End: <b>[Beenden]</b>

Setting the date and time	
Setting the alarm clock	
Displaying the telephone's IP address in the display	[briefly press the registration/paging key on the base station] (exit display)
Displaying incoming e-mail	→ → Ø → E-Mail