



<u>Technical Note</u>: Instructions to access WIP330 admin mode WebUI and admin mode Phone UI

Date: May 31st 2006

Version: 1.0

Abstract: This technical note explains the steps to enter the Web user interface of WIP330 in admin mode as well as the Phone User interface in admin mode. Admin modes enable the user via Web UI or via Phone UI to see and modify all configuration parameters which are hidden to the user:

- SIP Settings
- Supplementary Services configuration
- Firmware upgrade settings
- Auto-configuration settings

NOTE: LINKSYS PROPRIETARY CONFIDENTIAL. This is not a public user document, it is intended only for Service Providers, and not for end users or system integrators (this information should not be available to them). Don't share this document or its content to any other user outside your company. This contains security-sensible information.

Entering WebUI admin mode:

- 1. Enter WIP330 IP address in the Browser: To know WIP330 IP address, please click on *information* icon (on the phone screen).
- 2. Login into the page:
 - a. Username: "admin" (some version may use "administrator")
 - b. Default password: "0000"

Entering Phone UI Admin mode:

- 1. Enter WIP330 *Phone settings* menu, through the phone screen menu
- 2. Select Phone Password
- 3. Press central key in order to enable phone password
- 4. Change user password to ADMIN
- 5. Power cycle the phone
- 6. Screen will prompt you to enter user password, press dial button for 3 seconds, prompt will change asking you for admin password. Enter 0000
- 7. Phone will move to admin mode, you should be able to see all SIP settings, autoconfig, FW upgrade options, configuration of Supplementary Services.