

CallVoip Telefonie met de Cisco 7940(G) / 7960(G)

Hieronder vindt u de config-file van de Cisco 7940(G) en de Cisco 7960(G) (SIP-uitvoering) met de instellingen voor CallVoip Telefonie. Diverse waarden zijn standaard reeds ingevuld. De telefoon geeft bij diverse waarden een korte toelichting.

# Image Version					
image_version: "P0S3-08-9-00"		softewareversie			
# Proxy Server					
proxy1_address:	sip.sipnl.net	SIP serveradres			
line1_name:	050	telefoonnummer			
line1_authname:	31	SIP gebruikersnaam			
line1_shortname:	account-1	Tekst naast line button 1 in display			
line1_password:	SIP wachtwoord	SIP-wachtwoord bij deze account			
vul account 2 t/m 6 op dezelfde manier in					
phone_label: "CallVoip"					
# Proxy Server Port (default - 5060)					
proxy1_port: "5060"					
proxy2_port: "5060"					
Proxy3_port: "5060"					
proxy4_port: "5060"					
proxy5_port: "5060"					
proxy6_port: "5060"					
# outbound proxy info					
# outbound_proxy:	sip.sipnl.net	SIP serveradres			
# outbound_proxy_port:	5060				
# Emergency Proxy info					
# proxy_emergency: ""					
# proxy_emergency_port: "5060"					
# Backup Proxy info					
# proxy_backup: ""					
# proxy_backup_port: "5060"					
# NAT/Firewall Traversal					
nat_enable: "1"					
nat_address: ""					
voip_control_port: "5061"					
start_media_port: "16384"					
end_media_port: "32766"					

# Proxy Registration (0-disable (default), 1-enable) proxy_register: "1"	nat_received_processing: "0"	
proxy_register: "1" # Phone Registration Expiration [1-3932100 set] [Cofeault - 3600] timer_register_expires: "3600" # Codec for media stream (g711ulaw (default), g711alaw, g	· -	
# Phone Registration Expiration [1-3932100 sec] (Default - 3600) # Codec for media stream (g/11ulaw (default), g/11alaw, g/29) preferred_codec: "g/11alaw" # TOS bits in media stream [0-5] (Default - 5) # tos_media: "5" # Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to join remaining parties upon hangup cnf_join_enable: "1": 0-Disabled, 1-Enabled (default) # Allow from for to be completed while target phone is still ringing semt_altended_transfer: "0": 0-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2": 0-Disabled (default), 1-Enabled, 2-Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) # SIP Timers # SIP Timers # SIP Timers # SIP Timers # Infart Timer (1: "500"; Default 4 sec: slip_retx: "10"; Default 11 # sip_invite_retx: "6"; Default 7 # Itimer_lavite_expires: "180"; Default 180 sec # Setting for Message speeddial to Uone box # messages_uri: "197" # TITP Phone Specific Configuration File Directory # Time Server		
timer_register_expires: "3600" # Codec for media stream (g711ulaw (default), g711alaw, g729) preferred_codec: "g711alaw" # TOS bits in media stream [0-5] (Default - 5) # tos_media: "5" # Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to join remaining parties upon hangup coff_join_enable: "1": O-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0": O-Disabled, 1-Enabled (default) # Teinet Level (enable or disable the ability to teinet into this phone teinet_level: "2": O-Disabled (default), 1-Enabled, 2-Privileged # Teinet Level (enable or disable the ability to teinet into this phone teinet_level: "2": O-Disabled (default), 1-Enabled, 2-Privileged # To Out of band DTMF Settings (0-disable, 1-enable (default)) # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) # off out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) # SIP Times # SIP Timers # SIP Timers # Sip_retx: "10": Default 500 msec # Itime_12: "4000": Default 500 msec # Setting of Message speeddial to UOne box # Setting for Message speeddial to UOne box # Setting for Message speeddial to UOne box # TETP Phone Specific Configuration File Directory # Itip_cfg_dir: "/" # Time Server	# Phone Registration Expiration [1-3932100 sec]	
# Codec for media stream (q711ulaw (default), g711alaw, g729) # TOS bits in media stream (0-5) (Default - 5) # tos_media: "5" # Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to join remaining parties upon hangup onf_join_enable: "1"; 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing sami_attended_transfer: "0"; 0-Disabled, 1-Enabled (default) # Teinet Level (enable or disable the ability to teinet into this phone teinet_level: "2"; 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dimf_orbor." "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dimf_orbor." "3" # SIP Timers Itimer_11: "500": Default 500 msec Itimer_11: "500": Default 4 sec sip_retx: "10": Default 11 sip_invite_retx: "6": Default 7 Itimer_finvite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "197" # TITP Phone Specific Configuration File Directory Itime_fage_in: "7" # TITP Phone Specific Configuration File Directory Itime_fage_in: "7" # Time Server	· · · · · · · · · · · · · · · · · · ·	
g711alaw, g729) preferred_codec: "g711alaw" # TOS bits in media stream [0-5] (Default - 5) # tos_media: "5" # Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to join remaining parties upon hangup cnf_join_enable: "1": 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0": 0-Disabled, 1-Enabled (default) # Tolnet Level (enable or disable the ability to telnet into this phone telnet_levet: "2": 0-Disabled (default), 1-Enabled, 2- privileged # Inband DTMF Settings (0-disable, 1-enable (default)) # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_unband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_unband: "3" # SIP Timers # SIP Timers # SIP Timers # stimer_t1: "500": Default 500 msec # timer_t1: "500": Default 4 sec # sip_retx: "10": Default 11 # sip_invite_retx: "6": Default 180 sec # Setting for Message speeddial to UOne box # messages_uri: "497" # TETP Phone Specific Configuration File Directory # Time Server		
# TOS bits in media stream [0-5] (Default - 5) # tos_media: "5" # Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to Join remaining parties upon hangup cnf_Join_enable: "1"; 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0"; 0-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2"; 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_uot band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_dband: "3" # SIP Times timer_t1: "500"; Default 500 msec timer_12: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddal to UOne box messages_uri: "497" # TETP Phone Specific Configuration File Directory tftp_cfg_dir: "/" # Time Server		
# tos_media: "5" # Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to Join remaining parties upon hangup cnf_join_enable: "1"; 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing in the still ringing i	preferred_codec: "g711alaw"	
# Enable VAD (0-disable (default), 1-enable) enable_vad: "0" # Allow for the bridge on a 3way call to join remaining parties upon hangup cnf_join_enable: "1": 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0": 0-Disabled, 1-Enabled (default) irriging semi_attended_transfer: "0": 0-Disabled, 1-Enabled (default) irriging # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2": 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outofband: "avt" =no_# DTMF fall Level Settings (1-6dB down, 2-3db down, 3-nominal (default), avt_always - always avt) dtmf_outofband: "avt" =no_# DTMF fall Level Settings (1-6dB down, 2-3db down, 3-nominal (default), avt_always - always avt) dtmf_db_level: "3" # SIP Timers timer_i1: "500": Default 4 sec sip_rets: "10": Default 11 sip_invite_rets: "6": Default 7 timer_invite_expires: "180": Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	# TOS bits in media stream [0-5] (Default - 5)	
enable_vad: "0" # Allow for the bridge on a 3way call to join remaining parties upon hangup conf_join_enable: "1"; 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0"; 0-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2"; 0-Disabled (default), 1-Enabled, 2-Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) # Out of band DTMF Settings (none-disable, avt-avt enable (default), a-Jalways - always avt) dtmf_unband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable) # (default), av_always - always avt) dtmf_outofand: "avt" - no_* DTMF fall Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) # SIP Timers # SIP Timers # Imer_it: "500"; Default 4 sec # sip_rex: "10"; Default 11 # sip_invite_retx: "6"; Default 17 # Imer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory # Time Server	# tos_media: "5"	
# Allow for the bridge on a 3way call to join remaining parties upon hangup cnf_join_enable: "1": 0-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringling semi_attended_transfer: "0": 0-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2": 0-Disabled (default), 1-Enabled, 2-Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt.) dtmf_outofband: "avt" -np-# DTMF dB Level Settings (1-68 down, 2-38d down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500": Default 500 msec timer_t2: "4000": Default 11 stp_invite_retx: "6": Default 1 stp_invite_retx: "6": Default 1 stp_invite_expires: "180": Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "497" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "," # Time Server	# Enable VAD (0-disable (default), 1-enable)	
remaining parties upon hangup cnf_join_enable: "1"; O-Disabled, 1-Enabled (default) # Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0"; O-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2"; O-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outorband: "avt" -np-# DTMF dB Level Settings (1-deB down, 2-3abd down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 17 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "+97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: ",/" # Time Server	enable_vad: "0"	
# Allow Transfer to be completed while target phone is still ringing semi_attended_transfer: "0"; 0-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2"; 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outorband: "avt" -np-# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory ttp_cd_d.dir: "./" # Time Server		
is still ringing semi_attended_transfer: "0" ; 0-Disabled, 1-Enabled (default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2" ; 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) of the disable of the down, 2-3db down, 3-nominal (default), avt_always - always avt) dtmf_outofband: "avt" - np - # DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500" ; Default 500 msec timer_t2: "4000" ; Default 4 sec sip_retx: "10" ; Default 11 sip_invite_retx: "6" ; Default 7 timer_invite_expires: "180" ; Default 180 sec # Setting for Message speeddial to Uone box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tttp_cfg_dir: "./" # Time Server	cnf_join_enable: "1"; 0-Disabled, 1-Enabled (default)	
(default) # Telnet Level (enable or disable the ability to telnet into this phone telnet_level: "2"; 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-doß down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: ","" # Time Server		
into this phone telnet_level: "2"; 0-Disabled (default), 1-Enabled, 2- Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server		
Privileged # Inband DTMF Settings (0-disable, 1-enable (default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server		
(default)) dtmf_inband: "1" # Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server		
# Out of band DTMF Settings (none-disable, avt-avt enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server		
enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal (default), 4-3db up, 5-6dB up) dtmf_db_level: "3" # SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to Uone box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	dtmf_inband: "1"	
# SIP Timers timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	enable (default), avt_always - always avt) dtmf_outofband: "avt" ~np~# DTMF dB Level Settings (1-6dB down, 2-3db down, 3-nominal	
timer_t1: "500"; Default 500 msec timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	dtmf_db_level: "3"	
timer_t2: "4000"; Default 4 sec sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	# SIP Timers	
sip_retx: "10"; Default 11 sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	timer_t1: "500"; Default 500 msec	
sip_invite_retx: "6"; Default 7 timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	timer_t2: "4000"; Default 4 sec	
timer_invite_expires: "180"; Default 180 sec # Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	sip_retx: "10"; Default 11	
# Setting for Message speeddial to UOne box messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	sip_invite_retx: "6"; Default 7	
messages_uri: "*97" # TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	timer_invite_expires: "180"; Default 180 sec	
# TFTP Phone Specific Configuration File Directory tftp_cfg_dir: "./" # Time Server	# Setting for Message speeddial to UOne box	
tftp_cfg_dir: "./" # Time Server	messages_uri: "*97"	
# Time Server	# TFTP Phone Specific Configuration File Directory	
	tftp_cfg_dir: "./"	
data farmati D/MAY	# Time Server	
date_format : D/M/Y	date_format : D/M/Y	
sntp_mode: "unicast"	sntp_mode: "unicast"	

sntp_server: "Time2.Stupi.SE" # IP address here alternatively	
time_zone: "CET"	
dst_offset: "1"	
dst_start_month: "April"	
dst_start_day: ""	
dst_start_day_of_week: "Sun"	
dst_start_week_of_month: "1"	
dst_start_time: "02"	
dst_stop_month: "Oct"	
dst_stop_day: ""	
dst_stop_day_of_week: "Sunday"	
dst_stop_week_of_month: "8"	
dst_stop_time: "2"	
dst_auto_adjust: "1"	
# Do Not Disturb Control (0-off, 1-on, 2-off with no user control, 3-on with no user control)	
dnd_control: "0"; Default 0 (Do Not Disturb feature is off)	
# Caller ID Blocking (0-disabled, 1-enabled, 2-disabled no user control, 3-enabled no user control)	
callerid_blocking: "0"; Default 0 (Disable sending all calls as anonymous)	
# Anonymous Call Blocking (0-disbaled, 1-enabled, 2-disabled no user control, 3-enabled no user control)	
anonymous_call_block: "0"; Default 0 (Disable blocking of anonymous calls)	
# Call Waiting (0-disabled, 1-enabled, 2-disabled with no user control, 3-enabled with no user control)	
call_waiting: "1"; Default 1 (Call Waiting enabled)	
# DTMF AVT Payload (Dynamic payload range for AVT tones - 96-127)	
dtmf_avt_payload: "101"; Default 100	
# XML file that specifies the dialplan desired	
# dial_template: "dialplan"	
# Network Media Type (auto, full100, full10, half100, half10)	
network_media_type: "auto"	
#Autocompletion During Dial (0-off, 1-on [default])	
autocomplete: "0"	
#Time Format (0-12hr, 1-24hr [default])	
time_format_24hr: "1"	
# URL for external Phone Services	
services_url: "" # IP address here alternatively	
# URL for external Directory location	

directory_url: "" # IP address here alternatively	
# URL for branding logo	
logo_url: "" # IP address here alternatively	
# Remote Party ID	
remote_party_id: 1 ; 0-Disabled (default), 1-Enabled	

Deze handleiding werd samengesteld met informatie van één van onze klanten, waarvoor onze hartelijke dank, en wordt u aangeboden door:

CallVoip Telefonie | Kennis van VoIP Koldingweg 19-1 9723 HL GRONINGEN

<u>callvoip@callvoip.nl</u> <u>www.callvoiptelefonie.nl</u>