HW3 on MacBook and iPhone

MacBook: minicom

安裝 minicom,在 MacOS 上可以用 Homebrew 進行安裝

brew install minicom
brew install lrzsz

lrzsz 是用來傳輸檔案的,這次沒有用到。

minicom 的初始設定

sudo minicom -s

選擇 Serial port setup,然後更改 A - Serial Device 的值,如果你的 Mac 是使用轉接器進行連接,USB的 ID 可能不同,可以用 ls /dev 查詢,八成是 tty.usbserial 開頭的。

```
Serial Device
                        : /dev/tty.usbserial-1110
- Lockfile Location
                        : /opt/homebrew/Cellar/minicom/2.8/var
    Callin Program
  Callout Program
                          115200 8N1
     Bps/Par/Bits
- Hardware Flow Control : Yes
  Software Flow Control : No
     RS485 Enable
                       : No
    RS485 Rts On Send
  RS485 Rts After Send : No
  RS485 Rx During Tx
                       : No
  RS485 Terminate Bus
- RS485 Delay Rts Before: 0
- RS485 Delay Rts After: 0
 Change which setting?
```

回到上層選單 Exit 後應該就會自動接上。

iPhone: BLE scanner

下載這個 APP



- 1. 開啟後選擇底下的 Advertiser, 按右上角的 + 新增一個 BLE Device (圖左)
- 2. 點進去如果沒有 SERVICES 的話,按右上角的 S 新增一個(圖中)
- 3. 點進去後把 primary service 的名稱改成 FFF0(圖右)
- 4. 點右上角的 C 新增一個 characteristic,名稱改成 FFF1,Properties 選 Read(圖右)
- 5. 在 SetValue?的地方寫上想要傳的訊息(圖右)
- 6. 開啟這個 BLE Peripheral (圖左)就完成了,至於為什麼要執行 3、4 步的原因可以參考 py 檔。

