Laboratory Exercise 11

Interrupts & IO programming

Goals

After this laboratory exercise, you should understand the basic principles of interrupts and how interrupts can be used for programming. You should also know the difference between polling and using interrupts and the relative merits of these methods.

Literature

■ Patterson and Hennessy: Chapter 2.7, 2.9, 2.10, 2.13, 5.7, Appendix A.6, A.7, A.10

Polling or Interrupts

A computer can react to external events either by polling or by using interrupts. One method is simpler, while the other one is more systematic and also more efficient. You will study the similarities and differences of these methods using a simple "toy" example program.

Each pheriperal device connects to the CPU via a few ports. CPU uses address to find out the respective port, and after that, CPU could read/write the new value to these port to get/control the device.


Preparation

Study literature and these home assignments before coming into the class.

Assignments at Home and at Lab

Home Assignment 1 - POOLING

Write a program using assembly language to detect key pressed in Digi Lab Sim and print the key number to console.




The program has a unlimited loop, to read the scan code of key button. This is POLLING.

In order to use the key matrix⁴, you should 1.assign experted row index into the byte at the address 0xFFFF0012

2.read byte at the address 0xFFFF0014, to detect which key button was pressed

⁴ Key matrix animation: http://hackyourmind.org/public/images/keypad12keys anim.gif



# -			col 0x1	col 0x2	col 0x4	col 0x8					
#	row	0x1	0	1	2	3					
#			0x11	0x21	0x41	0x81					
#	row	0x2	4	5	6	7					
#			0x12	0x22	0x42	0x82					
#	row	0x4	8 0×14	9 0x24	a 0x44	b 0×84					
#											
#	row	0x8	c 0x18	d 0x28	e 0x48	f 0x88					
# -											
	# command row number of hexadecimal keyboard (bit 0 to 3)										
# Eg. assign 0x1, to get key button 0,1,2,3 # assign 0x2, to get key button 4,5,6,7											
<pre># NOTE must reassign value for this address before reading, # eventhough you only want to scan 1 row</pre>											
.eqv IN_ADRESS_HEXA_KEYBOARD 0xFFFF0012											
#	<pre># receive row and column of the key pressed, 0 if not key pressed # Eg. equal 0x11, means that key button 0 pressed. # Eg. equal 0x28, means that key button D pressed.</pre>										
.e	.eqv OUT_ADRESS_HEXA_KEYBOARD 0xFFFF0014										

```
.text
                            IN ADRESS HEXA KEYBOARD
main:
                      $t1,
                li
                      $t2,
                            OUT ADRESS HEXA KEYBOARD
                                  # check row 4 with key C, D,
                      $t3,
E, F
polling:
                            0($t1) # must reassign expected row
                sb
                      $t3,
                            0($t2)
                1b
                                    # read scan code of key button
                      $a0,
                      $v0,
                li
                                     # print integer (hexa)
   print:
                syscall
                      $a0,
                            100
                                      # sleep 100ms
                li
   sleep:
                      $v0,
                            32
                syscall
                      polling
back to polling: j
                                      # continue polling
```

Home Assignment 2 - INTERRUPT

Study the following assembly program, which waits for an interrupt from keyboard matrix, and prints out a simple message. Go over the code in detail and make sure that you understand everything, especially how to write and install an interrupt routine, how to enable an interrupt, and what happens when an interrupt is activated.

Vietnamese support:

Cũng như các bộ xử lý khác, MIPS có 3 service với cùng một nguyên lý, nhưng khác nhau về mục đích sử dụng

- Exception: xảy ra khi có lỗi trong quá trình chạy, chẳng hạn tham chiếu bộ nhớ không hợp lê.
- Trap: xẩy ra bởi cách lệnh kiểm tra
- Interrupt: do các thiết bị bên ngoài kích hoạt

Cả 3 cơ chế trên đều được gọi chung là Exception.

Cách thức hoạt động: khi một exception xảy ra

- Khi có một Exception xảy ra, MIPS sẽ luôn nhảy tới địa chỉ cố định 0x80000180 để thực hiện chương trình con phục vụ ngắt. Để viết chương trình con phục vụ ngắt, sử dụng chỉ thị .ktext để viết code ở địa chỉ 0x80000180 nói trên.
- Bộ đồng xử lý C0, thanh ghi \$12 (status) sẽ bật bit 1
- Bộ đồng xử lý C0, thanh ghi \$13 (cause) sẽ thay đổi các bit 2~6 cho biết nguyên nhân gây ra ngắt
- Bộ đồng xử lý C0, thanh ghi \$14 (epc) sẽ chứa địa chỉ kể tiếp của chương trình chính, để quay trở về sau khi xử lý các đoạn mã Exception xong. (giống như thanh ghi \$ra)
- Trường hợp thanh ghi \$13 (cause) cho biết nguyên nhân làm tham chiếu địa chỉ bộ nhớ không hợp lệ, thanh ghi \$8 (vaddr) sẽ chứa địa chỉ lỗi đó.
- Nếu không có mã lệnh nào ở địa chỉ 0x80000180 (.ktext), chương trình sẽ hiện thông báo lỗi và tự kết thúc.
- Sau khi kết thúc chương trình con, sử dụng lệnh **eret** để quay trở lại chương btrình chính. Lệnh **eret** sẽ gán nội dung thanh ghi PC bằng giá trị trong thanh ghi \$14 (epc).

Tuy nhiên, lưu ý rằng, trong MARS, thanh ghi PC vẫn chứa địa chỉ của lệnh mà ngắt xảy ra, tức là lệnh đã thực hiện xong, chứ không chứa địa chỉ của lệnh kế tiếp. Bởi vây phải tự lập trình để tăng địa chỉ chứa trong thanh ghi epc bằng cách sử dụng 2 lệnh mfc0 (để đọc thanh ghi trong bộ đồng xử lý C0) và mtc0 (để ghi giá trị vào thanh ghi trong bộ đồng xử lý C0)

- Các bit 8-15 của thanh ghi Cause, \$13 được sử dụng để xác định nguyên nhân gây ra ngắt. Hãy đọc thanh ghi này, kết hợp với thông tin chi tiết trong hướng dẫn sử dụng của từng thiết bị giả lập để biết được nguồn gốc gây ra ngắt.

Cách thức viết chương trình phục vụ ngắt: để viết chương trình con phục vụ ngắt khi có sự kiện ngắt xảy ra, có thể dùng một trong các phương pháp sau:

- 1. Viết chương trình con phục vụ ngắt trong cùng một file nguồn
- 2. Viết chương trình con phục vụ ngắt trong file nguồn độc lập, và lưu trữ trong cùng một thư mục với chương trình chính. Sau đó, sử dụng tính năng trong mục Setting là "Assemble all files in directory"
- 3. Viết chương trình con phục vụ ngắt trong file nguồn độc lập, và lưu trữ trong cùng một thư mục bất kì. Sau đó, sử dụng tính năng trong mục Setting là "Exception Handler.."

BUG: Ghi nhận các lỗi của công cụ MARS

- 1. Giữa 2 lệnh syscall và lệnh jump, branch cần bổ sung thêm lệnh nop. Nếu không việc ghi nhận giá trị của thanh ghi PC vào EPC sẽ bị sai
- 2. Với các công cụ giả lập, nên bấm nút "Connect to MIPS" trước khi chạy giả lập. Nếu không, việc phát sinh sự kiện ngắt sẽ không xảy ra.

```
sb $t3, 0($t1)
     # No-end loop, main program, to demo the effective of
interrupt
Loop: nop
    nop
    nop
    nop
         Loop # Wait for interrupt
end main:
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
.ktext 0x80000180
     # Processing
syscall
     # Evaluate the return address of main routine
     # epc <= epc + 4
return: eret
                    # Return from exception
```

Home Assignment 3 - INTERRUPT & STACK

Study the following assembly program, in which

- 1. Main program enables 1 interrupt: from key matrix in Data Lab Sim
- 2. Main program only print a sequence number to console
- 3. Connect Data Lab Sim. Whenever user press a key button C, D, E, or F, an interrupt raises and print key scan-code to console

```
#-----
      # Loop an print sequence numbers
     xor
          $s0, $s0, $s0 # count = $s0 = 0
Loop: addi $s0, $s0, 1 # count = count + 1
syscall
prn_eol:addi
           $v0,$zero,11
           $a0,'\n'
                      # print endofline
     li
      syscall
sleep: addi
           $v0,$zero,32
          $a0,300
                      # sleep 300 ms
     1i
      syscall
                       # WARNING: nop is mandatory here.
      nop
            Loop
                       # Loop
end main:
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
.ktext 0x80000180
      # SAVE the current REG FILE to stack
      #-----
IntSR: addi $sp,$sp,4
sw $ra,0($sp)
                   # Save $ra because we may change it later
      addi $sp,$sp,4
                   # Save $at because we may change it later
          $at,0($sp)
      addi $sp,$sp,4
                   # Save $sp because we may change it later
          $v0,0($sp)
      sw
      addi $sp,$sp,4
                   # Save $a0 because we may change it later
      sw
          $a0,0($sp)
      addi $sp,$sp,4
                   # Save $t1 because we may change it later
          $t1,0($sp)
      sw
      addi $sp,$sp,4
                   # Save $t3 because we may change it later
          $t3,0($sp)
      # Processing
      #-----
prn_msg:addi $v0, $zero, 4
           $a0, Message
     la
      syscall
get_cod:li $t1, IN_ADRESS_HEXA_KEYBOARD
li $t3, 0x88  # check row 4 and re-enable bit 7
sb $t3, 0($t1)  # must reassign expected row
          $t1, OUT_ADRESS_HEXA_KEYBOARD
      li
         $a0,
$v0,34
     1b
                 0($t1)
prn_cod:li
      syscall
      li
           $v0,11
     li
            $a0,'\n'
                      # print endofline
          ______
      # Evaluate the return address of main routine
      # epc <= epc + 4
# RESTORE the REG FILE from STACK
```

```
restore:1w
             $t3, 0($sp)
                              # Restore the registers from stack
       addi $sp,$sp,-4
             $t1, 0($sp)
                             # Restore the registers from stack
       addi $sp,$sp,-4
             $a0, 0($sp)
       lw
                             # Restore the registers from stack
       addi $sp,$sp,-4
             $v0, 0($sp)
       lw
                             # Restore the registers from stack
       addi $sp,$sp,-4
             $ra, 0($sp)
                             # Restore the registers from stack
       lw
       addi $sp,$sp,-4
             $ra, 0($sp)
                             # Restore the registers from stack
       lw
       addi
             $sp,$sp,-4
return: eret
                               # Return from exception
```

Home Assignment 4 – MULTI INTERRUPT

Vietnamese support:

Thanh ghi số 13, status trong bộ đồng xử lý C0, chứa các thiết lập về tình trạng

ngai	•									1	1	θ	1	0	<u> </u>
	15	14	13	12	11	10			6	5	4	3	2	1	0
					KM	TC			Ì	Ехсер	otion	Code	e	K/U	IE
IE = 1 cho phép ngắt. $IE = 0$ vô hiệu hóa mọi hoạt động ngắt												ngắt			
K/U=1 hoạt động ở chế độ Kernel. $K/U=0$ hoạt động ở chế độ User															
Ngoại lệ do syscall, overflow, lệnh tạo ngắt mềm như teq teqi															
	Time Counter bộ đếm thời gian														
	Key Matrix														

Study the following assembly program, in which

- 1. Main program enables 2 interrupts simultaneously: from key matrix and time counter in Data Lab Sim
- 2. Main program do nothing with a deadloop
- 3. Connect Data Lab Sim. Whenever user press any key or time interval reachs, an interrupt raises and print key scan-code to console.

```
.eqv IN_ADRESS_HEXA_KEYBOARD 0xffff0012
.eqv COUNTER
                 0xFFFF0013  # Time Counter
.eqv MASK_CAUSE_COUNTER 0x00000400  # Bit 10: Counter interrupt
.eqv MASK_CAUSE_KEYMATRIX 0x00000800  # Bit 11: Key matrix
interrupt
.data
msg keypress: .asciiz "Someone has pressed a key!\n"
msg counter: .asciiz "Time inteval!\n"
# MAIN Procedure
.text
main:
        # Enable interrupts you expect
        # Enable the interrupt of Keyboard matrix 4x4 of Digital Lab
Sim
              $t1, IN ADRESS HEXA KEYBOARD
              $t3, 0x80 # bit 7 = 1 to enable
```

```
sb $t3, 0($t1)
     # Enable the interrupt of TimeCounter of Digital Lab Sim
     li $t1, COUNTER
     sb $t1, 0($t1)
     #-----
     # Loop an print sequence numbers
Loop:
     nop
     nop
     nop
sleep: addi $v0,$zero,32 # BUG: must sleep to wait for Time
Counter
     li
         $a0,200
                    # sleep 300 ms
     syscall
                     # WARNING: nop is mandatory here.
     nop
          Loop
end main:
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
.ktext 0x80000180
    #-----
IntSR:
     # Temporary disable interrupt
# no need to disable keyboard matrix interrupt
     # Processing
     #-----
get_caus:mfc0 $t1, $13 # $t1 = Coproc0.cause
IsCount: li $t2, MASK CAUSE COUNTER# if Cause value confirm
Counter..
     and $at, $t1,$t2
     beq $at,$t2, Counter_Intr
IsKeyMa:li
         $t2, MASK CAUSE KEYMATRIX # if Cause value confirm Key..
     and $at, $t1, $t2
     beq $at,$t2, Keymatrix Intr
others: j end process
                        # other cases
Keymatrix_Intr: li $v0, 4
                       # Processing Key Matrix Interrupt
     la $a0, msg_keypress
     syscall
     j end process
Counter_Intr: li $v0, 4 # Processing Counter Interrupt
     la $a0, msg_counter
     syscall
     j
        end process
end process:
     mtc0 $zero, $13  # Must clear cause req
en int: #-----en int: #-----
     # Re-enable interrupt
     li $t1, COUNTER
     sb $t1, 0($t1)
     # Evaluate the return address of main routine
     # epc <= epc + 4
```

Home Assignment 5 - KEYBOARD

Vietnamese support:

- Bộ xử lý MIPS cho phép tạo ra ngắt mềm, bằng lệnh teq, hoặc teqi
- Thiết bị Keyboard không tự động tạo ra ngắt khi có một phím được bẩm, mà người lập trình phải tự tạo ngắt mềm.

```
# ASCII code from keyboard, 1 byte
                         # Auto clear after lw
.eqv DISPLAY_READY 0xFFFF0008 # =1 if the display has already to do
                          # Auto clear after sw
.eqv MASK CAUSE KEYBOARD 0x0000034
                                # Keyboard Cause
.text
          li $k0, KEY_CODE
li $k1, KEY_READY
          li $s0, DISPLAY CODE
          li $s1, DISPLAY READY
loop:
         nop
WaitForKey: lw $t1, 0($k1) $t1 = [$k1] = KEY READY
         beq $t1, $zero, WaitForKey # if $t1 == 0 then Polling
MakeIntR: teqi $t1, 1  # if $t0 = 1 then raise an Interrupt
          j loop
# Interrupt subroutine
.ktext 0x80000180
get_caus: mfc0 $t1, $13 # $t1 = Coproc0.cause
IsCount: li $t2, MASK_CAUSE_KEYBOARD# if Cause value confirm
Keyboard..
          and $at, $t1,$t2
          beq $at,$t2, Counter_Keyboard
             end process
Counter Keyboard:
ReadKey: 1w $t0, 0($k0) # $t0 = [$k0] = KEY CODE
WaitForDis: lw $t2, 0($s1)
                                # $t2 = [$s1] = DISPLAY READY
          beq $t2, $zero, WaitForDis # if $t2 == 0 then Polling
Encrypt:
         addi $t0, $t0, 1
                               # change input key
ShowKey: sw $t0, 0($s0)
                               # show key
          nop
end process:
          next_pc: mfc0
```

Assignment 1

Create a new project, type in, and build the program of Home Assignment 1. Upgrade the source code so that it could defect all 16 key buttons, from 0 to F.

Assignment 2

Create a new project, type in, and build the program of Home Assignment 2.

Assignment 3

Create a new project, type in, and build the program of Home Assignment 3. Upgrade the source code so that it could defect all 16 key buttons, from 0 to F.

Assignment 4

Create a new project, type in, and build the program of Home Assignment 4.

Assignment 5

Create a new project, type in, and build the program of Home Assignment 5.

Conclusions

Before you finish the laboratory exercise, think about the questions below:

- What is polling?
- What are interrupts?
- What are interrupt routines?
- What are the advantages of polling?
- What are the advantages of using interrupts?
- What are the differences between interrupts, exceptions and traps?