

If DTR is LOW, toggling RTS from HIGH to LOW resets to run mode.
If RTS is HIGH, toggling DTR from LOW to HIGH resets to bootloader.

[illegible][illegible]

The image displays three identical circuit diagrams, each for a different relay (Relay-1, Relay-2, and Relay-3). Each circuit consists of a 5V power supply connected to a red LED (D2, D4, D6) through a 1K resistor (R9, R11, R13). The LED is connected to the base of a transistor (Q2, Q3, Q4) through a 1K resistor (R10, R12, R14). The transistor's emitter is grounded, and its collector is connected to the coil of the relay (K1, K2, K3) through a 1K resistor (R10, R12, R14). The relay coil is also connected to the 5V supply. A diode (D3, D5, D7) is connected in parallel with the relay coil, with its cathode to the 5V supply and its anode to the transistor collector. The relay's common terminal (COM) is connected to the 5V supply, and its normally open (NO) and normally closed (NC) terminals are connected to the 5V supply and ground, respectively. The relay is labeled SRD-05VDC-SL-C.

