

Xinhmo

Staff guide

FOR STAFF

Everything you need to run the booth at an event. Print it and keep it at the booth.

Before guests arrive

- 1 Plug in the **camera** with its **power adapter**, not just the battery. Switch it on and take the lens cap off. The lens switch stays on **AF**.
- 2 Plug in the **printer**, switch it on, and check it has paper and ink.
- 3 On the Mac, double-click **START-BOOTH**.
- 4 It checks the camera and the printer first. If something is wrong it says exactly what to do: follow the steps, press **Return**, and it checks again.
- 5 When both say **OK**, the booth opens on its menu: *Tap a layout to begin*.

Leave the small black Terminal window open behind the booth. It is what keeps the booth running.

The staff phone. Join the phone to the same Wi-Fi as the Mac, then open `http://Chaus-baby-.local:8080` and enter the staff code. Bookmark it: the address stays the same on any Wi-Fi. If it does not load, use the number address START-BOOTH prints under **ALL GOOD** (for example `http://10.11.20.247:8080`). Everything below is done from the phone.

How a session goes

Guest does	Booth shows
Taps a layout: Grand, Trio or Quad	A short get-ready screen
Poses	6 photos, a 7-second countdown each, <i>Hold still</i> as the camera fires
Taps their favourite photos	Anything they skip is filled in for them
Picks a frame design and a look	Keychains, charms and extra copies can be added here
Taps Done	A pickup code , for example <code>B6W</code>

After each group the booth **locks itself**, so the next group cannot walk into someone else's session.

Your job: the phone

When a group finishes

- 1 They tell you their **pickup code**.
- 2 Take payment. It is Zelle or cash only, and extra copies are \$3 each.
- 3 On the phone's **Orders** tab, tap their code, then the blue **Print** button (it says how many photos, and the amount to be paid). A print takes about a minute.
- 4 Hand over the print.
- 5 Tap **Start next session** at the top of the Orders tab to let the next group in.

Keychains and charms

Each keychain prints **two identical strips**, one for each side, and **one sheet holds two keychains**. Cut along the thin lines; the pickup code is printed under each strip, so a pile of them is easy to sort.

In the order, tap **Print keychains** (it says how many). Someone who comes back later for more: open their order, change the number with **+**, and print again. The price updates by itself.

Grand has no keychains or charms. A Grand print is one big sheet, so there is no strip to cut them from. The booth's menu says so, and the phone greys them out on Grand orders.

Paper and ink

The printer's paper tray holds **18 sheets**, and an ink cassette prints **36**. The booth counts both. The **Booth** tab shows how many are left, and a banner appears when they run low.

After you reload, tap **Paper or Ink** on the phone, so the count starts again.

The Booth tab

Control	Use it when
Restart camera	The camera shows as off or stops answering
Test print	You want to check the printer: it reprints the last sheet
Calibration sheet	Print edges look cut off; the person who set up the booth uses this
End current session	A group walked off halfway through
Shut down booth	The event is over

The top of the tab says which camera driver is running. It should say **Canon SDK**.

If something goes wrong

What you see	What to do
Phone shows Camera off	Is the camera on? Is the power adapter plugged in, or the battery charged? Turn it off, wait 5 seconds, on . Then tap Restart camera .
Booth says <i>No camera found</i>	Same as above.
Photos are blurry	People moved, or stood too close to the camera. Ask them to stand on the floor mark. More light helps.
A print does not come out	Check the paper tray and the ink. Turn the printer off for 5 seconds, then on .
Phone banner: prints are waiting	The printer has stopped. Same fix as above.
Phone says Offline	The phone lost the Wi-Fi. Reconnect it to the same network as the Mac.
Red banner: Test mode	The booth is not really printing. Call whoever set the booth up.
Booth screen is frozen or black	Wait 30 seconds; it restarts itself. If not, close the black window and double-click START-BOOTH .
Booth says it is out of storage	The Mac's disk is nearly full. Call whoever set the booth up.

No phone? Hold the **top-left corner** of the booth screen for **2 seconds** and enter the staff code. The same controls are there.

If you cannot fix something, take a photo of the screen and note the time. The booth keeps a log that can be read afterwards.

Turning it off

- 1 On the phone's **Booth** tab, tap **Shut down booth**, then confirm.
- 2 Switch off the printer and the camera.
- 3 Shut down the Mac.