
Power Connector

The 850 uses a standard Eurorack non-shrouded non-keyed power connector and comes with a standard 10 pin Eurorack power cable. The red stripe on the power cable indicates the position of the –12V conductor. When connecting the power cable ensure that the red stripe side of the cable is aligned with the thick line next to the power header on the PCB. Connect the 10 pin connector to the 850's power header and connect the 16 pin connector to your system's power bus board. The 850 is designed to withstand brief conditions of reverse power, but prolonged connection to reverse polarity may damage the protection diodes and require module servicing.

Please use care to avoid reverse polarity conditions.



Slew Input Jumper

Use the jumper connector on the back of the module to select the source of the normalized Slew circuit input.





S&H selected Clock selected

850 Eurorack Module

Operation Manual

