

	Phasenmodulation (PM)	Winkelmodulation (FM)
Eintonsignal:	$m_{PM}(t) = A_m \cdot \sin(\omega_m t)$ $\varphi(t) = \underbrace{k_P \cdot A_m}_{\beta_P} \cdot \sin(\omega_m t)$	$m_{FM}(t) = A_m \cdot \cos(\omega_m t)$ $\varphi(t) = \underbrace{\frac{k_F \cdot A_m}{\omega_m}}_{\beta_F} \cdot \sin(\omega_m t)$