



$$m_{SH}(t) = m_s(t) * \text{rect}_{T_s/2}(t)$$

$$M_{SH}(\omega) = M_s(\omega) \cdot T_s \cdot \frac{\sin\left(\frac{T_s}{2} \omega\right)}{\frac{T_s}{2} \omega}$$