init
state

initialised!

idle
state

no
data!

data
received!

check
range
state

range
error!

no
range
error!

range
error
state

store_in_buffer_state

range
error
logged!

flush_buffer_state

Comms Driver State Machine