Table of Contents

Read audio file	1
Noise	-
Noisy signal	
FIR Filter with unit variance noise	1
FIR Filter with a noise of variance 10	2
IIR filter	2
NLMS algorithms	2

```
clear;
clc;
close all;
```

Mohammad Javad Amin 401211193 Problem 2

Read audio file

Noise

```
n0=randn(size(s));
b=rand(1,5);
a=1;
n=filter(b,a,n0);
disp("please wait until all souds played")
please wait until all souds played
```

Noisy signal

```
x=s+n;
sound(x,Fs)
```

FIR Filter with unit variance noise

N:length of filter M: length of input signal alpha: mu tilde e: errors w: weights of filter

```
M = length(s);
N =10;
alpha = 1;
[~,e]=NLMS(n0,x,N,alpha,M);
```

```
pause(14)
sound(e,Fs)
```

FIR Filter with a noise of variance 10

```
n0 = sqrt(10).*randn(size(s));
n=filter(b,a,n0);

pause(14)
x=s+n;
sound(x,Fs)

[~,e]=NLMS(n0,x,N,alpha,M);
pause(14)
sound(e,Fs)
```

IIR filter

```
a= [1,0.5];
b=[1,-0.9];
n=filter(b,a,n0);

x=s+n;
[w,e]=NLMS(n0,x,N,alpha,M);
pause(14)
sound(e,Fs)

figure(1)
plot(x)
title('noisy signal')
figure(2)
plot(e)
title('out signal');
```

NLMS algorithms

```
function[w,e]=NLMS(inputs,d,N,alpha,M)
% e : error
% u_temp : because LMS run when the first sample arrive, we put M-1 zeros in
beging of inputs, if whe don't put this zeros we must wait to m sample arrive
    u_temp=[zeros(1,N-1),inputs'];
    e=zeros(1,M);
    w=zeros(1,N);
    for i=N:M
        u=u_temp(i:-1:i-N+1);
        y=dot(w,u);
        e(i-N+1)=d(i-N+1)-y;
        w = w + (alpha/(norm(u)^2))*e(i-N+1)*u;
end
    w=w';
```

end

Published with MATLAB® R2022b