Voltrieve charging guide

How to charge a Voltrieve at home and on the road, what it costs, and how to get the most out of the battery in winter.

Charging a Voltrieve at home

Most charging happens at home, overnight. The Voltrieve Home Charger (article number VA-9001) is a 22 kW wall box with a type 2 cable and app control. It costs 11 900 SEK or 1 090 EUR; installation by an electrician is extra. The car charges at the lower of the wall box rating and its own onboard charger.

Model	Battery	Onboard AC charger	Empty to full on a home charger
Voltrieve Spark	42 kWh	11 kW	about 3.8 hours
Voltrieve Lumen	61 kWh	11 kW	about 5.5 hours
Voltrieve Ragn	84 kWh	22 kW	about 3.8 hours
Voltrieve Fjord	84 kWh	22 kW	about 3.8 hours
Voltrieve Atlas	112 kWh	22 kW	about 5.1 hours

The portable charger with a household plug is for occasional use, such as a night at a summer cottage. It charges much more slowly and should not be used every day.

Charging a Voltrieve on the road

At a public AC charger, use the mode 3 type 2 cable. At a fast DC charger the cable is fixed to the charger. Every Voltrieve has a CCS2 charge port.

Model	Peak DC charging	10 to 80 % at a fast charger
Voltrieve Spark	95 kW	about 25 minutes
Voltrieve Lumen	135 kW	about 26 minutes
Voltrieve Ragn	240 kW	about 21 minutes
Voltrieve Fjord	240 kW	about 20 minutes
Voltrieve Atlas	320 kW	about 20 minutes

Charging slows down above 80 %, so on a long trip it is usually quicker to stop twice for 20 minutes than once for an hour. The route planner in the car picks the chargers and preconditions the battery on the way.

What charging a Voltrieve costs

The examples use these electricity prices. Your own prices depend on your contract, the time of day and the charging network.

Electricity price	Sweden	EU
At home, per kWh	1.80 SEK	0.30 EUR
Public AC, per kWh	4.50 SEK	0.49 EUR
Public DC fast charging, per kWh	6.90 SEK	0.69 EUR

Model	Energy use (WLTP)	100 km charged at home, Sweden	100 km fast charged, Sweden	100 km charged at home, EU	100 km fast charged, EU
Voltrieve Spark	13.5 kWh per 100 km	24 SEK	93 SEK	4.05 EUR	9.31 EUR
Voltrieve Lumen	13.4 kWh per 100 km	24 SEK	92 SEK	4.02 EUR	9.25 EUR
Voltrieve Ragn	15.8 kWh per 100 km	28 SEK	109 SEK	4.74 EUR	10.90 EUR
Voltrieve Fjord	14.6 kWh per 100 km	26 SEK	101 SEK	4.38 EUR	10.07 EUR
Voltrieve Atlas	18.4 kWh per 100 km	33 SEK	127 SEK	5.52 EUR	12.70 EUR

Charging a Voltrieve in winter

- **Precondition before you leave.** Set a departure time in the app and the car warms the cabin and the battery while it is still plugged in, so the energy comes from the grid and not from the battery.
- **Precondition before a fast charge.** Choose the charger in the route planner and the car warms the battery on the way. A cold battery charges much more slowly.
- **Use the heat pump.** Voltrieve Lumen, Voltrieve Ragn, Voltrieve Fjord and Voltrieve Atlas have a heat pump as standard. The Voltrieve Spark gets one with the Winter pack, standard on Spark Plus and Prime.
- **Expect less range.** In real winter conditions the range is often 20 to 30 % below the WLTP figure. Seat and steering wheel heating use less energy than heating the whole cabin.
- **Park inside when you can.** A battery that stays above freezing keeps more of its range and charges faster.
- **Charge to 80 % every day** and to 100 % only before a long trip.