

Debugging

• For debugging purposes you can use the serial interface with command SerialLog 4 and the Arduino IDE set to 115200 baud (19200 for Sonoff Dual) and both NL & CR or the web console with command WebLog 4.

To aid in finding the IP address of sonoff the network name will be <MQTT_TOPIC>-<last 4 decimal chars of MAC address>. So the default name is sonoff-1234. Another option is MQTT command Status 5.

© 2017 GitHub, Inc. Terms Privacy Security Status Help Contact GitHub API Training Shop Blog About

1 of 1 04-Feb-17 10:01 AM