Chapter 2 - Fundamental Concepts Lecture 20

Sections 6.3 and 2.6

Introduction to Fluid Mechanics

Mechanical Engineering and Materials Science University of Pittsburgh Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume



Student Learning Objectives

Students should be able to:

▶ Determine the relationship between strain rate and shear stress in terms of viscosity

Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume



Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting or a Control Volume

2.6 Viscosity

► Recall the strain rate tensor:

$$\begin{split} \underline{\epsilon}_{ij} &= \begin{bmatrix} \epsilon_{xx} & \epsilon_{xy} & \epsilon_{xz} \\ \epsilon_{yx} & \epsilon_{yy} & \epsilon_{yz} \\ \epsilon_{zx} & \epsilon_{zy} & \epsilon_{zz} \end{bmatrix} \\ &= \begin{bmatrix} \frac{\partial u}{\partial x} & \frac{1}{2} \left(\frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \right) & \frac{1}{2} \left(\frac{\partial u}{\partial z} + \frac{\partial w}{\partial x} \right) \\ \frac{1}{2} \left(\frac{\partial v}{\partial x} + \frac{\partial u}{\partial y} \right) & \frac{\partial v}{\partial y} & \frac{1}{2} \left(\frac{\partial v}{\partial z} + \frac{\partial w}{\partial y} \right) \\ \frac{1}{2} \left(\frac{\partial w}{\partial x} + \frac{\partial u}{\partial z} \right) & \frac{1}{2} \left(\frac{\partial w}{\partial y} + \frac{\partial v}{\partial z} \right) & \frac{\partial w}{\partial z} \end{bmatrix} \end{split}$$

▶ For all intents and purposes, quantifying the strain generated within a fluid is difficult. What if we convert strain to stress, and stress to force? Thus, we can see how an applied force causes changes in velocity.



Stress Fields

- ► Recall from statics that it is important to look at strain, as well as stress, within the material.
- Strain is a result of stress, which can be in the form of surface forces and body forces.
- ▶ These two types of forces lead to two types of stress:
 - 1. Normal stress component of force acting normal to the surface, and can be defined as:

$$\sigma_n = \lim_{\partial A \to 0} \frac{\partial F_n}{\partial A} = \frac{F_n}{A}$$

2. Shear stress - component of force acting perpendicular to the surface, and can be defined as:

$$\tau = \lim_{\partial A \to 0} \frac{\partial F_t}{\partial A} = \frac{F_t}{A_n}$$

Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume


2.6 Viscosity



Slide 4 of 14 ©Barry, 2022

Stress Fields

► Each face of a differential volume is experiencing three stresses: one normal and two shear.



Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume



Stress Fields

- ▶ The first subscript is the direction in which the face of the volume is located; the second subscript is the direction in which the stress is acting. For example, τ_{xy} means the shear stress acting on a plane that is mutually orthogonal to the x-direction, and the stress is in the y-direction.
- ► Therefore, we can define all stress acting on a point of interest in tensor form: notation:

$$\underline{\underline{\sigma}} = \begin{bmatrix} \sigma_{xx} & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_{yy} & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_{zz} \end{bmatrix}$$

- ► The first, second, and third rows are all the forces acting on the plane that is mutually orthogonal to the *x*-, *y*-, and *z*-directions, respectively.
- ▶ The first, second, and third columns are the directions in which these stress are acting: x, y, and z.

Chapter 2 -Fundamental Concepts

MEMS 0071


Learning Objectives

6.3 Forces Acting on a Control Volume



Viscosity and Shear Stress

- ▶ We have to define the shear stress that is acting on the differential volume. Imagine the following situation, where we have a fluid constrained between a moving top plate that has some velocity magnitude V, and an immovable bottom plate.
- In this situation, we are imparting a shear stress onto this fluid. We call this is a shear driven flow, or Couette flow.



Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume




Viscosity and Shear Stress

▶ We can define the shear stress as:

$$\tau_{yx} = \lim_{\partial A_y \to 0} \frac{\partial F_x}{\partial A_y} = \frac{dF_x}{dA_y}$$

▶ To look at the deformation over some time interval:



► The shear stress, from a classical mechanics perspective is:

$$\tau_{yx} \approx \partial \theta = \frac{\partial u \partial t}{\partial y}$$

Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume



Viscosity and Shear Stress

During some time interval dt, $d\theta$ is the angle between the normal in the y-direction and the line representing the velocity gradient. We can express our deformation rate as as:

$$\frac{\partial \theta}{\partial t} = \frac{\partial u}{\partial y} \implies \frac{d\theta}{dt} = \frac{du}{dy}$$

- Shearing will generate motion in the x-direction, and that motion will vary in the y-direction, i.e. u = u(y).
- ▶ We can conclude that the rate of deformation of a fluid is equivalent to the velocity gradient, and it can be shown that said deformation is proportional to the velocity gradient:

$$au_{yx} \propto \frac{du}{dy}$$

Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives


- 6.3 Forces Acting on a Control Volume
- 2.6 Viscosity



Classifications of Fluids

The constant of proportionality that relates shear stress to the velocity gradient is called dynamic viscosity (μ) [Pa-s]:

- Fluids exhibit various behaviors, all attributed to how μ varies with respect to the $\dot{\gamma}$.
- Fluids where $\dot{\gamma}$ is linearly proportional to τ are referred to as Newtonian fluids.



Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

- 6.3 Forces Acting on a Control Volume
- 2.6 Viscosity



Slide 10 of 14

©Barry, 2022

Non-Newtonian Fluids

- ▶ When shear stress is not directly proportional to the rate of deformation, the fluid is **non-Newtonian**.
- ► The **power law** commonly describes non-Newtonian fluids:

$$\tau_{yx} = k \left| \frac{du}{dy} \right|^{n-1} \frac{du}{dy} = \eta \frac{du}{dy}$$

- ► The first term on the RHS of the second term of the power law equation is the apparent viscosity
- ▶ If $\eta < 1$, shear thinning (pseudoplastic).
- ▶ If $\eta > 1$, shear thickening (dilatant).

Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume



Non-Newtonian Fluids

- ▶ Dilatant shear thickening fluid that exhibits and increase in resistance to flow at higher strain rates, i.e. corn starch solution.
- ▶ Pseudoplastic shear thinning fluid that exhibits less resistance to flow at higher strain rates, e.g. latex paint, blood plasma.
- ▶ Plastic a shear thinning fluid that exhibits very strong thinning
- ▶ Bingham plastic limiting case of a plastic fluid that requires a finite yield stress before flow can be initiated, e.g. drilling fluids, toothpaste, ketchup $\rightarrow \tau_{yx} = \tau_y + \mu_p du/dy$

Chapter 2 -Fundamental Concepts

MEMS 0071

earning Objectives

6.3 Forces Acting on a Control Volume



Example #1

• Given a Newtonian fluid, determine the velocity profile u(y) of the fluid under Couette flow conditions. Express your answer in terms of the top plate velocity V, the height of the channel h and the distance from the bottom stationary plate y.

Chapter 2 -Fundamental Concepts

MEMS 0071

earning Objectives

6.3 Forces Acting on a Control Volume



Example #1

Chapter 2 -Fundamental Concepts

MEMS 0071

Learning Objectives

6.3 Forces Acting on a Control Volume

