

# UEFI & EDK II Training

EDK II Debugging with Windows Lab – Simics® QSP

tianocore.org

Copy and Paste LabGuide.md




## Lesson Objective

- Using PCDs to Configure DebugLib LAB 1 & 2
- Change the DebugLib instance to modify the debug output LAB 3 & 4
- Debug EDK II Boot Flow LAB 5



## Catch up Lab 0

In this lab, you'll start where the previous Writing UEFI Applications left off.





### Lab 0: Catch up from previous lab (1)

Skip the Catch up Lab if Lab Writing UEFI App Lab completed (UEFI App Lab Guide)

- Perform Lab Setup from previous Labs (<u>Lab Guide</u>)
- Copy contents of C:../FW/LabSampleCode/SampleAppDebug/, directory "MyPkg", to C:/FW/edk2-ws/edk2/
- Open
   edk2-platforms/Platform/Intel/SimicsOpenBoardPkg/BoardX58Ich10/OpenBoardPkg.dsc
- Add the following in the [Components . . .] section, Hint: add after comment:

```
# Add new modules here
MyPkg/SampleApp/SampleApp.inf
```

Save and close the file OpenBoard.dsc



## Lab 0: Catch up from previous lab (2)


Copy the UefiAppLab.vhd

From:

.../Lab\_Material\_FW/FW/LabSampleCode/ AppLab/UefiAppLab.vhd

to

%USERPROFILE%\AppData\Local\Programs\Simics\simics-qsp-x86-6.0.57\targets\qsp-x86\images





## Lab 0: Catch up from previous lab (3)

**Update** the Simics Script to Use the UefiAppLab.vhd image as a file system

Edit the file: qsp-modern-core.simics from

#### **%USERPROFILE%**\

\AppData\Local\Programs\Simics\simics-qsp-cpu-6.0.4\targets\qsp-x86\qsp-modern-core.simics

Add the following Line:

\$disk1\_image="%simics%/targets/qsp
-x86/images/UefiAppLab.vhd"

Before the "run-command-file" line

Save qsp-modern-core.simics

File: qsp-modern-core.simics

```
Decl{
decl {
 ! Script that runs the Quick Start Platform (QSP) with a modern
 ! processor core.

params from "%simics%/targets/qsp-x86/qsp-clear-linux.simics"
default cpu_comp_class = "x86QSP2"
default num_cores = 2
default num_threads = 2
}
$disk1_image="%simics%/targets/qsp-x86/images/UefiAppLab.vhd"

run-command-file "%simics%/targets/qsp-x86/qsp-clear-linux.simics"
```



## Lab 1 – Adding Debug Statements

In this lab, you'll add debug statements to the previous lab's SampleApp UEFI Shell application





### Lab 1: Add debug statements to SampleApp

- 1. Mount the UefiAppLab.vhd using Disk Manager: How to Mount VHD
- 2. Open C:/FW/edk2-ws/edk2/MyPkg/SampleApp/SampleApp.c
  - Add the following to the include statements at the top of the file after below the last "include" statement:

#include <Library/DebugLib.h>



### Lab 1: Add debug statements to SampleApp

Locate the UefiMain function. Then copy and paste the following code after the "EFI\_INPUT\_KEY KEY;" statement: and before the first Print() statement as shown in the screen shot below:

LabGuide.md for Copy and paste

```
DEBUG ((0xffffffff, "/n/nUEFI Base Training DEBUG DEMO/n"));
DEBUG ((0xffffffff, "0xffffffff USING DEBUG ALL Mask Bits Set/n") );
                       " 0x%08x USING DEBUG DEBUG INIT/n" , (UINTN)(DEBUG INIT)) );
DEBUG ((DEBUG INIT,
                       " 0x%08x USING DEBUG_WARN/n", (UINTN)(DEBUG_WARN))
DEBUG ((DEBUG WARN,
                       " 0x%08x USING DEBUG_LOAD/n", (UINTN)(DEBUG_LOAD))
DEBUG ((DEBUG LOAD,
                       " 0x%08x USING DEBUG DEBUG_FS/n", (UINTN)(DEBUG_FS)) );
DEBUG ((DEBUG FS,
                       " 0x%08x USING DEBUG_POOL/n", (UINTN)(DEBUG_POOL)) );
DEBUG ((DEBUG POOL,
                       " 0x%08x USING DEBUG DEBUG_PAGE/n", (UINTN)(DEBUG_PAGE)) );
DEBUG ((DEBUG PAGE,
                       " 0x%08x USING DEBUG DEBUG_INFO/n", (UINTN)(DEBUG_INFO))
DEBUG ((DEBUG INFO,
DEBUG ((DEBUG_DISPATCH, " 0x%08x USING DEBUG DEBUG_DISPATCH/n", (UINTN)(DEBUG_DISPATCH)));
DEBUG ((DEBUG VARIABLE, " 0x%08x USING DEBUG DEBUG VARIABLE/n", (UINTN)(DEBUG VARIABLE)));
DEBUG ((DEBUG BM,
                       " 0x%08x USING DEBUG_BM/n", (UINTN)(DEBUG_BM)) );
                       " 0x%08x USING DEBUG_BLKIO/n", (UINTN)(DEBUG_BLKIO)) );
DEBUG ((DEBUG BLKIO,
                       " 0x%08x USING DEBUG DEBUG_NET/n", (UINTN)(DEBUG_NET)) );
DEBUG ((DEBUG NET,
                       " 0x%08x USING DEBUG DEBUG UNDI/n", (UINTN)(DEBUG UNDI)) );
DEBUG ((DEBUG UNDI,
DEBUG ((DEBUG LOADFILE, " 0x%08x USING DEBUG DEBUG LOADFILE/n", (UINTN)(DEBUG LOADFILE)));
                       " 0x%08x USING DEBUG_EVENT/n", (UINTN)(DEBUG_EVENT)) );
DEBUG ((DEBUG EVENT,
                       " 0x%08x USING DEBUG DEBUG_GCD/n", (UINTN)(DEBUG_EVENT)) );
DEBUG ((DEBUG GCD,
                       " 0x%08x USING DEBUG_CACHE/n", (UINTN)(DEBUG_CACHE)) );
DEBUG ((DEBUG CACHE,
DEBUG ((DEBUG VERBOSE,
                       " 0x%08x USING DEBUG DEBUG VERBOSE/n", (UINTN)(DEBUG VERBOSE)) );
                       " 0x%08x USING DEBUG_ERROR/n", (UINTN)(DEBUG_ERROR)) );
DEBUG ((DEBUG ERROR,
```

SAVE and CLOSE SampleApp.c



### Update UefiAppLab.vhd File

## Build the Simics QSP Board At the VS Command Prompt, Build BoardX58Ich10

- \$> cd C:\FW\edk2-ws\edk2-platforms\Platform\Intel\
- \$> python build\_bios.py -p BoardX58Ich10 -t VS20XX


### Copy

C:\FW\edk2-ws\Build\SimicsOpenBoardPkg\BoardX58Ich10\DEBUG\_VS2015x86\X64\SampleApp.efi

#### To

#### X:\UEFIAPPLAB\

(where X is the VHD Drive)



**Build Directory** 

VHD Disk



### Lab 1: Build, Run and Test Result

### **Open** another Windows Command Prompt

```
$> cd simics-projects\my-simics-project-1
```

### Run the qsp-modern-core script:

```
$> .\simics targets/qsp-x86/qsp-modern-core.simics
simics> run
```

(Press "F2" at the logo, then Select "Boot Manger" followed by "EFI Internal Shell")

### Invoke SampleApp at the Shell prompt

```
Shell> Fs1:
FS1:\> SampleApp
```

See that the output from the Debug statements goes to the Simics Serial Console

**Exit** Simics simics > Stop then simics > quit


```
Loading driver at 0x000DD279000 EntryPoint=0x000DD279344 SampleApp.efi
InstallProtocolInterface: BC62157E-3E33-4FEC-9920-2D3B36D750DF DDF99818
ProtectUefiImageCommon - 0xDDF901C0
    - 0x0000000DD279000 - 0x000000000004020
InstallProtocolInterface: 752F3136-4E16-4FDC-A22A-E5F46812F4CA DF303818

>>>>>[UefiMain] Entry point: 0xDD279560 <<<<<
UEFI Base Training DEBUG DEMO
0xffffffff USING DEBUG ALL Mask Bits Set
0x00000001 USING DEBUG DEBUG_INIT
0x000000002 USING DEBUG DEBUG_WARN
0x00000004 USING DEBUG DEBUG_LOAD
0x00000004 USING DEBUG DEBUG_FS
0x000000040 USING DEBUG DEBUG_FS
0x000000040 USING DEBUG DEBUG_INFO
0x800000000 USING DEBUG DEBUG_ERROR
FSOpen: Open '\' Success
```



# Lab 2 – Changing PCD Value

In this lab, you'll learn how to use PCD values to change debugging capabilities.





## Lab 2: Change PCDs for SampleApp

### Open

C:/FW/edk2-ws/edk2-platforms/Platform/Intel/SimicsOpenBoardPkg/BoardX58Ich10/OpenBoardPkg.dsc
Replace MyPkg/SampleApp/SampleApp.inf with the following:

```
MyPkg/SampleApp/SampleApp.inf {
     <PcdsFixedAtBuild>
        gEfiMdePkgTokenSpaceGuid.PcdDebugPropertyMask|0xff
        gEfiMdePkgTokenSpaceGuid.PcdDebugPrintErrorLevel|0xffffffff
}
```

Save and close OpenBoardPkg.dsc

<u>LabGuide.md</u> for Copy and paste



### Lab 2: Build and Test SampleApp

board.mb.sb.com[0] - serial console

- 1. At the VS Command Prompt, Re-Build BoardX58Ich10
  - \$> Cd C:\FW\edk2-ws\edk2-platforms\Platform\Intel\
  - \$> python build bios.py -p BoardX58Ich10 -t VS20XX
- 2. Copy SampleApp.efi from the build directory to the VHD Disk

Copy ..\Build\SimicsOpenBoardPkg\BoardX58Ich10\DEBUG\_VS20XX\X64\SampleApp.efi UefiAppLab Disk

3. Run the qsp-modern-core script from Windows Command Predit View Settings

```
$> .\simics targets/qsp-x86/qsp-modern-core.simics
simics> run
```

4. At the UEFI Shell prompt

```
Shell> Fs1:
FS1:\> SampleApp.efi
```

See that the output from ALL the Debug statements goes to the Simics Serial Console

5. Exit Simics simics > stop, simics > quit

```
JEFI Base Training DEBUG DEMO
∂xffffffff USING DEBUG ALL Mask Bits Set
0x00000001 USING DEBUG DEBUG INIT
0x00000002 USING DEBUG DEBUG WARN
0x00000004 USING DEBUG DEBUG LOAD
0x00000008 USING DEBUG DEBUG FS
0x00000010 USING DEBUG DEBUG POOL
0x00000020 USING DEBUG DEBUG PAGE
0x00000040 USING DEBUG DEBUG INFO
0x00000080 USING DEBUG DEBUG DISPATCH
0x00000100 USING DEBUG DEBUG VARIABLE
0x00000400 USING DEBUG DEBUG BM
0x00001000 USING DEBUG DEBUG BLKIO
0x00004000 USING DEBUG DEBUG NET
0x00010000 USING DEBUG DEBUG UNDI
0x00020000 USING DEBUG DEBUG LOADFILE
0x00080000 USING DEBUG DEBUG EVENT
0x00080000 USING DEBUG DEBUG GCD
0x00200000 USING DEBUG DEBUG CACHE
0x00400000 USING DEBUG DEBUG VERBOSE
0x80000000 USING DEBUG DEBUG ERROR
FSOpen: Open '\' Success
```



# Lab 3 – Library Instances for Debugging

In this lab, you'll learn how to add specific debug library instances.





## Lab 3: Using Library Instances for Debugging

Save and close OpenBoardPkg.dsc



### Lab 3: Build and Test SampleApp

- 1. At the VS Command Prompt, Re-Build BoardX58Ich10
  - \$> Cd C:\FW\edk2-ws\edk2-platforms\Platform\Intel\
  - \$> python build\_bios.py -p BoardX58Ich10 -t VS20XX
- 2. Copy SampleApp.efi from the build directory to the VHD Disk Copy ..\Build\SimicsOpenBoardPkg\BoardX58Ich10\DEBUG VS20XX\X64\SampleApp.efi UefiAppLab Disk
- 3. Run the qsp-modern-core script from Windows Command Prompt:

```
$> .\simics targets/qsp-x86/qsp-modern-core.simics board.mb.gpu.vga - graphics console
simics> run
```

Edit View Settings

4. At the UEFI Shell prompt

Shell> Fs1: FS1:\> SampleApp.efi

See that the output from the Debug statements now goes to the Simics VGA console

5. Exit Simics simics > stop, simics > quit

Shell> fs1: FS1:\> SampleApp.efi >>>> [UefiMain] Entry point: 0xDD2F4670 <<<<< **UEFI Base Training DEBUG DEMO** Oxffffffff USING DEBUG ALL Mask Bits Set 0x00000040 USING DEBUG DEBUG\_INFO 0x80000000 USING DEBUG DEBUG\_ERROR Sustem Table: 0xDEFED018



# Lab 4: Null Instance of DebugLib

In this lab, you'll change the DebugLib to the Null instance.





### Lab 4: Using Null Library Instances

Save and close OpenBoardPkg.dsc



### Lab 4: Build and Test SampleApp

FSOpen: Open '\' Success

- 1. At the VS Command Prompt, Re-Build BoardX58Ich10
  - \$> Cd C:\FW\edk2-ws\edk2-platforms\Platform\Intel\
  - \$> python build\_bios.py -p BoardX58Ich10 -t VS20XX
- 2. Copy SampleApp.efi from the build directory to the VHD Disk
  Copy ..\Build\SimicsOpenBoardPkg\BoardX58Ich10\DEBUG\_VS20XX\X64\SampleApp.efi UefiAppLab Disk
- 3. Run the qsp-modern-core script from Windows Command Prompt:

```
$> .\simics targets/qsp-x86/qsp-modern-core.simics
simics> run
```

4. At the UEFI Shell prompt

```
Shell> Fs1:
FS1:\> SampleApp.efi
```

See that there is **NO** Debug output

5. Exit Simics simics > stop, simics > quit

```
■ board.mb.gpu.vga - graphics console

Edit View Settings

Shell> fs1:
FS1:\> SampleApp.efi
System Table: 0xDEFED018

Press any Key to continue:
Enter text. Include a dot ('.') in a sentence then ⟨Enter⟩ to exit:
FS1:\>
■ board.mb.sb.com[0] - serial console

Edit View Settings
InstallProtocolInterface: 5B1B31A1-9562-11D2-8E3F-00A0C969723B DDF3D040
Loading driver at 0x000DDD38000 EntryPoint=0x000DDD382DC SampleApp.efi
InstallProtocolInterface: BC62157E-3E33-4FEC-9920-2D3B36D750DF DDF41118

ProtectUefiImageCommon - 0xDDF3D040
- 0x00000000DDD38000 - 0x000000000002660
InstallProtocolInterface: 752F3136-4E16-4FDC-A22A-E5F46812F4CA DF303498
```



# Lab 5: Debugging EDK II add Debug to Boot Flow

In this lab, you'll learn how to add Debug statements to the EDK II Boot flow and check the debug log output





### Lab 5: Debug Boot Flow

Edit the MdeModulePkg/Core/Pei/PeiMain/PeiMain.c

Add a "DEBUG" print ~line 489 before the call to the PeiDispatcher:

```
DEBUG((DEBUG_INFO, "**** ***** *****Before call to Pei Dispatcher ***** ***** **** **** 'n"));
```

#### Save PeiMain.c

```
// Call PEIM dispatcher
// DEBUG((DEBUG_INFO, "**** ***** *****Before call to Pei Dispatcher **** ***** *****\n"));
PeiDispatcher (SecCoreData, &PrivateData);

491
```



### Lab 5: Build and Test the Boot Flow

- 1. At the VS Command Prompt, Re-Build BoardX58Ich10
  - \$> Cd C:\FW\edk2-ws\edk2-platforms\Platform\Intel\
  - \$> python build\_bios.py -p BoardX58Ich10 -t VS20XX
- 2. Copy the Simics QSP Board .FD file

C:\fw\edk2-ws\Build\SimicsOpenBoardPkg\BoardX58Ich10\DEBUG\_VS20XX\FV\BOARDX58ICH10.fd To

**%USERPROFILE%\AppData\Local\Programs\Simics\simics-qsp-x86-6.0.57\targets\qsp-x86\images** 

3. Run the qsp-modern-core script from Windows Command Prompt:

\$> .\simics targets/qsp-x86/qsp-modern-core.simics
simics> run
board.mb.sb.com[0] - serial console

- 4. Scroll back in the Simics Serial Console to find the Debug statement before the PEI Dispatcher.

  This would be a place to debug a PEIM with a Debugger and add a "CpuDeadLoop" or "CpuBreakPoint"
- 5. Exit Simics simics > stop, simics > quit

www.tianocore.org



## Summary

- Using PCDs to Configure DebugLib LAB 1 & 2
- Change the DebugLib instance to modify the debug output LAB 3 & 4
- Debug EDK II Boot flow- LAB 5

24







### Return to Main Training Page



Return to Training Table of contents for next presentation link





### **ACKNOWLEDGEMENTS**

Redistribution and use in source (original document form) and 'compiled' forms (converted to PDF, epub, HTML and other formats) with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code (original document form) must retain the above copyright notice, this list of conditions and the following disclaimer as the first lines of this file unmodified.

Redistributions in compiled form (transformed to other DTDs, converted to PDF, epub, HTML and other formats) must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS DOCUMENTATION IS PROVIDED BY TIANOCORE PROJECT "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL TIANOCORE PROJECT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2022, Intel Corporation. All rights reserved.