

FIELD SERVICE REPORT

Technical Maintenance & Equipment Inspection

Report ID: SR-20260927-190717

Date: 2026-09-27

1. CLIENT & SITE DETAILS

Client Name: +564+456+456
Contact Person: jkvfghgc

Site / Branch: yutyuit
Contact Phone: jkhouihgou

2. MACHINE SPECIFICATIONS

Equipment Model: iohiy8
Operating Hours: 11
Serial Number: ihioho
Service Type: Preventive Maintenance

3. ISSUE DESCRIPTION & ROOT CAUSE

2165

4. ACTIONS TAKEN & REMARKS

665465

5. REPLACED / REQUIRED SPARE PARTS

Part Number	Description	Qty	Status
6565		1	Installed

6. SITE & FAULT PHOTOGRAPHIC EVIDENCE (1 Photos)

Service Training 40 No function 41 Feedback of intermediate circuit voltage power unit pump motor 42 Feedback phase voltage 12 from power unit 141 43 Output relay driver 1 (relay 302 stop light) 44 Output relay driver 2 (relay 303 sensor function) 45 ISD L for LLC diagnosis 46 CAN L from power unit 141, 142 47 No function 48 ISD L for diagnosis function 49 Supply voltage 10 V for position 50 Enable non-halt signal from power unit 241 51 Control speed (ISD) 52 Parameter truck signal switch 155 transverse seat position 53 Signal from stop pedal switch 155 transverse truck seat position 155 54 No function 55 Channel A speed sensor 152 56 Channel B speed sensor 152 57 No function 58 No function 59 No function 60 Supply voltage 15 V for accelerator 61 Feedback phase voltage 11 from power unit 142 62 Feedback phase voltage 13 from power unit 141 63 Output relay driver 3 (relay 304 of power unit 140 make) 64 Output relay driver 4 (relay 305 stop light) 65 ISD L for LLC diagnosis 66 CAN L from power unit 141, 142 67 No function 68 ISD L for diagnosis function 69 Negative safety relay for position 70 Negative safety relay for accelerator 71 Control speed (ISD) 72 Parameter truck signal switch 157 normal seat position 73 No function 74 Signal for speed reduction function 75 Signal from stop pedal switch, single pedal 1513 76 Channel B speed sensor 151 77 No function 78 No function 79 No function 80 Feedback phase voltage 12 from power unit 142 81 Feedback phase voltage 13 from power unit 141 82 Drive signal position filling 83 Drive signal position filling 84 Drive signal position filling 85 No function 86 Signal speed reduction LLC from composite instrument 87 Feedback signal from sensor ISD steering control valve 88 No function 89 Collecting proportional valve 216 aux hydraulics 14	Service Training 90 Drive signal position aux hydraulics 2 91 No function 92 No function 93 Signal for switch-controlled speed reduction LLC 94 No function 95 No function 96 Collecting proportional valve 215 aux hydraulics 18 97 Reference signal position filling 98 Reference signal position filling 99 Reference signal position filling 100 Reference signal position filling 101 Channel A speed sensor 255 102 No function 103 No function 104 Collecting proportional valve 216 aux hydraulics 24 105 Reference signal position aux hydraulics 2 106 No function 107 No function 108 No function 109 Collecting proportional valve 212 filling 110 Collecting proportional valve 217 aux hydraulics 28 111 Negative safety relay for hydraulic valve coil activation 112 Collecting safety valve lowering 219 113 Battery positive for safety relay LLC 114 Collecting safety valve 219 115 Positive safety voltage, valve coil 116 Collecting proportional valve 211 filling 117 Collecting proportional valve 213 forward filling 118 Collecting proportional valve 214 backward filling 6.8.3 TRACTION FUNCTION A 24 V supply voltage is supplied to the controller through X13.5. The voltage is generated by the voltage transformer 10. The negative signal for the controller is effected via X13.2. In addition, another battery voltage is supplied to the controller through X13.6. In the controller, this connection is connected to the common of the traction relay. After recovery to the safety relay is activated, position the relay voltage is connected to the coil of the main contactor X1 through X13.3. Once the intermediate circuit capacitors have been charged, the main contactor is activated via X13.1. To protect the contactor coil from overheating, the negative signal is pulled. This reduces the voltage at the contactor coil between voltage 48 V to a value of approx. 20 V.
---	---

7. VERIFICATION & SIGN-OFF

Service Engineer: 6685464

Customer Representative: jlhfutkdysdydjxyrf

Signature: _____ - Signature: _____ -