Cabin Lifecycle DFDs

Leon Starr
2025-10-14/ v0.4

A28

Changing destination

```
~.Go to floor( Dest floor: ^new dest )? {
    Cabin redirected( Updated dest: ^new dest ) -> /R53/Transfer
    Change requested -> me
}
```

Go to floor

new dest

ACTN5

External operation

Decision

ACTN1

/R53/Transfer

_5_true   _5_false

me

Change requested

F1

ACTN2

Traverse

Signal Instance

Signal Completion

ACTN3

ACTN4

Cabin redirected