Cabin Lifecycle DFDs

Leon Starr
2025-10-14/ v0.5

A28

Changing destination

~.Go to floor(Dest floor: ∧new dest)? {
    Cabin redirected(Updated dest: ∧new dest) -> /R53/Transfer
    Change requested -> me
}

Go to floor

new dest

F2

ACTN5

_1_stopping

Operation Call

Decision

F3

ACTN1

/R53/Transfer

me

_5_true   _5_false

Change requested

F1

ACTN2

Traverse

Signal Instance

Signal Completion

ACTN3

ACTN4

Cabin redirected