

Wiring - Blink ESP32

No external component is required. On common ESP32 Dev Module boards the built-in LED is often on GPIO2, but the exact board revision must be checked if no LED activity is visible.

Test

1. Select the ESP32 Dev Module target.
2. Upload at 115200 baud.
3. Open Serial Monitor.
4. Observe LED ON/OFF messages every 500 ms.