

Nimbus Home Hub - User Manual

Nimbus Labs (fictional company) - Model NH-200 - Revision 3.1

1. Overview

The Nimbus Home Hub is a fictional smart-home controller that connects your lights, locks, thermostats and sensors through one app. It supports Wi-Fi 6 (2.4 and 5 GHz), Zigbee 3.0 and Bluetooth 5.2, and handles up to 120 connected devices.

2. What is in the box

- Nimbus Home Hub NH-200
- USB-C power adapter (15 W)
- Ethernet cable (1 m)
- Quick start card

3. First-time setup

- Plug in the hub and wait for the LED to pulse blue (about 60 seconds).
- Install the Nimbus app and create an account.
- In the app, tap Add Device and scan the QR code under the hub.
- Choose your Wi-Fi network and enter the password.
- When the LED turns solid green, setup is complete.

4. Factory reset

If you sell or give away the hub, erase your data first. To factory reset: press and hold the reset button on the back of the unit for 10 seconds until the LED blinks amber, then release. The hub reboots and restores factory defaults in about 2 minutes. All paired devices and your account link are removed.

5. Troubleshooting

- LED solid red: no internet - check the Ethernet cable or Wi-Fi password.
- Devices drop offline: move the hub away from microwaves and thick walls.
- App cannot find the hub: make sure your phone is on the same 2.4 GHz network during setup.

6. Warranty

The Nimbus Home Hub carries a 24-month limited warranty covering manufacturing defects in materials and workmanship. The warranty does not cover physical damage, water damage, or unauthorized modifications. To claim, contact support with your proof of purchase.